



UNITED
NATIONS

EP

UNEP(DEPI)/MED WG.421/Inf.14



UNITED NATIONS
ENVIRONMENT PROGRAMME
MEDITERRANEAN ACTION PLAN

11 September 2015
Original: English

Meeting of the MAP Focal Points

Athens, Greece, 13-16 October 2015

Agenda item 3: Progress Report on Activities Carried Out during the 2014 - 2015 Biennium

Report of the joint Regional Meeting on environmental sound management and illegal traffic of chemicals and hazardous waste in the Mediterranean, Istanbul, April 2015

For environmental and economic reasons, this document is printed in a limited number. Delegates are kindly requested to bring their copies to meetings and not to request additional copies.



**UNITED
NATIONS**

EP

UNEP(DEPI)/MED WG.409/5



**UNITED NATIONS
ENVIRONMENT PROGRAMME
MEDITERRANEAN ACTION PLAN**

UNEP

29 April 2015
Original: English

Regional joint meeting on environmental sound management and
illegal traffic of chemicals and hazardous waste in the Mediterranean.

Istanbul, Turkey, 7- 9 April 2015

Report of the Meeting

For environmental and economic reasons, this document is printed in a limited number. Delegates are kindly requested to bring their copies to meetings and not to request additional copies.

UNEP/MAP
Athens, 2015

Table of contents

Report

Annex I List of Participants

Annex II Provisional Agenda

Annex III Conclusions and Recommendations

Annex IV Guide for ESM of PCB and Fact Sheets

Annex V Presentations

Introduction

1. The Barcelona Convention for the Protection of the Marine Environment and the Coastal Region of the Mediterranean and its related Protocols (Land-based Sources and Activities Protocol, and the Hazardous Waste Protocol) and in particular the Strategic Programme to combat pollution from Land Based Sources addressed the PCB phasing out and their environmental sound disposal.
2. The international conventions such as Stockholm Convention on Persistent Organic Pollutants (POPs) counts PCBs among the substances targeted for worldwide elimination. The existing PCBs and all equipment contaminated with PCBs have to be eliminated in an environmentally sound manner without producing hazards for humans or the environment by 2028. PCB treatment or disposal technology must comply with the highest safety and environmental standards and must be capable of reducing the PCB contamination level of those pieces of equipment suitable for re-classification below the legally permitted level of 50 ppm as well as assure that the PCB level remains below that limit. Other global and regional conventions regulate the management of dangerous chemicals and hazardous wastes addressing PCB such as the Basel Convention, as well as the Rotterdam Convention.
3. The Regional joint meeting on environmental sound management and illegal traffic of chemicals and hazardous waste in the Mediterranean was held in Istanbul, Turkey on 7- 9 April. The meeting was co-organized by UNEP/MAP-Barcelona Convention, Basel Convention Secretariat and the Horizon 2020 Initiative capacity building component through the SWIM project, and took place at the Central Palace hotel, Istanbul, Turkey on 7- 9 April 2015.
4. The **objectives of this Regional Meeting** were:
 - a) Review of Polychlorinated Biphenyl (PCB) ESM guidelines and fact sheets prepared by the UNEP/MAP Secretariat.
 - b) Round table on lessons learnt, challenges and ways and means to enhance PCB and HW ESM, including their disposal.
 - c) Strengthening Mediterranean countries capacities to combat illegal trafficking of chemicals and hazardous waste (training sessions).

Participation

5. The meeting was attended by 40 participants from the following Contracting Parties: Albania, Algeria, Bosnia and Herzegovina, Cyprus, Egypt, Israel, Lebanon, Malta, Montenegro, Morocco and Turkey. Palestine also attended the meeting as an observer.
6. The Secretariat of the Mediterranean Action Plan (UNEP/MAP), was represented by MED POL Programme (MED POL). Representatives of the Joint Secretariat of the Basel, Rotterdam and Stockholm Conventions, UNEP/MAP Regional Activity Centre for Sustainable Consumption and Production (SCP/RAC), as well as of MIO-ECSDE Greece and Turkish Marine Research Foundation, were also present at the meeting.
7. The full list of participants is attached as Annex I to this report.

Agenda items 1, 2 & 3: Opening of the meeting, election of Officers, and Adaption of the Agenda and organization of work

8. The Meeting was opened at 9.00 a.m. on 7 April 2015 by Mr. Sabahattin Dokmeci, Deputy General Manager - Ministry of Environment and Urbanisation followed by Mrs. Tatjana Hema, UNEP/MAP – MED POL Programme Officer and Mr. Tarcisio Hardman Reis, UNEP/ Secretariat of Basel, Rotterdam and Stockholm Conventions Programme Officer. Mr. Sabahattin Dokmeci in his speech welcomed all participants and wished them fruitful outcomes for this

meeting and a pleasant stay in Istanbul. He pointed out the work done by UNEP/MAP to support Turkey in PCB awareness and strengthening capacity for PCB inventory and disposal. Mrs. Tatjana Hema in her speech welcomed all participants and briefed about UNEP/MAP-MED POL work and MedPartnership project to support PCB awareness, capacity building, inventory and disposal in the Mediterranean countries. Mr. Tarcisio Hardman Reis in his opening speech focused on the role of Basel Rotterdam Stockholm Conventions Secretariat (BRSCS) and the cooperation with UNEP/MAP Secretariat in the field of hazardous waste transboundary movement. control.

9. Following the opening speeches the meeting elected its officers as follows:

Chairperson: Ms. Refet Sinem Atgin, Turkey

Vice-Chairperson: Ms. Elham Refat, Egypt

Rapporteur: Mr. Redi Baduni, Albania.

10. The meeting adopted the agenda (UNEP(DEPI)/MED WG.409/1 presented in Annex II of the present report and annotated agenda presented in UNEP(DEPI)/MED WG.409/2.
11. Interpretation in English and French was provided at the meeting.

Agenda item 4: Review of ESM Guidance and Fact sheets on PCB

12. Under this agenda item, the Secretariat invited Mr. Urs Wagner, MED POL PCB consultant, to present:
- a) PCB ESM Guidelines (document UNEP (DEPI)/MED WG. 409/3) containing information on maintenance of equipment, PCB wastes, safety and emergency actions, phase out and storage of PCB, treatment and disposal options, risk assessment, and draft template of PCB phase out plan.
 - b) PCB Fact sheets (document UNEP (DEPI)/MED 409.4) addressing identification of PCB transformers, PCB Awareness raising, identification of PCB capacitors, PCB open applications, and PCB handling, packing, and transport.
13. The meeting reviewed the proposed Guide, suggested and agreed on a number of changes that are summarized in Annex III of the present report.
14. The participants worked in three groups with the support of the experts to complete the fact sheets with information as appropriate on the state of play of PCB management at the national level.. Some countries completed their information requested in the fact sheets. The other countries will continue working and submit the final fact sheets after the meeting.

Agenda item 5: PCB Management and disposal, lessons learned and challenges in the framework of MedPartnership project implementation.

15. The four countries participating in the MedPartnership project (Albania, Bosnia and Herzegovina, Egypt, and Turkey) made presentations on their experiences related to management and disposal of PCB, as well as on lessons learned and challenges faced during the project implementation. In addition, Lebanon also made a presentation on their national PCB management system and related projects. The Secretariat also made a presentation on the overall project implementation and lessons learned from the regional perspective. Annex IV includes all presentations.

Agenda item 6: Strengthening Mediterranean Countries Capacities to efficiently combat illegal trafficking of chemicals and hazardous waste (focus on PCB).

16. The representative of the Joint Basel, Rotterdam and Stockholm Secretariat made a number of

presentations and provided training on the following topics:

- a) An overview of Export/Import/Transit controls under the Basel, Rotterdam and Stockholm Conventions.
- b) Practical aspects of enforcement of chemicals and hazardous waste with particular focus on precaution aspects and related tools on the regional and national levels.
- c) Basel, Rotterdam and Stockholm Conventions tools and materials.

Agenda item 7: Round table on the Mediterranean priorities with regards to ESM of chemicals and hazardous waste illegal trafficking (focus on PCB).

17. Under this agenda item, Ms. Gehan El Sakka, Task manager consultant for UNEP/MAP – MED POL – MedPartnership made a presentation on UNEP/MAP legal framework addressing hazardous waste, including the first draft of the general framework of the regional strategy for combating illegal trade and dumping of hazardous chemical and wastes in the Arab region prepared in 2007 – 2008.
18. Ms. Nancy Isarin, H2020 consultant made two presentations addressing illegal trafficking of hazardous waste presented in Annex IV of the present report.
19. The participants were separated into three smaller groups to carry out some exercises related to shipment of hazardous waste. Each group reported back to plenary the results of the exercise.

Agenda item 8: Conclusions and recommendations

20. Under this agenda item the Secretariat presented a set of draft conclusions and recommendations that were agreed upon as amended and contained in Annex III of this report.

Agenda item 9: Closure of the Meeting

21. Mr. Sabahattin Dokmeci, Deputy General Manager, making some final remarks thanked the Secretariat and the participants for their constructive contribution and wished them a safe trip back home. The Chairperson closed the meeting at 17:00 pm on 9 April 2015.

Annex I
LIST OF PARTICIPANTS
LISTE DES PARTICIPANTS

<p>ALBANIA ALBANIE</p>	<p>Mr. Redi Baduni Director of Directory of Environment Ministry of Environment , Albania Duresi Str., 27 Tirana Albania Tel: +355 42 270623 Mob: +355 672042259 E-mail: Redi.Baduni@moe.gov.al</p> <p>Ms. Blerina Xhixha Specialist, Sector of waste and Industrial Accident, Directory of Environment Ministry of Environment , Albania Duresi Str., 27 Tirana Albania Tel: +355 42 270623 Mob: +355 5672520471 E-mail: Blerina.Xhixha@moe.gov.al</p> <p>Ms. Rovena Agalliu Specialist, Sector of Air ,Climate change and Chemical, Directory of Environment Ministry of Environment , Albania Duresi Str., 27 Tirana Albania Tel: +355 42256106 Mob: +355 695693240 E-mail: Rovena.Agalliu@moe.gov.al</p>
<p>ALGERIA ALGERIE</p>	<p>Mr. Abdelbaki Djemaat Engineer of State for the Environment Ministry of Land Planning and Environment Rue de 4 Canons 16000 Alger Algerie Tel: +213 21432852 Mob: +213 664664542 Email: essahili2010@gmail.com</p>

<p>BOSNIA AND HERZEGOVINA BOSNIE-HERZEGOVINE</p>	<p>Mr. Senad Oprasic Ministry of Foreign Trade and Economic Relations of Bosnia and Herzegovina Musala 9 71000 Sarajevo Bosnia and Herzegovina Tel : +387 33953536 Email: senad.oprasic@heis.ba</p> <p>Ms. Irem Silajdzic Environment Engineer/leading Researcher Institut za Hidrotehniku GF Stjepana Tomica Street 1 71000 Sarajevo Bosnia and Herzegovina Tel: +387 33 212466 Fax:+387 33212467 Email: irem.silajdzic@heis.ba</p> <p>Ms Ines Fejzic Environmental Consultant ENOVA Consultants and Engineers Podgaj 14 71000 Sarajevo Bosnia and Herzegovina Tel: +387 33 279107 Mobile: 387 61800580 Email: ines.fejzic@enova.ba</p> <p>Ms. Maja Maretic Tiro Senior Environmental Consultant/ Head of Environmental Programme Enova , Consultants and Engineers Podgaj 14 71000 Sarajevo Bosnia and Herzegovina <u>Tel:+387 33279103</u> Mob:+387 33279108 Email: maja.maretic-tiro@enova.ba</p>
<p>CYPRUS CHYPRE</p>	<p>Neoklis Antoniou Environment Officer Department of Environment Ministry of Agriculture, Rural Development and Environment 20-22 28th Octovriou Ave 2414, Nicosia, Cyprus Tel: +357 22408936 Fax: +357 22774945 Email : nantoniou@environment.moa.gov.cy</p> <p>Demetris Demetriou Environment Officer Department of Environment Cyprus Ministry of Agriculture, Rural Development and Environment 1498, Nicosia, Cyprus</p>

	<p>Tel: +357 25802713 Mob +357 99133602 Fax: +357 22774945 Email : ddemetriou@environment.moa.gov.cy</p>
<p>EGYPT ÉGYPTE</p>	<p>Elham Refaat Abdel Aziz Stockholm Convention Focal Point General Director of Environmental Development Department Manager of Integrated Management for PCBs . MED POL Project Manager of Integrated Management of Medical Waste Project Egyptian Environmental Affairs Agency 30 Misr Helwan El-Zyrae Rd.Maadi, Cairo , Egypt P.O.11728 Mobil: 01009183010 Tel.: +2 02 25256452 Ext.: 8879 Email: emorefaat@yahoo.com</p> <p>Ms. Amel Barakat Environment Researcher Egyptian Environmental Affairs Agency (EEAA) OmZeghio Road Km 21 connection Alexandria Egypt Tel: +203 020691 Mob +002 01283439536 Fax: +203 3024477 Email: barakat_amel@yahoo.com</p> <p>Ms. Manal Farag Environmental auditor in hazardous waste and substances sector/ Deputy Project Manager of PCBs Project (MED POL) National Director of POPs Project Egypt (GEF/Worldbank) Egyptian Environmental Affairs Agency (EEAA) 30 Misr Helwan El Zyrae road Maadi, Cairo Egypt Tel: +202 25256454 Mob +001 005504944 Email: m5samyFarag@gmail.com</p>
<p>ISRAEL ISRAEL</p>	<p>Mr. Helal Tarbush Hazardous Materials Supervisor Ministry of Environmental Protection Northern District Nazareth Illit Israel Tel: +972 4 6059136 Mob: +972 5444914787 Email: hillalti@sviva.gov.il</p>
<p>LEBANON LIBAN</p>	<p>Ms. Sabine Ghosn Environment Specialist Ministry of Environment Beirut Lebanon</p>

	<p>Tel: +961 3740171 Email: s.ghosn@moe.gov.lb</p>
MALTA	<p>Mr. Kevin Mercieca Unit Manager Malta Environment and Planning Authority Hexagon House Spencer Hill Marsa Malta Tel: +356 22907200 Mob: +356 99444036 Email: kevin.mercieca@mepa.org.mt</p>
MONTENEGRO	<p>Mr. Pavle Duraskovic Head Environment Department IV Proleterske no. 19 Podgorica Crna Gora 81000 Montenegro Tel: +38220655365 Mob:+382 67592925 Fax:+382 20655197 Email: pavle.djuraskovic@meteo.co.me</p>
MOROCCO MAROC	<p>Mr. Mohammed El Bouch Chef de Division du Laboratoire National des études et de Surveillance de la Pollution Environment Ministry 9,Al Arrar Street, Sector 16, Hay Ryad, Rabat Morocco Tel : + 212 5 37 57 0118 Mob : +212 637082936 Email : elbouch21@yahoo.fr</p> <p>Mr. Khalid Margaa Head of Prevention Office/Focal Point Basel and Rotterdam Environment Ministry 9,Al Arrar Street, Sector 16, Hay Ryad, Rabat Morocco Tel : + 212 537576605 Mob : +212 661706054 Email : margaakhalid@yahoo.fr</p>
TURKEY	<p>Mr. Sabahattin Dokmeci Deputy General Manager Ministry of Environment and Urbanisation Ehlibeyt Mah Ceyhun Atuf Kansu Cad .1271 SOK. NO: 13 06520 Blagat Cankaya Ankara Turkey Tel: + 90 312 4740326 Fax:+ 90 312 4740335 Email: sebahattin.dokmeci@csb.gov.tr</p> <p>Mr. Ahmet Varir Departement Head Ministry of Environment and Urbanisation Ehlibeyt Mah Ceyhun Atuf Kansu Cad .1271 SOK. NO: 13 06520 Blagat Cankaya Ankara</p>

Turkey
Tel: + 90 312 4740315
Fax:+ 90 312 3124740335
Email: ahmet.varir@csb.gov.tr

Mr. Gokhan Sentutk
Section Chief
Ministry of Environment and Urbanisation
Ehlibeyt Mah Ceyhun Atuf Kansu Cad .1271
SOK. NO: 13 06520 Blagat Cankaya Ankara
Turkey
Tel: + 90 312 5863078
Fax:+ 90 312 3124740335
Email: gokhan.senturk@csb.gov.tr

Ms. Halime Sezer
Section Chief
Ministry of Environment and Urbanisation
Vekaletter Cad. No. 1
Bakemliklar-Gonkaya
Ankara
Turkey
Tel: + 90 3124101965
Mob:+90 5065816438
Fax:+ 90 312 4190257
Email: halime.sezer@csb.gov.tr

Ms. Refet Sinem Atgin
Expert
Ministry of Environment and Urbanisation
General Directorate of Environmental
Management
Ehlibeyt Mah 1271
Sokak No. 13
Balgat, Ankara
Turkey
Tel: +90 312 5863103
Mob:+905332424500
Fax: +903124740335
Email: rsinem.atgin@csb.gov.tr

Mr. Sabahattin Turan
Assistant Expert
Ministry of Environment and Urbanisation
Ehlibeyt Mah Ceyhun Atuf Kansu Cad .1271
SOK. NO: 13 06520 Balgat Cankaya Ankara
Turkey
Tel: + 90 312 5863033
Mob:+ 90 05452751778
Fax:+ 90 312 4740335
Email: sturan460@gmail.com
sabahattin.turan@csb.gov.tr

Ms. Sadiye Bilgic Karabulut
Engineer
Ministry of Environment and Urbanisation

	<p>Ehlibeyt Mah Ceyhun Atuf Kansu Cad .1271 SOK. NO: 13 06520 Balgat Cankaya Ankara Turkey Tel: + 90 3125863264 Mob:+90 5357146928 Fax:+ 90 312 4740335 Email: sadiye.karabulut@csb.gov.tr</p> <p>Mr. Ertan Ozturk Expert Ministry of Environment and Urbanisation Ehlibeyt Mah Ceyhun Atuf Kansu Cad .1271 SOK. NO: 13 06520 Balgat Cankaya Ankara Turkey Tel: + 90 312 5863192 Mob:+90 5322051301 Fax:+ 90 312 4740318 Email: ertan.ozturk@csb.gov.tr</p> <p>Mr.Gulsen Sahin Otulu Expert Ministry of Environment and Urbanisation Ehlibeyt Mah Ceyhun Atuf Kansu Cad .1271 SOK. NO: 13 06520 Balgat Cankaya Ankara Turkey Tel: + 90 312 5863246 Fax:+ 90 312 3124740335 Email: gulsen.oltulu@csb.gov.tr</p> <p>Ms. Menekse Keski Chemist Ministry of Environment and Urbanisation Ehlibeyt Mah. Ceyhun Atuf Kansu Cad .1271 sk No: 13 06520 Balgat Cankaya Ankara Turkey Tel: +90 312 5863194 Email: menekse.keski@csb.gov.tr</p> <p>Ms Sabriye Ayhan Section Chief Ministry of Environment and Urbanisation Ehlibeyt Mah Ceyhun Atuf Kansu Cad .1271 SOK. NO: 13 06520 Balgat Cankaya Ankara Turkey Tel: +90 312 5863083 Email:sabriye.ayhan@csb.gov.tr</p>
--	--

OBSERVERS

<p>PALESTINE</p>	<p>Mr. Atef Jaber Director of Solid and Hazardous Waste- Stockholm Convention Focal Point Environment Quality Authority (EQA) Abu Baker Street, Al Jawazat, 1st Junction, Rafah, Gaza Strip Palestine Tel : + 972 8 2131506 Mob : +972 599 730157 Email : amhjaber@yahoo.com</p> <p>Mr. Yaser Abu Shanab Director of Public Health Environment Quality Authority (EQA) Al Sharafs,Al Bireh, BO box 3841 Palestine Tel : + 970 2 2403495/8 Mob : +970 599264230 Email : yaser_shanab@hotmail.com</p>
-------------------------	---

MAP PARTNERS

<p>APNEK</p>	<p>Mr. Ameer Jeridi CEO-Executive President APNEK 1 Rue Istamboul 2080 Ariana Tunisia Tel: +216 98305586 Fax: +216 70 731085 Ameer.ahmad.jeridi@gmail.com</p>
<p>Arab Office for Youth and Environment</p>	<p>Mr. Essam Nada Executive Director Arab Office for Youth and Environment (AOYE) 3° Masaken Masr Lel-Taameer Zahraa El-Maadi Street, 11931 Cairo Egypt Tel: +202 251 61519/245 Mobile: +201 001188998 Email: e.nada@aoye.org</p>
<p>Centre for Environmental and Sustainable Development, Bosnia</p>	<p>Ms Sanda Midzic Kurtagic Executive director Centre for Environmental Sustainable Development Bosnia and Herzegovina Stjepana Tomica Street 1a 71000 Sarajevo Bosnia and Herzegovina Tel : +387 33 212466 Email: sanda@coor.ba</p>
<p>CMED MOROCCO /RAED</p>	<p>Mr. Mohamed Ftouhi Moroccan Club of Environment and Development (CMED)</p>

	<p>Tel: +212 661546591 Email: ftouhimohamed21@gmail.com</p>
ECAT Tirana	<p>Ms. Marjeta Mima Director of ECAT Tirana RrA Frasheri, Pall.16/Shk.6/Ap53 Tirana Albania Tel: +355 42 223930 Mob: +355 682024054 Fax: +355 42223930 E-mail: mima@ecat-tirana.org</p>
Ecological Association of Boumerdes Algeria	<p>Mr. Nacer Riad Bendaoud President Ecological Association of Boumerdes Boumerdes El Bahran (Rocher Noir) Tel: +213(0) 771594353 Email: aeb-boum@hotmail.com</p>
MIO-ECSDE Greece	<p>Ms. Thomais Vlachogianni Programme Officer Mediterranean Information Office for Environment, Culture and Sustainable Development (MIO-ECSDE) 12, Kyrristou str. 105 56, Athens, Greece Tel: +30 210 3247490 Email: vlachogianni@mio-ecsde.org</p>
Tudav Turkish Marine Research Foundation	<p>Dr. Ayaka Amaha Ozturk Mr. Ozgegul Ozturk H20202 Ms Esra Billur Balcioglu</p> <p>Turkish Marine Research Foundation P.O Box 10 Beykoz 81650 Istanbul Turkey Tel: +90 216 4240772 Fax: +90 216 2420771 Email: tudav@tudav.org</p>

**UNITED NATIONS ENVIRONMENT PROGRAMME/
MEDITERRANEAN ACTION PLAN**

United Nations Environment Programme Mediterranean Action Plan (UNEP/MAP)	<p>Ms. Tatjana Hema MED POL Programme Officer Tel: +30 210 7273115 Email: tatjana.hema@unepmap.gr</p> <p>Ms. Shelley Farrington MedPartnership and MED POL Assistant Tel: +30 210 7273135 Email: shelley.farrington@unepmap.gr</p> <p>United Nations Environment Programme Mediterranean Action Plan 48 Vassileos Konstantinou 11635 Athens</p>
--	---

	<p>Greece</p> <p>Ms. Gehan Mohamed El Sakka MAP MED POL and MedPartnership Consultant Tel: +306943994479/ +201113357651 medpol.medpartnership@unepmap.gr gelsakka2004@yahoo.com United Nations Environment Programme Mediterranean Action Plan 48 Vassileos Konstantinou 11635 Athens Greece</p> <p>Mr. Urs K. Wagner MAP wagner@eti-swiss.com</p> <p>Mr Panagiotis Iokimidis MAP iokimidispan@gmail.com</p>
<p>UNEP/Secretariat of the Basel, Rotterdam and Stockholm Conventions</p>	<p>Mr. Tarcisio Hardman Reis Programme Officer UNEP/ Secretariat of Basel, Rotterdam and Stockholm Conventions 15, Chemin des Anemones, 1219 Chatelaine, Switzerland Tel: +41229178341 Email: Tarcisio.HardmanReis@brsmeas.org</p>
<p>Regional Activity Centre for Sustainable Consumption and Production (SCP/RAC)</p>	<p>Mr. Manolo Clar Messanet Consultant Regional Activity Centre for Sustainable Consumption and Production (SCP/RAC) Carrer d'Angli, 31 3rd Floor Barcelona Tel : +34 93 5538790 Email : mclar@pmecon.com</p> <p>Mr. Omer Hallac info@omerhallac.com</p>
<p>H2020 MEP/EU-SWIM Project</p>	<p>Ms. Konstantina Ithakisiou LDK Consultants Tel: +30 210 8196720 Email: cit@ldk.gr</p> <p>Ms. Eirini Sakellaraki LDK Consultants Off 21, Thivaidos str, GR 145 64 Kifissia, Athens, Greece Tel: +30 210 8196720 Email: irini@ldk.gr</p> <p>Ms. Nancy Isarin Consultant LDK Nancy.isarin@ambiendura.com</p>

Annex II Agenda

Agenda item 1: Opening of the Meeting

Agenda item 2: Election of Officers of the Bureau

Agenda item 3: Adoption of the Agenda and Organization of Work

Agenda item 4: Review of Polychlorinated Biphenyl Environmental Sound Management (PCB -
ESM) guidelines and fact sheets.

Agenda item 5: Polychlorinated Biphenyl (PCB) management and disposal, lesson learnt and challenges in the framework of UNEP/MAP GEF MedPartnership project.

Agenda item 6: Strengthening Mediterranean countries capacities to efficiently combat illegal trafficking of chemicals and hazardous waste (focus on PCB).

- a) An overview of Export/Import/Transit controls under the Basel, Rotterdam and Stockholm Conventions.
- b) Practical aspects of enforcement with particular focus on precaution aspects and related tools on the regional and national levels.
- c) Group exercise.

Agenda item 7: Round table on the Mediterranean priorities with regard to ESM of chemicals and Hazardous waste illegal traffic.

Agenda item 8: Conclusions and recommendations

Agenda item 9: Closure of the Meeting

Annex III: Conclusions and recommendations

Introduction:

In the framework of UNEP/MAP and the H2020 Programme of work (PoW), under the MedPartnership project, the UNEP/MAP Secretariat (MED POL) in collaboration with the Basel, Rotterdam and Stockholm Conventions Secretariat, organised a regional joint meeting on environmental sound management and illegal traffic of chemicals and hazardous waste in the Mediterranean held in Istanbul, Turkey 7, 8 and 9 April 2015 at the kind invitation of the Ministry of Environment and Urbanization of Turkey.

The meeting reviewed and took note of the following documents and developments:

- a) The draft guide on the environmentally sound management of PCBs in the Mediterranean as well as the related fact sheets;
- b) The progress of implementation of the PCB Component of the MedPartnership project by the participating countries and at the regional level;
- c) The PCB management country profile fact sheets
- d) Exchange of views on ways forward and next steps to also ensure MedPartnership's project results sustainability beyond 2015.
- e) The overall framework of the Basel, Rotterdam and Stockholm Conventions on hazardous chemicals and wastes, their transboundary procedures, monitoring, detecting illegal waste traffic, customs collaboration, and tools developed to support the law enforcement agencies.

A training session was dedicated on combating illegal trafficking of waste, carried out by the Basel Convention representative.

Finally the meeting had a round table discussion on ways forward and means to strengthen the POPs ESM and combat illegal trafficking of waste in the Mediterranean.

The meeting agreed on the following conclusions and recommendations:

- I. **Guide on the environmentally sound management of PCBs in the Mediterranean region UNEP(DEPI)/MED WG.404.3 (hereafter referred to as the Guide) and related fact sheets UNEP(DEPI)/MED WG.404.4**
 - a) **The meeting appreciated the very good quality of the proposed guide and fact sheets and approved its content, provided that the following changes are made to the document and sent to the participants by 18 April 2015 the latest for final validation 5 May at the latest:**

Title

To change the title of the document to: "Guide on the environmentally sound management of PCBs in the Mediterranean"

- **Chapter 0**

To revise the list of Abbreviations, in order to also include the abbreviations used in the annexes to the Guide.

- **Chapter 2**

1. To add the following footnote on page 20 in relation to step one 'Year of manufacture' in paragraph 2.2.3: "It is recommended to choose the year of manufacturing of the capacitors in line with national legislation. In case a reference year is missing in national legislation it is recommended to use 1993 as reference year."

2. To add to paragraph 2.2.7 the following sentence: “Sampling of soil and ground water is to be carried according to protocols, whose description is beyond the scope of this guide. “
3. To mention under sub chapter 2.4 that the database should also include data related to PCB contaminated hotspots, including sites and groundwater.
4. To add to sub chapter 2.5 a sentence recommending that the contracting Parties use the proposed labels, presented in picture 32 to 34 for the purpose of maintenance and while in service. For the export purposes countries shall use the labels as referred to in chapter 8.2.2 in line with the Basel Convention requirements.
5. To shift paragraph 2.2.3 to after paragraph 2.2.5.
6. To add under paragraph 2.2.2 reference to a more detailed description on the sampling procedures to be provided in annex 12.15 of this guide.
7. To clarify that in relation to the Density test and the Beilstein screening methods as mentioned in the current sub chapter 2.3, they may only be used as an emergency method, or in case of severe lack of resources and under certain circumstances.

○ **Chapter 3**

1. To slightly revise paragraph 3.1.1 by clarifying that the company has to assign to one or several people, depending of the size of the company, the responsibilities of implementing the procedures as described below.
2. To add a sentence to sub chapter 3.3 that ‘Particular importance should be given to get better insight in unknown sources, equipment or hotspots.’
3. To amend the title of paragraph 3.1.7 into “Disposal and site decontamination plan” and to add a text on decontamination of PCB polluted sites.
4. To amend the title of paragraph 3.3.3 into ‘Priorities for disposal and site decontamination’ and add a text on site decontamination.
5. To add to sub chapter 3.1 the sentence: “The management plan should be based on the polluter pays principle and should be in line with national law, regulations and priorities.”

○ **Chapter 4**

1. To shift paragraph 7.2.4 to a new section under 4.1.
2. [To amend the title of sub chapter 4.2 from ‘Maintenance’ into ‘Inspection of PCB containing transformers’].
3. To add under the new sub chapter 4.2 an additional bullet point highlighting the role of universities, NGOs and related stakeholders in promoting the dissemination of PCB management’s best practices.
4. To slightly revise the sub chapter 4.4 in order to clarify what can be decontaminated and re-used, and what should be disposed of.
5. To amend the title of paragraph 4.3 from ‘Maintenance’ into ‘Evaluation’.

○ **Chapter 5**

1. To add to sub chapter 5.1 the fact that people handling PCBs or people that can be potentially exposed to PCBs use adequate protective equipment. The level of protection and the choice of protective equipment depends highly on the tasks carried out.
2. To include in table 11 and table 12 only filters relevant to PCBs.

○ **Chapter 6**

To add to the introductory part of chapter 6 that, in case of incidents, accidents or spills in line with national regulation and environmental permit standards the company should notify all competent authorities.

- **Chapter 7**

Add a paragraph on decontamination of hot spots.

- **Chapter 9**

To add a new sub chapter 9.3 on 'Authorization and Control', and delete the box on 'Control' in sub chapter 9.1. Under the new sub chapter 9.3 it should be mentioned that the establishment of an interim storage facility or central storage area is only possible after submission of an Environmental Impact Assessment study and is subject to authorization. An extension of temporary storage beyond the period of 12 months as recommended, is subject to authorization by the competent authorities.

- **Chapter 10**

1. To add to sub chapter 10.3 a text that stresses the need to develop national legislation to regulate criteria for transport hazardous wastes, such insurance, registration, and license and safety aspects.
2. To mention that under sub chapter 10.4 direct reference should be made to the provisions of the Basel Convention.

- **Chapter 11**

1. To add to the introductory part that among the criteria to be used to select the treatment and disposal options, BAT/BEP and already approved technologies shall be considered, as well as the need to carry out an Environmental Impact Assessment study.
2. To clarify in sub chapter 11.1 that the co-processing technologies, if not prohibited by national legislation, shall be implemented according to the Basel Convention Technical Guidelines on the environmentally sound co-processing of hazardous wastes in cement kilns as well as the relevant national legislation and regulations.
3. To change the title of chapter 11 into 'Pre-treatment, treatment and disposal' and revise table 21 accordingly. Also to this table the de-chlorination treatment option will be added.

b) The meeting requested the Secretariat to consider future work and provide support and guidance to the countries with regards to groundwater and soil sampling and their PCB decontamination as well as providing official information on the list of international disposal companies and accredited PCB laboratories.

c) Appreciating the work done in advance of and at the meeting for the preparation of the national country profile of the PCBs fact sheets, the meeting invited the participants to send by e-mail to the Secretariat their final version at the latest 30 April 2015.

II. Country experiences, lessons learned and challenges in PCB management and disposal

a) Following four country's presentations on their national experiences with the PCB management project, the meeting highly appreciates the progress achieved and the added value of the Medpartnership project. Thanking the project teams (countries and the Secretariat), the meeting took note of the following lessons learned and challenges faced during project implementation:

1. The clear and continuous need for comprehensive awareness raising and education campaigns and training targeting all involved various stakeholders, including national guidance on identification and ESM of PCBs.

2. The need for ongoing coordination and cooperation between the national involved entities and the need to reconsider and improve the institutional set up by establishing an effective and reliable mechanisms of coordination
3. Lack of or outdated specific national regulations addressing PCBs hinder an effective PCB management approach and limit the options of the involved authorities. Development or updating of regulations dealing with PCBs was strongly recommended, therefore the preparation of the Guide was appreciated as a tool to support the countries in developing and implementing PCB specific regulations.
4. The need to improve the link with Customs and establish criteria and mechanisms for the customs control of import, export and transit of equipment and products potentially containing PCBs.
5. The recognition that collecting good quality data for national PCBs inventories is essential for an adequate management plan. Communication with the companies is important aspect in this, as well as onsite sampling and analysing. Also facilitating easy filling of the database should be promoted, e.g. online.

b) Following a presentation by the Secretariat, which provided an overview of the project, the meeting acknowledged the added value the project, in particular the opportunity for the participating countries to exchange their experiences at the regional level, and highlighted the following lessons learned:

1. Ownership and leadership of the project by the individual countries is a must, including dedicated human resources, budget and time. The use of local consultants added to the success of the project in supporting national PCB teams.
2. Phase out plans for replacing in-use PCB transformers should be developed by the responsible government authorities in order to promote the replacement of contaminated transformers.
3. Cross-contamination is a very sensitive issue, and measures to control and prevent cross-contamination should be given high priority. In this respect national regulation should provide for a. screening before transformer or a capacitor draining, to make sure they are PCB free, b. further import and export of new or refurbished transformer and capacitors is allowed only with a certificate and analysis to proof that the dielectric oil is PCB free.
4. Dedicated customs codes should be developed to differentiate between new, refurbished and waste equipment containing PCBs.
5. Soil contamination was also identified a critical area during the project. Solutions to prevent soil contamination should be further developed in the future including remediation measures.
6. Future work should focus on supporting *inter alia* developing and implementing PCB specific regulations, implementing the Guide, updating the PCB inventory database, improve reporting to UNEP MAP and the Stockholm Convention, replicating the experience of the MedPartnership project in other countries in close collaboration with the global and regional partners, in particular the Basel and Stockholm Conventions, and continue with awareness raising activities targeting all stakeholders at national and regional levels.

c) The meeting invited the participating countries to consider reporting the success of the PCB component of the MedPartnership project, in collaboration with the UNEP/MAP Secretariat, to the forthcoming Conference of the Parties to the Stockholm Convention in May 2015 as a contribution of Regional Seas Conventions and the Mediterranean region specifically towards global and regional PCBs related targets.

III. Training on illegal trafficking of waste

1. The meeting followed with high interest the presentations made by the representative of the Basel, Rotterdam and Stockholm Conventions Secretariat on the overall framework of the three Conventions, and more specifically the procedures for importing and exporting chemicals and wastes covered by the

Conventions and detecting illegal trade and traffic. Some of the tools developed under the coordination of the Secretariat aiming to support law enforcement entities were highlighted. The presentation generated many questions from the audience.

2. The UNEP/MAP Secretariat delivered a presentation on the regulatory and policy framework in the Mediterranean region on hazardous waste and on combating illegal trafficking.

3. The meeting appreciated the further practical training on specifically illegal trafficking of PCBs wastes, in particular an exercise about dealing with a possible illegal shipment of mixed chemicals.

4. Areas identified which pose challenges and risks in relation to illegal trafficking of PCBs include e-waste, cable waste and ships destined for dismantling. Training activities to enhance country capacities to combat illegal trafficking are needed including training on investigation, monitoring, inspection and enforcement as well as environmental prosecution.

IV. Round table discussion and future priorities

a) Based on the discussions held during the three-days, the last session was dedicated to highlight the Mediterranean priorities and challenges on proper management of obsolete chemicals as well as combating illegal trafficking.

b) Following the exchange of views, the meeting highlighted the need for further coordinated work on:

General priorities

1. Further streamlining tools with Basel and Stockholm conventions for national inventories and reporting (HW and POPs including PCB).
2. Jointly developing tools for implementing global/regional guidelines on management of chemicals and wastes, thus taking into account regional specificities and country needs with a strong dimension on prevention and related SCP tools while taking into consideration the most recent technical guidelines of the BRS conventions
3. Coordinating capacity building activities in the region by the specialized Regional Centres established under BRS and UNEP/MAP Barcelona Convention working in the Mediterranean.
4. Encouraging further consolidation of the informal compliance and enforcement network established under the LBS Protocol of the Barcelona Convention, and as appropriate the extension of its scope and composition to address illegal trafficking under the HW Protocol of the UNEP/MAP-Barcelona Convention and encourage networking and exchange of experience with other enforcement networks in particular with ENFORCE established under the Basel Convention and IMPEL TFS.
5. Considering to work at the national level more closely with NGOs, Universities and other relevant stakeholders in developing knowledge and creating awareness on PCB management and combatting HW illegal trafficking.
6. Better supporting country's efforts in increasing internal and external resource and funds mobilization through project proposals to address their needs on HW and POPs ESM including a regional dimension as well as the implementation of pilot projects at country level taking into account the need to integrate and mainstream climate change and other drivers in POPs and HW management.

Specific priorities related to the ESM of PCB

Supporting the implementation of the PCB Guide including the development and update of PCB specific regulations.

Providing technical support on inventories of PCB in open applications and address this issue in the updated NIPs as appropriate

Providing support on the development of sampling and monitoring protocols as well as decontamination of soil and groundwater

Supporting countries in the development of customs codes to differentiate between new, refurbished and waste equipment containing PCBs.

Undertaking awareness raising activities for the public and decision makers of all levels on POPs including PCB ESM

- **Specific priorities related to transboundary movement of HW**

Considering the preparation by UNEP/MAP in close consultation with the BRS Conventions Secretariat of a work plan to support the Mediterranean countries to strengthen their capacities with regards to transboundary movement, preventing and combatting illegal trafficking of HW

- Undertaking training activities to enhance country capacities to combat illegal trafficking including on investigation, monitoring, inspection and enforcement as well as environmental prosecution.
- Supporting the establishment of mechanisms to strengthen coordination with customs to obtain data,
- Collaborating with relevant authorities including the links between customs and enforcement authorities such as police, persecutors, inspectors, judges, etc).

Annex IV: Guide for ESM of PCB

Guide on the Environmentally Sound Management of PCBs in the Mediterranean



Rev. Edition from April 16, 2015

Table of content

1.	Introduction.....	10
1.1.	Polychlorinated Biphenyls (PCBs)	10
1.2.	Basel Convention.....	11
1.3.	Stockholm Convention	11
1.3.1.	PCBs Elimination Network (PEN)	12
1.3.2.	Handling of PCBs Regulated in the Stockholm Convention	12
1.4.	Rotterdam Convention (PIC Convention)	13
1.5.	Barcelona Convention and its Protocols	13
2.	Data collection, Identification, Sampling and Monitoring.....	15
2.1.	Data collection and Inventory	15
2.2.	PCB Applications	17
2.2.	Periodic Examinations and Maintenance of PCB Containing Devices.....	18
2.2.1.	Sampling of Transformers, Capacitors and Construction Materials	19
2.2.2.	General Sampling Procedures.....	21
2.2.3.	Sampling of Transformers	21
2.2.4.	Sampling of Phased Out and Drained Transformers	24
2.2.5.	Sampling of Capacitors.....	25
2.2.6.	Sampling of Concrete and Brick Walls	27
2.2.7.	Sampling of Soil	30
2.3.	Screening Test Kits and Laboratory Analysis.....	30
2.3.1.	Analysis by Gas Chromatography (GC)	34
2.3.2.	Analysis Proceedings	35
2.4.	Database.....	36
2.5.	Labelling of Checked Equipment	37
2.6.	Site Monitoring.....	38
2.6.1.	Land Register of Areas and Storage Facilities with Possible PCB Contamination or contaminated equipment	39
2.6.2.	Risk Assessment	39
2.6.3.	Analysis	40
2.6.4.	Extent of Contamination.....	40
3.	PCB Management of Closed Applications	42
3.1.	PCB Management Plan.....	42
3.1.1.	Designation of a PCB Responsible	42
3.1.2.	Training and Instruction of Staff	42
3.1.3.	Inventory.....	42
3.1.4.	Database on Locations with PCB Equipment, Waste or Contamination	42
3.1.5.	Maintenance Plan.....	42
3.1.6.	PCB Spill Prevention, Control and Countermeasure Plan (SPCC Plan).....	43
3.1.7.	Disposal and Site Decontamination Plan.....	43
3.2.	Spill Prevention, Control and Countermeasure Plan (SPCC Plan)	43
3.2.1.	Prevention.....	43
3.2.2.	Spill Prevention Tools	43
3.2.3.	Countermeasure	45
3.3.	Priorities for Disposal and Site Decontamination.....	45
4.	Maintenance of Equipment Containing PCB.....	46
4.1.	Maintenance of In-Service PCB Equipment.....	46
4.2.	Best Working Practices.....	47
4.3.	Inspection of PCB Containing Transformers.....	49
4.3.1.	Visual Checks	49
4.3.2.	Leaks of Transformers	49
4.3.3.	Oil Level of Transformers	50
4.3.4.	Temperature Gauge	50
4.3.5.	Pressure-Vacuum Gauge	50
4.3.6.	Corrosion on Tank and Radiator Fins.....	50

4.3.7.	Performance Tests	50
4.4.	Evaluation of PCB Containing Capacitors	51
4.5.	Substitute Fluids	51
5.	Safety.....	53
5.1.	Safety and Personal Protective Equipment	53
5.2.	Protection of the Environment	56
6.	Emergency Actions and Clean Up.....	57
6.1.	Emergency Actions for Cold Incidents	57
6.2.	Emergency Actions for Hot Incidents.....	58
6.2.1.	Incident Caused by an Internal Failure	58
6.2.2.	Fires	60
6.3.	First Aid in Case of Contact with PCB	61
6.4.	Clean Up after Incidents	61
6.4.1.	Assessment of an Incident	61
6.4.2.	Decontamination Methods.....	62
6.4.3.	Protection of Workers and the Environment.....	63
6.4.4.	Disposal	63
6.5.	Check of Clean Up (Monitoring).....	63
6.5.1.	Tolerable Remaining Contamination after a Clean-up	63
7.	Phase Out.....	65
7.1.	Phase Out of Transformers	65
7.2.	Phase Out of Capacitors.....	66
7.2.1.	Preparation.....	66
7.2.2.	Dismantling	67
7.2.3.	Phase Out of Other Equipment	67
7.2.4.	Error! Bookmark not defined.	
8.	Packing.....	69
8.1.	Packing According to ADR	69
8.2.	Summary of Possible Containers for PCB Transports	70
8.2.1.	Labelling of the Packaging	75
8.2.2.	Labelling for Storage or Transport	75
8.3.	Handling of Packed Waste.....	77
9.	Temporary Storage.....	78
9.1.	Temporary Storage - On Site	78
9.2.	Central Storage Platform	79
9.3.	Authorization and Control	85
10.	Transport.....	86
10.1.	International Regulations for the Transport of Hazardous Goods	86
10.2.	ADR.....	86
10.2.1.	Obligations of Main Actors	86
10.2.2.	Documentation.....	87
10.3.	National Transports	88
10.4.	Transboundary Movement of Hazardous Waste.....	88
10.5.	Loading and Safety Check before Transport Takes Place	89
10.5.1.	Loading on a Truck for Local Transports	89
10.5.2.	Loading of Containers for International Transport	89
10.6.	Waste Transportation by Air.....	92
11.	Pre-treatment, Treatment and Disposal.....	93
11.1.	Technologies and Methods in General	93
12.	Annexes.....	97
12.1.	In-Depth Information on the Internet: Conventions and Guidance Documents	97

12.2.	Detection Kits and Other Instruments.....	99
12.3.	PCB Pre-Treatment Technologies (Extract only)	100
12.4.	PCB Non-Combustion Technologies.....	100
12.5.	PCB Combustion Technologies.....	104
12.6.	PCB Emerging Technologies.....	104
12.7.	PCB Treatment and PCB Disposal Companies	104
12.8.	Emergency Response Plan for Cold Incidents	105
12.9.	Emergency Response Plan for Hot Incidents.....	106
12.10.	Best Working Practices.....	107
12.11.	PCB Instructions for Workers.....	108
12.12.	First Aid in Case of Contact with PCBs	109
12.13.	Guidelines for the Inspection of Sites and the Sampling of Transformers and Capacitors (two persons)	109
12.14.	Draft Inventory Questionnaires	110
12.14.1.	Preliminary Inventory Form used in the Regional Pilot Project	113
12.15.	Example of a Possible Register	115
12.16.	PCB Equipment Monthly Maintenance Plan	116
12.17.	PCB Interim Storage Facility Monthly Inspection Report.....	117
12.18.	Transboundary Movement and Notification Documents for Hazardous Waste	118
12.19.	Dangerous Good Declaration and Container Packing Certificate.....	119
12.20.	Application Form for Membership in the PEN.....	120

Abbreviations and Definition of Terms

AC	Alternating Current
ADR	European agreement on the international road transport for hazardous goods
Askarel	Trade name of PCB cooling fluid (USA, Monsanto)
BAT	Best Available Technique
BC	Basel Convention on the trans-boundary movement of hazardous wastes and their disposal
BCD	<u>Base catalysed decomposition</u>
BEP	Best Environmental Practice
BRS	Basel, Rotterdam, Stockholm Convention (Secretariat)
CaO	Calcium oxide
Capacitor	Equipment or unit to supply lagging kilovars for power factor correction of an electric system; some capacitors were manufactured with PCB as cooling fluid
Capacitor Bank (General)	Practically there are three different ways of power factor (PF) correction: Capacitors for "individual" PF-correction; the capacitor is directly connected to the terminals of an equipment (motors, welding machine etc.) producing the "lagging kilovars"
Capacitor Bank (LV)	Capacitors for "group" PF- correction; the capacitor(s) is (are) connected to the LV-busbar of a transformer station, which feeds a number of consumers with individual motors, welding machines etc.
Capacitor Bank (MV)	Capacitors for "central" PF-correction; Large capacitor installation connected to the Middle- or High Voltage busbars of a substation where many individual electrical appliances (motors etc.) of various size operate at different times and periods.
CHD	<u>Catalytic hydrodechlorination</u>
Closed Systems	Capacitors and transformers, where the PCB itself is in completely closed containers; PCBs rarely emit from closed systems (in good condition)
Congener	Depending on the number and position of the chlorine atoms in the Biphenyl molecule, 209 isomers and homologue Chlorine Biphenyls are theoretically possible. A single compound from this group is called PCB congener.
Container 20'	Internationally used expression for Transport or Storage Containers with the Standard size of 2 x 2 x 6 meters (40' Container – 2 x 2 x 12 meters)
Container Box	There are various types of 20' and 40' Containers available, the most common is the Box Container with a front door, from an open top Container the roof can be removed for loading and off-loading activities (e.g. ideal for transformers)
Cooling Fluid	Dielectric fluid
COP	Conference of the Parties
DC	Direct Current
DDT	Dichlorodiphenyltrichloroethane
DE	Destruction efficiency
DRE	Destruction and removal efficiency
e.g.	Exempli gratia / for example
ESM	Environmentally Sound Management
ETI	Environmental Technology International Ltd. / Switzerland
EU	European Union
FAO	Food and Agriculture Organization of the United Nations

GC	Gas chromatography; Procedure for the determination of evaporating substances
GEF	The Global Environment Facility (GEF) is an international financial entity with 177 countries as members
GHS	Globally harmonized system of classification and labelling of chemicals
GPCR	<u>Gas-phase chemical reduction</u>
GTO	Gate turn-off thyristor
HV	High voltage
IATA DGR	IATA regulations on the transport of dangerous goods / transport by air
IBC	Intermediate Bulk Container
ID (number)	Identification (number)
IGBT	Insulated-gate bipolar transistor
IMDG	International maritime dangerous goods code / transport by sea
ISO	International Organization for Standardization
kV	Kilovolts
kVA	Kilovolt ampere
kVAR	Kilovolt ampere reactive
kW	Kilowatt
LBS	Land based sources and activities Protocol
LV	Low voltage (230/400 V)
MAP MEDPOL	Programme for the Assessment and Control of Marine Pollution in the Mediterranean
µg	Microgram
mg/kg	Milligram per kilogram
MS	Mass spectrometry
MV	Medium voltage (Normally in the range between 11 and 66kV)
MVA	Megavolt ampere
ng	Nanogram (1000 ng = 1 µg)
NGO	Non-governmental organization
Open Systems	Applications where PCB is consumed during its use or not disposed of properly after its use or after the use of the products that contain PCB; Open systems emit PCB directly in the environment (e.g. softeners in PVC, neoprene and other rubbers containing chloride)
PBB	Polybrominated Biphenyls
PCB	Polychlorinated Biphenyls
PCDD	Dibenzo-p-dioxins or dioxin; Highly toxic by-product of PCB
PCDF	Dibenzofurans or furan; Highly toxic by-product of PCB
PCT	Polychlorinated Triphenyls
PE	Polyethylene
PE-HD	High-density polyethylene
PE-LD	Low-density polyethylene
PEN	PCB Elimination Network of UNEP Chemicals
Persistent	Very slightly degradable in the environment

PIC	Prior Informed Consent
POP	Persistent Organic Pollutants
PPE	Personal Protective Equipment
ppb	Parts per billion
ppm	Parts per million (mg/kg)
Primary source	A product to which PCB was added voluntarily to influence the product's characteristics (e.g. cooling fluids for transformers like Sovol, Sovtol, Askarel, Pyralene, Clophen, etc.); Such products emit PCB continuously
RC	Rotterdam Convention on the Prior Informed Consent Procedure (PIC) for certain hazardous chemicals and pesticides in international trade
RID	Regulation for the international transport of hazardous goods / transport by rail
SAP-MED	Strategic Action Programme to address pollution from land-based activities in the Mediterranean Region
SBC	Secretariat of Basel Convention
SC	Stockholm Convention Persistent Organic Pollutants (POPs)
SCWO	<u>Supercritical water oxidation</u>
Secondary source	A product that originally was free of PCB, but later contaminated by PCB emitting from primary sources (e.g. by emission from primary sources or use of contaminated pumps, hoses, etc.) Such products also emit PCB
SNV	Swiss Association for Standardization
SPCC	Spill Prevention, Control and Countermeasure
TDI	Tolerable daily intake
TEQ	Toxic equivalency factor
Transformer	Equipment used to increase or reduce voltage; PCB containing transformers are usually installed in sites or buildings where electricity is distributed.
TTCB	Tri-tetrachlorobenzenes
UN-approved	Equipment that fulfils the specific United Nations testing procedures
UNDP	United Nations Development Programme
UNEP	United Nations Environment Programme
UNIDO	United Nations Industrial Development Organization
UNITAR	United Nations Institute for Training and Research
US EPA	United States Environmental Protection Agency
WHO	World Health Organisation

1. Introduction

1.1. Polychlorinated Biphenyls (PCBs)

Persistent Organic Pollutants (POPs) have been identified by the international community for immediate international action by means of the Stockholm Convention. The pesticide DDT, highly toxic Dioxins and Furans (unintentionally formed by-products as a result of incomplete combustion or chemical reactions) as well as PCBs count among the POPs.

PCBs have serious health and environmental effects, which can include carcinogenicity, reproductive impairment, immune system changes, and effects on wildlife causing a loss of biological diversity (Carpenter 2006, Hotchkiss et al. 2008, Wirgin et al. 2011). PCBs bioaccumulate in the fatty tissue of humans and other living organisms. The chemical is transported over long distances to regions where it has never been used or produced before. This process of evaporation, movement with the air streams, condensation and deposition on the ground is known as the “grasshopper effect”.

PCB production started in 1929. PCBs were manufactured by a number of companies in many industrialised countries, and maximum production was reached in the late 1960s. After 1983 production was stopped in most countries, except for some Eastern European countries and Russia, where manufacture ceased between 1987 and 1993.

PCBs were mostly used in closed applications for example as cooling and isolating agents in transformers and capacitors, in heat transfer systems and hydraulic systems, in particular in mining equipment. PCBs mixtures were, however, also widely used in open and partially open applications, for example in caulks/sealants, paints, anti-corrosion coatings, surface coatings, cables and cable sheaths, small capacitors, etc.

From the technical point of view, the characteristics of PCBs were quite advantageous, thus they found a wide range of applications as mentioned above.

The Stockholm Convention on Persistent Organic Pollutants (POPs) counts PCBs among the substances targeted for worldwide elimination. The existing PCBs and all equipment contaminated with PCBs have to be eliminated in an environmentally sound manner without producing hazards for humans or the environment by 2028. PCB treatment or disposal technology must comply with the highest safety and environmental standards and must be capable of reducing the PCB contamination level of those pieces of equipment suitable for re-classification below the legally permitted level of 50 ppm as well as assure that the PCB level remains below that limit.

Other global and regional conventions regulate the management of dangerous chemicals and hazardous wastes addressing PCB such as the Basel Convention, as well as the Rotterdam Convention . In addition the Barcelona Convention for the Protection of the Marine Environment and the Coastal Region of the Mediterranean and its related Protocols (Land-based Sources and Activities Protocol, and the Hazardous Waste Protocol) also addresses the PCB phase out and disposal.

1.2. Basel Convention

In 1989, the Basel Convention was adopted to improve monitoring of the transboundary movements of hazardous wastes.

The Basel Convention has the following key objectives:

- To reduce transboundary movements of hazardous wastes to a minimum consistent with their environmentally sound management
- To dispose of hazardous wastes as closely as possible to their source of generation
- To minimize the generation of hazardous wastes in terms of quantity and hazardousness
- Prohibition of an export of hazardous waste to developing countries that do not have suitable disposal technologies

The Basel Convention has set up a very strict operational control system based on the prior written notification procedure. The procedure for the notification of transboundary movements of hazardous wastes or other wastes can take place only upon prior written notification to the competent authorities of states of export, import and transit (if appropriate) and upon consent from these authorities permitting the transboundary movement of waste (see also chapter 10.4. and Annexes 12.18.).

Any transboundary movement of hazardous wastes or other wastes carried out in contravention of notification system is considered illegal traffic.

1.3. Stockholm Convention

This Convention regulates the prohibition of - so far - 23 toxic chemicals called the POPs (Persistent Organic Pollutants).

The text of the Stockholm Convention on Persistent Organic Pollutants was adopted on 22 May 2001 and entered into force on 17 May 2004; 90 days after the 50th member country had ratified it.

The initial twelve POPs are Aldrin, Chlordane, DDT, Dieldrin, Endrin, Heptachlor, Hexachlorobenzene, Mirex, Toxaphene, Polychlorinated Biphenyls (PCBs) as well as Dioxins and Furans (unintentionally formed by-products as a result of incomplete combustion or chemical reactions).

At its fourth meeting held from 4 to 8 May 2009, the Conference of the Parties (COP) adopted amendments to Annexes A (elimination), B (restriction) and C (unintentional production) of the Stockholm Convention to list nine additional chemicals as persistent organic pollutants: Chlordecone, Hexabromobiphenyl, Lindane, Alpha Hexachlorocyclohexane and Beta Hexachlorocyclohexane, Tetrabromodiphenyl ether and Pentabromodiphenyl ether, Hexabromodiphenyl ether and Heptabromodiphenyl ether, Perfluorooctane Sulfonic Acid, its salts and Perfluorooctane Sulfonyl Fluoride, Pentachlorobenzene. These amendments entered into force on 26 August 2010.

During the fifth meeting of the Conference of the Parties in April 2011, the Parties agreed to list Endosulfan in Annex A to the Convention, with specific exemptions. One year later, Endosulfan became the 22nd POP.

Finally, at its sixth meeting held from 28 April to 10 May 2013, the Conference of the Parties adopted an amendment to Annex A to list Hexabromocyclododecane with specific exemptions (decision SC-6/13). On 26 November 2014, one year after notification, the amendment listing HBCD in Annex A to the Stockholm Convention entered into force for most parties.

The contracted parties to the Stockholm Convention must take the following measures:

- Production, use, import, and export of the 23 most dangerous POPs shall be eliminated or restricted. For DDT a special regulation has been stipulated, as this product is used in developing countries to fight malaria
- When constructing new plants/installations measures shall be taken to minimize a possible production of POPs
- Stockpiles and wastes that are contaminated with POPs shall be recorded in an inventory and disposed of in an environmentally sound manner
- The use of devices containing PCB is still permitted until 2025, under the condition that certain safety precautions and conditions are fulfilled
- By the year 2028, however, all PCB equipment shall be disposed of in an environmentally sound manner

1.3.1. PCBs Elimination Network (PEN)

The PCBs Elimination Network (PEN) was launched at the simultaneous extraordinary meetings of the Conferences of the Parties to the Basel, Rotterdam and Stockholm Conventions in Bali on 22 February 2010. The PEN has been established as an arrangement for information exchange on the promotion of the cost-effective completion of the environmentally sound management (ESM) of liquids and equipment containing or contaminated with PCBs. The PEN is designed as an equal partnership for stakeholders from different sectors with an interest in the ESM of PCBs to interact within a voluntary framework to undertake the following:

- Promote ESM of PCBs and its equipment
- Foster cooperation
- Promote technical assistance and technology-transfer
- Provide and facilitate information exchange
- Raise awareness
- Encourage development and adoption of environmentally sound techniques and practices to eliminate PCBs
- Establish linkages between stakeholders

The PEN is an arrangement built on the platform of the clearinghouse mechanism, providing support to developing country Parties and Parties with economies in transition to reach the goals of the Stockholm Convention in relation to PCBs. The PEN shall implement its work on information exchange being mindful of the obligations of the Basel Convention on the transboundary movement of hazardous waste and its disposal and of the Rotterdam Convention on the prior informed consent procedure for certain hazardous chemicals and pesticides in international trade.

The application form for becoming a member of the PCBs Elimination Network (PEN) is attached in Annex 0.

1.3.2. Handling of PCBs Regulated in the Stockholm Convention

It is forbidden:

- To produce, import and trade PCBs
- To re-use and process PCB waste
- To re-fill PCB equipment

Legal and physical entities that possess PCBs, used PCBs and PCB equipment are obliged to report the quantity, origin, nature and content of PCBs, used PCBs and PCB containing/contaminated equipment to the responsible government agency/body for the professional activities in the field of environment not later than one year after the Convention enters into force. Entities are obliged to properly label the equipment. Legal and physical entities handling PCBs, used PCBs and PCB equipment are obliged to keep records in accordance with the convention.

1.4. Rotterdam Convention (PIC Convention)

Toxic pesticides and other hazardous chemicals kill or seriously sicken thousands of people every year. They also poison the natural environment and damage many wild animal species. Governments started to address this problem in the 1980s by establishing a voluntary Prior Informed Consent procedure. PIC required exporters trading in a list of hazardous substances to obtain the prior informed consent of importers before proceeding with the trade.

In 1998, governments decided to strengthen the procedure by adopting the Rotterdam Convention, which makes PIC legally binding. The Convention establishes a first line of defence by giving importing countries the tools and information they need to identify potential hazards and exclude chemicals they cannot manage safely. If a country agrees to import chemicals, the Convention promotes their safe use through labelling standards, technical assistance, and other forms of support. It also ensures that exporters comply with the requirements. The Rotterdam Convention entered into force on 24 February 2004. The contracting parties take measures to:

- Establish an official notification procedure i.e. to inform the importing country that an export of a chemical figuring on the PIC list will take place before the first shipment
- Inform the importing country that an export of a chemical that is banned or severely restricted for use within its territory will take place before the first shipment
- Inform other countries of each national ban or severe restriction of a chemical

1.5. Barcelona Convention and its Protocols

The UNEP/MAP-Barcelona Convention for the Protection of the Marine Environment and the Coastal Region of the Mediterranean was adopted in 1995 thus amending the Barcelona Convention on the protection of the Mediterranean sea against pollution adopted in 1976 by the Mediterranean coastal states and European Union. The Barcelona Convention operates in the framework of the Mediterranean Action Plan adopted and amended respectively in 1975 and 1995. The Secretariat is provided by UNEP through the UNEP/MAP Coordinating Unit located in Athens, Greece.

The Barcelona Convention is associated by seven important protocols out of which two address different aspects of POPs management namely the Land based sources and activities Protocol, 1996 (LBS Protocol) and the Protocol on the trans-boundary movement of hazardous waste in the Mediterranean, 1996.

The LBS Protocol through the Regional Plans adopted by COP in the framework of its Article 15 provide for the contracting parties to take legally binding measures to phase out POPs and their stocks including the PCB in synergy with the work and commitments taken under the Stockholm Convention.

UNEP/MAP- Barcelona Convention is supporting the Contracting Parties to implement the SAP-MED (Strategic Action Programme to address pollution from land-based activities in the

Mediterranean Region) and associated National Action Plans adopted in accordance with Land Based Sources and Activities Protocol of the Barcelona Convention which provide for a number of regional targets by 2025 related to hazardous waste and POPs ESM including phasing out and disposal.

The Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem (MedPartnership) is a collective effort of leading environmental institutions and organizations together with countries sharing the Mediterranean Sea to address the main environmental challenges that Mediterranean marine and coastal ecosystems face. The project is led by UNEP/MAP and is financially supported by the Global Environment Facility (GEF) and other donors, including the European Commission and all participating countries.

Within the framework of the project, UNEP/MAP, through its MEDPOL programme, aims to support countries in the implementation of the SAP-MED. The project is supporting the EMS disposal of up to 870 tons PCB as well as undertaking important capacity building activities in four Mediterranean countries, including the preparation of EMS Guidelines for PCB.

The proposed Guideon PCB ESM is prepared by UNEP/MAP MEDPOL Programme in the framework of the Medpartnership Project with the technical support of Urs K. Wagner (ETI Umwelttechnik AG, Chur/Switzerland).

The purpose of this Guide is to provide technical guidance on different aspects of PCB life cycle environmental sound management including inventory and monitoring until their final phasing out and disposal.

2. Data collection, Identification, Sampling and Monitoring

2.1. Data collection and Inventory

The inventory is the initial stage in the management of PCB contaminated equipment and it should be generated in the most ecological way. Implementing the following general activities will support a reliable PCB data collection:

- Assessment of the national PCB situation
- Legal assessment of national regulations
- Identification of possible stakeholders
- Awareness raising workshops for possible stakeholders, capacity building
- Preliminary inventory
- Public information
- Adaptation of national regulations
- Information of the identified stakeholders
- Detailed inventory (physical inspection, sampling, analysis, database)
- Infrastructure (handling, transport, interim storage, disposal)

The aim of the inventory is to identify, quantify and keep records of the equipment and the materials prone to containing or being contaminated with PCBs. These bits of information are indispensable when preparing a plan for PCB management, which should encompass the entire cycle of these products, as follows:

- Usage
- Management
- Storage
- Decontamination
- Elimination

Table 1: Potential holders of PCB

Electric Utilities	Maintenance Companies
Industrial Facilities	Hospitals
Railroad Systems	Research Laboratories
Mining Industry	Manufacturing Plants
Army Installations	Waste Water Discharge Facilities
Residential or Commercial Buildings	Car Service Stations
Holiday Resorts / Hotels	Small/Medium sized Co.
School Buildings	Airports
Cold Storage Depots	Wood Processing Co.
Suppliers	Disposal & Recycling Companies

The sites with possibly PCB containing equipment shall be inspected by field teams or engineers of the authorised body in the field of environmental protection. During the inspection the particulars given in the questionnaires shall be checked and further data regarding the particular type of PCB equipment or PCB waste collected and recorded, for example *kVA rating, brand name, fluid quantity, type of fluid, location of the device, serial number, PCB concentration, year of manufacture, and weight*. During the visit, the site shall also be checked for visual contamination. An inventory is always a chance for preventive maintenance.

The following data need to be collected and recorded when compiling the PCB inventory:

In-service transformers

- kVA rating
- Brand name
- Fluid quantity
- Type of fluid (brand of the fluid)
- Location of transformer producer
- Number
- PCB concentration (not for refilled transformers)
- Year of manufacture
- Weight of the transformer
- Status/owner

Out of service transformer

- kVA rating (transformer capacity)
- Brand name
- Fluid quantity
- Location of the transformer producer
- Number
- PCB concentration (not for refilled transformers)
- Year of manufacture
- Weight of the transformer
- Status/owner

In-service capacitors

- kVAR rating
- Brand name
- Location of the capacitor producer
- Number
- Year of manufacture
- Weight of the capacitor
- Status/owner

Out of service capacitors

- kVAR rating
- Brand name
- Location of the capacitor producer
- Status/owner
- Number
- Year of manufacture
- Weight of the capacitor

Bulk storage tanks, drums and containers

- Type
- Location
- Weight
- Fluid quantity
- PCB concentration
- Status/owner

In order to facilitate the inspection, country-tailored inventory forms shall be developed which include all data necessary for the determination of the parameters needed for the evaluation of the risk associated with the PCB equipment and waste.

Also, ID numbers shall be determined for each piece of potentially contaminated equipment and waste. Each owner of potentially PCB contained equipment should affix the ID number to it and fill in the inventory form. If conclusion about PCB presence cannot be made based on the available data, then equipment has to be sampled. The data entry for status can include codes for leaking, stable, packed etc., which can be found at the transformer nameplate.

Not only the PCB content of transformers in use has to be checked, but also the contamination of devices out of use or in reserve. Rigorous examinations must include spare oils and other equipment that could contain PCBs (capacitors, voltage regulators¹, circuit breakers, heat exchangers, oil cisterns, pipe systems, etc.). Only equipment exceeding the capacity of 1 litre must be declared. All transformers have to be sampled even if they are of recent date of manufacture because a later unintended contamination of the transformer could have occurred (see also chapter 2.3.). If a device cannot be sampled for technical reasons (e.g. capacitor), it has to be regarded as containing PCB until the sampling performed at the time of the phase out proves the opposite.

¹ Voltage regulators are devices similar to transformers and have an iron core and windings used to boost up the voltage in long overhead power lines (the American – English name for a voltage regulator is booster). A rectifier is a device to change Alternating Current (AC) to Direct Current (DC). In use are semiconductors as Thyristors, GTO's IGBT's to "rectify" the AC. These electronic devices do not contain PCB.

2.2 PCB Applications

Closed, partially open and open applications of PCBs are presented in the tables below.

Table 2: Closed Applications of PCBs

Insulation and/or cooling fluid in transformers
Dielectric fluid in capacitors
Hydraulic fluid in lifting equipment, trucks and high pressure pumps (mining industry especially)

Table 3: Partially Open Applications of PCBs


Vacuum pumps
Switches
Voltage regulators
Liquid filled electrical cables
Liquid filled circuit breakers
Heat transfer fluids
Hydraulic fluids

Table 4: Open Applications of PCBs

Caulks/sealants (buildings)
Paints and plaster
Anti-corrosion coatings (indoors and outdoors)
Surface coatings (e.g. floors)
Cables and cable sheaths
Sealed double glazing windows
Lubricating fluid in oils and grease; cutting oils
PCBs as flame retardant and impregnating agent (e.g. indoor wood sealing for panels and floor finishers)
Adhesives
Carbonless copy paper
Inks
etc.

The Chemical lifecycle of POPs and specifically PCB shall always be considered.

Chart 1: Chemical lifecycle of PCBs



2.2. Periodic Examinations and Maintenance of PCB Containing Devices

Devices containing PCB are subject to regular periodic checks. These examinations mainly consist of checking the parameters from a technological and production aspect (e.g. technical characteristics, electric permeability of insulating materials, losses).

Due to possibility of contamination of the environment, additional inspections are needed with devices identified as PCB-containing. These inspections are mainly from the aspect of leakage of contaminating insulating oils. Thus, the following inspections should be added to the warrant for regular inspections (if not already envisaged from another aspect):

- Inspection of all sealing elements of the device
(the check consists of a visual inspection if some element leaks)
- Inspection whether any of the elements containing insulating oil is oxidized (corroded)
(this check is performed visually, because devices containing insulating oil are painted regularly due to easier dissipation of heat)
- Inspection for deformations of the housing of the device (hermetically sealed capacitors often “puffed up”)

If any of the above damages are confirmed, then a proposed intervention procedure follows:

- The bolts are re-tightened. If this does not stop the leakage, then a part of the insulating oil is drained “under the level of the edger” and the sealer is switched.
- The oxidized surface is cleaned from the oxide with a steel brush and sanding paper to reach metal shine. Afterwards, the spot is degreased with solvents, and the metal is checked for punctures and leakage with absorbing paper (filter paper or common paper handkerchief will also do the job). Even if there is no leakage, the spot is impregnated with means for neutralizing the iron oxide (“Antirost” or similar) and at the end are painted with basic and covering paint as the other part of the transformer. If even smallest leakage is noticed, the element (i.e. the radiator) must be demounted and welded, replaced if possible or the transformer should be taken to an industrial reparation. If the element is a condenser, it is discarded and replaced with a new one.
- The capacitor is discarded and replaced with a new one.

ADVICE: ALL THESE INTERVENTIONS ARE TO BE PERFORMED BY SKILLED AND AUTHORISED SERVICE ONLY.


2.2.1. Sampling of Transformers, Capacitors and Construction Materials

It is advisable to prepare a sampling box that contains basic equipment for sampling activities. This ensures access to essential equipment immediately when required.

Picture 1: Inside view with possible equipment I



Picture 2: Consider also electric safety precautions



Normally glass bottles are used for liquid samples and glass or plastic containers for solids. However if a high PCB content is expected (e.g. in case of pure PCB) glass bottles must always be chosen, because PCB can diffuse through plastic containers.

Sampling containers must be absolutely clean. Whenever sampling containers are transported over long distances, demands on the glass quality (unbreakable) obviously increase.

When preparing the sampling box, the intended minimum number of samples has to be considered. This depends on the kind of PCB analysis and possible further analyses (e.g. oil quality in case of negative PCB result).

Table 5: Minimum sample quantities and sampling containers

Method	Matrix	Quantity	Container
Clor-N-Oil	Oil	10 ml	➤ 20 ml glass vial (white lid)
Clor-N-Soil	Solids (e.g. soil, concrete dust, etc.)	10 g	➤ 60 ml glass vial (white lid) ➤ 250 ml PE-HD container (plastic, white with blue lid)
L 2000 DX	Oil	10 ml	➤ 20 ml glass vial (white lid) ➤ 30 ml glass bottle Hexavis (brown with black lid)
L 2000 DX	Solids (e.g. soil, concrete dust, etc.)	Minimum 10 g, if possible more	➤ 60 ml glass vial (white lid) ➤ 250 ml PE-HD container (plastic, white with blue lid)
GC (lab)	Oil	20 ml	➤ 20 ml to ½ litre bottles
GC (lab)	Solids (e.g. soil, concrete dust, etc.)	10 g	➤ 60 ml glass vial (white lid) ➤ 250 ml PE-HD container (plastic, white with blue lid)

Please consider that the above-mentioned quantities are minimum figures. It is advisable to always take more sampling material e.g. to fill a 250 ml PE-HD container with soil. For drill samples minimum quantities are acceptable because of the often difficult sampling procedures.

To determine the quality of a transformer's cooling fluid at the same time, sample at least 500 ml of the oil. It should be filled in a 500 ml glass bottle (with blue lid). There are various manufacturers of quality glass bottles as e.g. Schott, Duran or Simax.

Picture 3: Glass vial



Picture 4: 30 ml Glass bottle Hexavis



Picture 5: 500ml Glass bottle Duran



Picture 6: 60 ml Glass Vial



Picture 7: 250 ml PE-HD Cont.



Picture 8: 750 ml PE-HD Cont.



2.2.2. General Sampling Procedures

The main source of error is the sampling process itself. Therefore the following points must be particularly considered:

Risk of Cross Contamination

Contamination is easily spread from one sample to another. When using one-way material (e.g. Kleenex, pipettes, metal scoops, etc.) it must be ensured that a new product is used for every new sample. If this is not possible, the used equipment must always be cleaned before another sample is taken. If possible, solvents (e.g. technical acetone) should be used for cleaning purposes.

Confusion of Samples

In order to prevent a confusion of samples, it is crucial to clearly mark the sample containers immediately after the sample has been taken. The identical data must also be recorded in a sampling report. A label must be affixed to the sampling containers.

Picture 9: Taking all records of sampled electr. devices



Picture 10: Labelling BEFORE Sampling



Sampling Reports:

The sampling report must be filled in immediately. If it is completed at a later stage, important information could be lost or forgotten.

Sampling forms must be used to record the data required for evaluation and interpretation, for quality assurance and to ensure comparability with other assessment observation.

As opposed to laboratory procedures, no standard procedure for the performance of sampling can be given, since both the circumstances and the potential problems encountered are manifold. The ISO (ISO 2002c) recommends that quality assurance be performed according to the principles of the ISO 9000 standard (SNV 1999). An adequate standard of quality demands the application of quality assurance methods. Quality assurance involves strategies for the reduction of errors in sampling and sample treatment from the planning to the operational stage, by making the procedural steps readily comprehensible and retraceable (ISO 9000). Quality assurance also obliges those performing the sampling activities to uphold the necessary standards during their task and on all sites.

2.2.3. Sampling of Transformers

In order to prevent skin from getting into contact with PCBs, one-way protective gloves must be worn. Eyes must be protected against possible oil splashes by wearing goggles.

The sample can be taken by using the drain tap, which usually is at the bottom of the transformer. If a transformer has been disconnected from power for over 72 hours the sample

should generally be taken from the bottom, as PCB sinks to the lower level because of its higher density. Sometimes the gasket gets damaged when the drain tap is opened. It is therefore advisable to always have a spare gasket ready.

Alternatively, transformers can be sampled via the oil filling cap by using a hand pump (consider: a new hand pump must be used for each transformer). Oil samples from the expansion receptacle cannot always be regarded as representative, because the oil does not circulate and thus it is not really mixed.

Often, transformers are sampled when they are in use. Appropriate protective measures and safety regulations by responsible Electricians must be known and considered at any time!

If only the PCB content of the oil is analysed, 20 ml glass vials can be used provided analysis is performed on site. If the analysis is performed elsewhere and the samples have to be transported over long distances, 30 ml glass bottles should be used as sample containers because they are more robust. If a holder of a transformer also wants to have the quality of the oil tested, a 500 ml glass bottle should be used.

If a PCB inventory demands an analysis of the cooling fluid, the owner has the possibility to test the oil quality at the same time. This is dependent on the age and condition of the equipment. Such a preventive maintenance allows an assessment of the technical condition of the transformer and thus helps prevent possible damages/failures resulting from e.g. acidity or increased dampness.

Oil quality analyses must only be run after negative PCB result; otherwise the laboratory equipment will be contaminated with PCB.


The following steps must be followed when sampling a transformer:

- Place a drip tray under the drain tap,
- Label the sample bottle with the same serial number as on the inventory form,
- Drain off the required oil into the glass vial - quantity depending on screening/analysis
- Carefully retighten the seal.
- Then affix a label on the transformer with the same serial number as on the inventory form and the glass vial. The label usually contains the Identification number and Date of sampling

Step-by-step Sampling of a Transformer



Place drip tray under drain tap, wearing gloves and goggles



Sample the oil (30-50ml for PCB screening, 1l if also oil quality is tested)



Affix sampling label on transformer (after cleaning the surface)



Record sample in sampling report, affix sampling label to report



Screen the oil sample by Clor-N-Oil or L2000 DX



If the **oil quality** shall also be tested, the following steps have to be considered:

- Sampling via drain tap: Drain off 1 to 2 litres of oil first in order to clean the drain from particles which might have accumulated in that area,
- Amount of oil required: 0.5 to 1 litres,
- Leave the oil for 24 hours, in order to allow particles and water to settle,
- Take sample from the upper third of the oil for the analysis using a pipette, and
- Return the drained 1 to 2 litres of oil back into the transformer (only if the oil filling cap is out of reach of the high voltage, otherwise shut off the transformer before refilling the drained oil)

All wastes must be disposed of in an environmentally sound manner – the disposal method always depends on the analysis result.

Remark: Sampling is also an opportunity to collect useful information for the database.

2.2.4. Sampling of Phased Out and Drained Transformers

Often transformers have already been phased out, temporarily stored and drained at the time a PCB inventory is compiled. In such cases, it needs to be decided on site, how the sampling shall be performed.

Even if a device has been drained, there should still be some oil present in the passive part of the transformer due to the leaching in the days and weeks after the draining. Depending on the size of the transformer, the leaching from the solid parts of the device (wood, insulation paper, etc.) can leave a few litres of oil at the bottom of the transformer. However, usually there is not enough oil to sample it via the drain tap, as the oil layer is deeper than the valve.

In such cases, the device needs to be sampled through an opening in the top. Stiff tubes (e.g. glass or PE) can be used to take a sample of the oil at the bottom of the transformer.

The PCB results obtained from drained transformers could be higher than the original contamination in the transformer. This is due to the leaching effect from the core and windings into only a limited volume of oil.

If there is no oil at all left in the device, solid materials from the active part of the transformer could be sampled and analysed (wood or insulation paper). However, such analysis can only be performed in a laboratory by gas chromatography.

Due to practical reasons it might be advisable to label such drained transformers as PCB-contaminated and note it accordingly in the physical site inspection report (respectively inventory form) and leave it for future investigations.

Picture 11: Sampling of oil drums



Picture 12: Affix labels while sampling and later final one



Sampling of Capacitors

Power capacitors are built into hermetically closed containers and there is no direct access to the cooling liquid.

In many cases, the manufacturer provided information about the type of dielectric liquid, either with identification on the nameplate or with a separate tag confirming that the contents are harmful for the environment. Such capacitors do not need further investigation. They definitely contain PCBs and must be treated accordingly.

Picture 13: Identification of Capacitor Fluid



Picture 14: Tag Information on Capacitor



If a designation is missing and relevant information from the manufacturer is not available, the only way to test the dielectric liquid is to drill a hole in the casing on the top or cut the isolator and retrieve an oil sample. This can be done by (e.g.) using a pipette (using only once).

After having opened the capacitor, it is damaged and unusable and thus must be stored in appropriate containers (e.g. in an UN-approved steel drum).

Thus only phased out capacitors can undergo this procedure. Capacitors still in service and manufactured before 1993, with missing information about the dielectric liquid have to be labelled as PCB suspected equipment (see chapter 2.5.).

If there is a series of the same capacitors, it is usually sufficient to sample only two devices out of the series. Preferably a mixed sample originating from the two capacitors with the lowest serial numbers should be analysed. Caution should be taken if the analysis reveals PCB, even if it is only a slight contamination. Such contamination could have been caused during the production e.g. when using the same pumps for mineral oil and PCB oil. In such cases, all capacitors of one series must be analytically tested.

Personal Protective Equipment (PPE)

The PPE for these activities consist of protective gloves and goggles. Respiratory protection is not necessary when taking single samples. If several samplings are taken within short intervals light respiratory protection is recommended.

Sampling of Small Sized Capacitors

Usually capacitors of a smaller size do not contain PCB as a floating liquid in the casing, but rather as an impregnating agent of the insulation layers in the capacitor. It is therefore not possible to drill a hole in the casing and take an oil sample with a pipette.

Prepare the working place with an oil carpet and a tray (metal if available). The personal protective equipment comprises gloves, safety goggles and in case of poor ventilation a respiratory mask. Firstly, a circle has to be cut around the top end of the capacitor casing near the contacts using a small iron saw. Once the top has been lifted, it is usually possible to pull out the

active part (caps don't have windings as such). With a tool remove about 1 cm³ of the insulation and conductor layers and place them in a 60 ml glass vial. The samples can then be prepared in the laboratory and analysed by gas chromatography.

All tools and materials that came in contact with the capacitors have to be cleaned e.g. with acetone, or be disposed of as hazardous waste.





Picture 15: Small sized capacitors



Picture 16: Sampling of small sized capacitors



Step-by-step identification of PCB Capacitors

<p>Step 1 – Year of Manufacture:</p>	<p>Check nameplate for year of manufacture. If the capacitor was manufactured in or after 19**² → “PCB free”</p> <p>There is no SC or global regulatory policy on a deadline. The decision is based from where electrical devices were imported and experience data. Therefore it may vary from country to country, in many Countries the deadline is set on 1993</p> <p><i>** Final Year and/or additional text to be provided by the countries.</i></p>	
<p>Step 2 – Declaration:</p>	<p>Check nameplate for declaration “PCB” or “PCB trade name”, e.g. <i>Aroclor, Askarel, Clophen, Delor, Elaol, Fenclor, No Flamol, Phenoclor, Pyralene, Pyranol, Sovol, etc.</i> → “PCB containing”</p>	
<p>Step 3 – Capacitor Lists:</p>	<p>Compare nameplate/serial number with capacitor lists. Many devices can be identified or categorised according to information in capacitor lists. → “PCB free or PCB suspect”</p>	
<p>Step 4 – Sampling/Analysis:</p>	<p>If capacitor cannot be identified according to Steps 1-3 above, it must be sampled and analysed according to the procedure with transformers. Alternatively, the capacitor can be regarded as PCB containing. Please see the appropriate Factsheets.</p>	

2.2.5. Sampling of Concrete and Brick Walls

A cordless drill can be used for taking samples. Drills (bits) with a diameter of 20 mm to 22 mm should be used to drill holes in the PCB suspected areas. The collected concrete dust from the drilling activity forms the sample for the analysis.

Safety Precautions

The drilling procedure produces dust that must be regarded as contaminated. Consequently the safety precautions during the sampling must be followed strictly and it is essential to wear:

- Leather and/or Nitrile gloves,
- Safety goggles,

² It is recommended to choose the year of manufacturing of the capacitors in line with national legislation. In case a reference year is missing in national legislation, it is recommended to use 1993 as reference year.

- Respiratory mask with a filter for organic vapours and dusts,
- Ear protection while drilling.

If samples are taken from a brick wall, cross contamination must be avoided by taking steps such as covering the floor with plastic liner or industrial carpet. These materials have also to be disposed of as hazardous waste.


Defining the Extent of the Contaminated Area

When confronted with a spill the first step is a visual inspection of the site. In most cases, the oily parts can be distinguished visually. The extent of the contamination should be investigated and the source of spill traced.


These first impressions must be verified by a few well-chosen samples. The first sample will be taken from the estimated centre, to determine whether the spill contains PCB. If the first sample indicates that PCB is present, the next samples will be taken in order to delineate the contaminated area. Not only is the size of the contamination on the surface important, but also it is essential to know the depth of penetration into the material. The limit for a sample to be considered as contaminated is 50 mg/kg (ppm), thus all samples below 50 mg/kg (ppm) can be regarded as PCB free.

In order to save costs, a strategy should be prepared to delineate the contaminated area with a small number of samples. This can be done in many ways. The appropriate strategy will be determined by the specific situation. A chosen strategy can be adapted or optimized by considering the results of an on-site analysis of the samples. An example of a visible contamination is shown in Picture 17 and Picture 18. If a rather large area can be assumed as being PCB-free, there is a way to reduce the expenditures for sampling by collecting mixed samples to verify this. Instead of taking a number of «single» samples and analysing them separately, one sample with an equal mixture from several sampling spots can be analysed in one go. If the result turns out to be well below the limit of 50 mg/kg, it can be assumed that all spots are PCB free. If the result shows a contamination around 50 mg/kg or more, the source of the contamination has to be located by further single samples.

Picture 17: Proposal strategy - horizontally



Picture 18: Proposal strategy - vertically



If the extent of the contamination is not visible a site specific strategy for the problem has to be applied. The area, where a contamination cannot be excluded, could be subdivided into a grid with equal parts with collection of a (mixed) sample in each field.

Sampling

After preparing a sampling strategy and considering the safety precautions mentioned above, the drilling can be executed. The sampling report must be filled in correctly and the sample containers marked accordingly.

Before drilling, the auger has to be cleaned e.g. with acetone, in order to prevent any contamination from former drillings.

For field analysis purposes, 10 grams of concrete or brick dust are needed, though it is advisable to take more so that the results can be double checked or verified by gas chromatography. Consider that it has to be assumed that the contamination varies with the depth of the drilled hole.

Therefore it is advisable to drill no deeper than 1.5 cm within one sample. If the necessary amount of dust cannot be obtained from this hole it is recommended to drill another one right next to it, instead of drilling deeper.

The drill dust can be collected by using a poly spoon (Picture 19) and put into the sample container. After the sampling any remaining dust has to be collected with a brush and a weighing dish and disposed of as hazardous waste. Materials that came in contact with the soil/dust have to be cleaned with acetone or disposed of as hazardous waste.

Picture 19: Sampling of concrete



Picture 20: Cleaning of leftover dust



Sampling a brick wall requires the assistance of another person who collects the drilling dust with an appropriate dish.

Sampling in Depths

Depending on the chosen strategy to define the extent of the contamination, the limits of the contamination in depth have to be verified by taking samples.

Below an explanation of the proceedings for a sampling in depths is given for an assumed depth of contaminant penetration of 10 cm:

Firstly: the area is covered with an oil pad (approx. 30 x 30 cm, with a hole in the middle of around the size of the drill bit). Secondly: a hole with a depth of 10 cm is drilled, the dust collected and the hole cleaned. Then the oil pad is removed and disposed of as hazardous waste including the dust. The spot is then covered with a new oil pad as previously described and sticky tape is placed over the hole to facilitate the dust collecting. The drilling is continued to the required depth for the sample. The collected dust should not get in contact with the contaminated surface, otherwise or the sample will be a mixture and indicate wrong results. Finally the oil pad is removed and disposed of as hazardous waste.

2.2.6. Sampling of Soil

During the sampling it is recommended to wear:

- Disposable gloves (Nitrile or Vinyl).

If a site is heavily contaminated, the wearing of the following is recommended:

- Respiratory mask with a filter for organic vapours and dusts,
- Tyvek overall and boots.

The defining of the extent of the contaminated area works along the same principles as with the sampling of concrete and brick walls (see previous chapter). With regard to soil samples, the choice of where to take the sample has an influence on the results obtained.

Suspected contaminated areas are sites where either transformers containing PCB, contaminated transformers and/or capacitors containing PCB are or were installed or stored. In some cases oil-stains resulting from leakage or improper storage are even visible. The soil or gravel in such areas needs special attention.

If there are no visible stains in the mentioned areas, mixed samples must be taken directly from the surface. A strategy to delineate the contaminated area should be prepared (see also sampling of concrete or walls). The samples from the surface are taken with a clean poly spoon. After the exercise the spoon must be cleaned with solvents (acetone) to prevent any possible cross contamination.

Picture 21: Sampling on surface



Picture 22: Sampling in depth (Excavation slot)



The sampling report³ has to be filled in correctly and the sample container has to be marked accordingly. Glass vials or PE-HD plastic containers should be used.

Big stones are not appropriate for an analysis as the extraction solution to extract the PCBs for the analysis does not deeply penetrate stone. Material with small sized gravel or sand should be preferred.

Cross contamination must be avoided in any case. After use the scoop and all other items, which were in direct contact with the soil, have to be cleaned with acetone or disposed of as hazardous waste.

Sampling of soil and groundwater is to be carried out according to protocols, whose detailed description is beyond the scope of this guide.

2.3. Screening Test Kits and Laboratory Analysis

³ The sampling report format could be used on the base of the PCB Inventory Form according to the “Regulation on criteria and conditions for handling, storage and disposal of PCBs”

PCB analysis can be divided into two categories: *Specific and non-specific methods*.

Specific methods include gas chromatography (GC) and mass spectrometry (MS) which analyse for particular PCB molecules.

Non-specific methods identify classes of compounds such as chlorinated hydrocarbons, to which PCBs belong. These non-specific methods include PCB field screening tests like CLOR-N-OIL and CLOR-N-SOIL test kits as well as the L2000 DX field Analyzer.

In general, PCB specific methods are more accurate than non-specific methods but they are more expensive, take longer to run, qualified staff is needed, and they cannot be used on site.

Two non-specific tests are below described that are however **ABSOLUTELY NOT** recommended to be used due to uncertainties in results and high potential of polluting water and air!

Density Tests

The easiest way to verify whether or not oil contains heavy concentrations of PCBs is a simple density test: → Use a 10 ml glass vial → pour some water into the vial → add some dielectric liquid. If the oil layer is at the bottom of the vial the density of the oil is > 1 . In such a case there is no doubt that the PCB concentration is rather high. If the oil layer remains on top of the water layer; it can be assumed that it is a mineral oil with a density of < 1 .

Picture 23: Density Test with oil in water on a scrap yard



Picture 24: The same method in an oil laboratory



However, a density test only remains an emergency method in order to identify a pure PCB source. It cannot be recommended as a reliable tool for inventory purposes, as contaminated oil cannot be detected. Furthermore, there is a high risk of water/sewage contamination by hydrocarbons due to non-environmental conform disposal.

Beilstein Method

A piece of copper oxide fastened to a platinum wire is moistened with the oil to be tested and held in the outer zone of a Bunsen flame. As soon as the carbon has burned away, the presence of chlorine is indicated by the greenish or greenish-blue colour of the flame. This colour is produced by volatilizing copper chloride and its intensity and duration depends on the amount of chlorine present.

This test may only be performed in a laboratory by chemists in appropriate lab-chapels and/or ventilated rooms. There is a risk that highly toxic dioxins are unintentionally formed and released.



Generally, both the Density test and the Beilstein method may only be used as an emergency method, or in case of severe lack of resources and under certain circumstances.

Chlorine Detection Test Kits


There are a variety of different brands of chlorine detection test kits available:

- Immunoassay technology ENVIROGARD by Millipore;
- CLOR-N-OIL and CLOR-N-SOIL by Dexsil. The Dexsil test generally distinguishes between the PCB test kits for oil (e.g. CLOR-N-OIL) and for soils (e.g. CLOR-N-SOIL).

Picture 25: CLOR-N-OIL



Picture 26: CLOR-N-OIL 50 ppm



Both Dexsil tests rely on the same principle: The chlorine atoms are chemically stripped away from the PCBs, the total chlorine concentration is determined and indicated by a colorimetric reaction. Three different test levels are available: **20 ppm, 50 ppm and 500 ppm**. Each kit is used in the same way. The end point for each has been adjusted so that it changes color at the required level. The kit is a «GO / NO GO» type of test where the result is either positive or negative.

More information and links regarding test kits and their applications can be found in Annex 12.1.

Instrumental Detection of the Chlorine Concentration

Instrumental detections of the chlorine concentration are methods that use instruments or analyzers to determine the chlorine concentration in the samples.

The L2000DX relies on the same basic chemistry as the CLOR-N-OIL test kits, however instead of a colorimetric reaction; the L2000DX uses an ion specific electrode to quantify the contamination in the sample. Sample analysis is available for transformer oils, soils, water and surface wipes. The usable measurement range for oils and soils is 2 to 2'000 ppm, 20 ppb to 2'000 ppm for water and 2 to 2'000 ug/100 cm² for wipe samples.

The L2000DX Analyzer is pre-programmed with conversion factors for all major Aroclors and most chlorinated pesticides and solvents. The built-in methods include corrections for extraction efficiencies, dilution factors and blank contributions.

Picture 27: L2000 PCB / Chloride Analyzer

Picture 28: L2000 in use



The L2000DX can be used in the field or laboratory by non-technical personnel. An oil sample requires about five minutes to run while water, soil and surface tests take about ten minutes each. This eliminates the need to wait days or even weeks for laboratory results. Crews working at a site can take immediate action to secure equipment, isolate a site, or remove contaminated soil.

Instrument calibration is required at the beginning of each day (takes about 2 minutes). After calibrating, a reagent blank is tested to ensure the analysis is being run properly and to provide a baseline for accurate low-level results.

Blank subtraction can be incorporated into the method and is automatically updated upon calibration. The preparation steps involve extracting the chlorinated organics from the soil, water or wipe material, (not required for PCB in transformer oil), and reacting the sample with a sodium reagent to transform the chlorinated organics into chloride. The resulting chloride is quantified by the L2000DX Analyzer. Several samples can be prepared concurrently, than analyzed in less than a minute per sample. One operator can complete about 65 oil tests, or 45 soil or surface wipe tests in an eight hour day.

Table 6: Advantages and disadvantages of field screening tests


Field Screening Tests	
Advantages	Disadvantages
<p>Time: Within minutes one has proof whether the sample contains > or < than 20/50/100 ppm PCB.</p> <p style="text-align: right;">→</p>	<p>Can provide false-positive results (but never false-negative)</p> <p style="text-align: left;">←</p>
<p>Easy to use: The tests follow a simple procedure anyone can perform in the field or lab.</p> <p style="text-align: right;">→</p>	
<p>Inexpensive: A PCB determination by test kits is less expensive than analysis in the laboratory.</p> <p style="text-align: right;">→</p>	
<p>Economical: Many samples need not to be analyzed by GC at all.</p> <p style="text-align: right;">→</p>	

Regarding waste generated during the sampling and screening activities it is generally advised to consider all waste as PCB contaminated. Therefore, UN-approved packaging (Steel- or PE drums, Big Bags, Containers etc.) for both, liquid and solid waste must be available. Also all used reagents, test kits etc. shall be collected and disposed of as industrial waste.

Picture 29: L2000 use Practicing



Picture 30: Use of Clor-N-Soil on Site



2.3.1. Analysis by Gas Chromatography (GC)

Gas chromatography separates the components of a mixture and allows an electron capture detector to detect any compounds containing chlorine, including PCBs.

Due to their unique retention time, PCBs can usually be singled out from other chlorinated compounds using this technique. If closely related chlorinated compounds are present in the sample, then a mass spectrometry detector can «fingerprint» the PCBs and confirm their identity. A common question is whether such analyses should be focused on mixtures of PCBs (e.g., Aroclor mixes) or on individual congeners. Congener-specific analyses have important advantages over analyses of mixtures: generally, congener analyses offer lower detection limits and greater information content. In addition, compositions of weathered, degraded, and metabolized PCB mixtures can be measured and interpreted more easily.

Also, it is easier to detect interferences caused by other chemicals, and quantification of individual congeners is more accurate. However, co-elution of analytes is a problem in a PCB congener analysis, so a strong quality assurance program and reliable reference materials are needed by the analyst.

Table 7: Advantages and disadvantages of gas chromatography

Gas Chromatography	
Advantages	Disadvantages
Exact results	Relatively high costs
Identification of PCB type possible	Long waiting time for result

Analyses shall be carried out by accredited and registered laboratories. Laboratories carrying out PCB analyses shall incorporate quality assurance and quality control programs.

2.3.2. Analysis Proceedings

To save analysis costs and time it is advisable to use screening tests whenever applicable. Nevertheless, it has to be considered that these methods test for the presence of chlorine in the sample being examined. As a result other chlorinated compounds, which can be part of the sample, could cause false positive results because the analysis method assumes all chlorinated compounds are PCBs. False negative results are not possible as if there is no chlorine present, PCBs cannot be present either.

Thus if a screening test shows a negative result (PCB below 50 ppm) it must be true, so there is no need of verification by another method.

If a test kit or the L2000 DX analyzer shows positive screening result (PCB > 50 ppm) verification by gas chromatography is always necessary.

In this case the sample for gas chromatography analysis is to be kept and forwarded to the appropriate laboratory. If results of a GC analysis show a significantly lower result than the screening tests there is no reason to be alarmed.

The tests are standardized for Aroclor 1242 with chlorine content of 42 %. Analyses with higher chlorinated PCB samples (e.g. Aroclor 1260 with chlorine content of 60 %) consequently show a higher result than the true PCB content. Thus the screening tests are always on the safe side.

Although false positive results obtained by the screening tests can cause unnecessary secondary testing, non-specific methods can be very economical when used on samples such as transformer oil, in which few sources of chlorine other than PCB exist. Used crankcase and cutting oils however always contain some chlorinated paraffin and almost every non-specific test produces false positive results. More expensive laboratory analysis is advised when testing for PCBs in these chlorine-containing oils.

2.4. Database

The information on PCB containing equipment and its owners, which is compiled in the course of the national inventory, has to be recorded in a database:

An Access or similar database is an ideal tool to estimate the overall amount of PCB. This information is essential regarding possible project proposals e.g. for an installation of a decontamination or elimination plant in the country. The database enables the environmental authorities to control the PCB equipment in regard to the deadlines for the elimination. As the addresses of all owners of PCB containing equipment are recorded, the database can also be used if the environmental authorities have to send mailings to the owners.

Picture 31: Example of input mask of database

The screenshot shows a complex data entry form titled 'Transformer data'. It is divided into several sections with various input fields, dropdown menus, and checkboxes. Key sections include: 'Identification' (item ID, name, station, branch), 'Technical Data' (type, manufacturer, country, year, serial number, voltage, rating, weight, dimensions), 'Operational Status' (status of operation, condition, leakage, label), 'Inventory & Maintenance' (inventory date, dead line, remarks, company), and 'Compliance & Testing' (L2000DK, gas chromat, parts per million, test kits, analyzed by, removed, refilled). The form is designed for detailed data capture from an inventory form.

The database's input mask should match with the inventory form. All information from the form should be recorded in the database. The extent of the information to be declared by the stakeholders in the inventory form should include at least: general data about ownership, equipment details as dimensions, ratings, location: indoor / outdoor etc. and also information that could be essential regarding future elimination (as leakages status of PCB-screening etc.). Furthermore, data related to PCB contaminated hotspots, including sites and groundwater, should be included.

Even photographs of the equipment and eventual leakages are to be incorporated in the National PCB Database. Therefore the database software in use should cover functions to enable storage of digital pictures.

Depending on the criteria for the deadlines of elimination (see also chapter 3.3) the following information should be considered:

- Is the equipment in use or out of use?
- Is the concentration of PCB <500mg/kg or >500mg/kg
- Is the technical condition of the equipment good or bad? and
- Is the equipment located near places of higher risk (e.g. hospitals, medical centres, food industries, water and sanitation services, highly frequented buildings etc.)?

Ideally the above criteria are linked to a search or output function in the database, which enables the user to control and monitor each piece of equipment that has to be eliminated by a certain deadline.

Each party of the Stockholm Convention is obliged to provide a report to the Conference of the Parties (COP) every five years on the progress in eliminating PCB. Therefore a function of the database should cover the recording and print out of all eliminated equipment in a given period.


A PCB database should not only be considered as a way to store all gathered information, but also as a tool which will be continually updated, assessed and adapted, until the last device containing PCB is eliminated (2028).

2.5. Labelling of Checked Equipment

When compiling the inventory, the inspected equipment shall be marked with labels as a precautionary measure. According to the result of the analysis of a sample or to the examination of the manufacturer's plate on a capacitor, a label as specified below will be affixed to the equipment.


This shall guarantee that the equipment can be separated easily and correctly for the disposal at the time of the dismantling activities. In addition, in case of an incident it ensures that the hazards of the situation can be assessed immediately at first glance from the color of the label.

Picture 32: Label for PCB free equipment




The equipment has been checked. Either the analysis of a sample has shown a PCB content of < 50 ppm or it has been possible to definitely determine that the equipment does not contain PCB e.g. by manufacturer's plate, nameplate, etc. (only possible with capacitors).

Picture 33: Label for PCB containing equipment



The red label is affixed to equipment where a PCB concentration of > 50 ppm has been analytically proven or if the equipment could clearly be identified as PCB containing by means of manufacturer's information e.g. name of cooling fluid. (possible with transformers and capacitors).

Picture 34: Label for PCB suspected equipment



The equipment has been recorded but not yet tested for PCBs e.g. if a sampling is only possible after a phase out. Such labelled equipment remains PCB suspected, a sample must be analyzed after dismantling respectively before disposal.

It is recommended that the contracting Parties use the proposed labels, presented in pictures 32 to 34 for the purpose of easy recognition while in service, for maintenance and phased out equipment. For the export purposes countries must use additionally the labels as referred to in chapter 8.2.2 in line with the Basel Convention requirements.

Picture 35: Example labelled transformers



Picture 36: Example labelled capacitors



Picture 37: Label for decontaminated PCB equipment

Decontaminated PCB Equipment	
The liquid containing PCBs was replaced:	
- with (name of replacement liquid)
- on (date)
- by (contractor)
Weight percentages of PCBs in the liquid in the equipment:	
- old liquid
- replacement liquid

Obviously, the concentration of PCB will increase after some time because of remaining PCBs in the active parts of the equipment (transformer). Therefore, a reliable measurement of the concentration is only valid after a given time after the decontamination.

The owner of decontaminated transformer should retest the oil in the transformer not before six months after treatment, and again after 2-3 months of operating time before a transformer can be reclassified.

Labels will be made by the owners of the equipment in accordance with the provisions (regarding size and material of the labels) stipulated in the Inventory Regulations.

2.6. Site Monitoring

The aim of a site monitoring is to identify all materials that could have been contaminated by equipment containing PCB during their life as a result of leaks, inexpert working practices, spills, inexpert storage or incidents. Places to investigate include concrete floors or gravel under

former PCB containing equipment, concrete floor in workshops or storage sites, soil in the area of former incidents or dumping places, etc.

Site monitoring covering the entire area of a company can be regarded as the last step after the disposal or decontamination of all equipment containing PCB in that company. Nevertheless, it is also recommended to perform site monitoring on a smaller scale after the disposal or decontamination of a single piece of equipment. In this case the monitoring would only cover the area of the concerned device.

2.6.1. Land Register of Areas and Storage Facilities with Possible PCB Contamination or contaminated equipment

In a POPs contaminated areas database all spots are summarized that potentially could be contaminated by PCBs. It includes all locations where PCB or equipment containing PCB has been in use, repaired or stored.

It must also be investigated, in what locations and circumstances PCB had been used in the past. Company archives about material flow or documents about former equipment can be a useful source of information. It is further worthwhile to interview employees of the company who are or were in charge of the acquisition or maintenance of potentially PCB containing equipment. Interviews should cover the types of purchased equipment, practices of maintenance, possible refills, stored drums with PCB for topping-ups, places of storage and workshops, incidents, etc.

The information obtained must be checked visually to substantiate the suspicion of PCB. The places which have to be visited are:

- Current and former sites of potentially PCB containing equipment (check ground under the equipment for leaks especially),
- Current and former workshops,
- Current and former storage sites for potentially PCB containing equipment or spare insulation fluid,
Sites of incidents (spills, internal failures, etc.), and Dumping sites.

All buildings where the PCB contaminated equipment is stored the following label should be affixed on building doors as indicated above.

2.6.2. Risk Assessment

To optimize the further proceedings it is advised to assess the associated risks of the sites that are listed in the POPs contaminated areas database. The questions to be considered are:

- Is the suspected PCB contamination secured or is it currently still spreading?
- Is the contamination endangering drinking water (ground water)?
- Is the location highly frequented by workers or passers-by (residential area)?
- Quantification: What is the size of the potential contamination or quantity of the endangered goods? and
- Storage: Are the suspected PCB containing goods stored appropriately (in drums or trays, sheltered, locked and separated from other goods) or inexpertly (no trays, in the open air)?

Sites that present an increased risk for humans or the environment have to be imposed with a higher priority for immediate action.

2.6.3. Analysis


In the next step a suspicion concerning possible PCB contamination has to be proved or disproved by taking and analysing specific samples. It is important to note that even if a visible spill does not contain PCB it is very likely that it does contain hydrocarbons, which are also a risk for the environment and have to be treated.

2.6.4. Extent of Contamination

When a site has been confirmed as being PCB contaminated, the extent of the contamination has to be delineated by taking further specific samples. In addition, the surrounding conditions of the site in terms of accessibility for machinery, availability of water and power, etc., need to be clarified. On the basis of the information obtained a decontamination of the site can be prepared.

The following flow chart provides an overview of the procedures for a site monitoring.

Chart 2: Site monitoring – procedures



3. PCB Management of Closed Applications

3.1. PCB Management Plan

Due to the noxious properties of PCBs every owner of equipment containing PCB should prepare a PCB management plan. It must cover the whole life cycle of these products (use, handling, storage and disposal) taking into consideration the dates as per PCB regulation. The management plan should be based on the polluter pays principle and should be in line with national law, regulations and priorities. Usage, handling and storage of PCB equipment should be considered as significant aspect by organization's Environmental Management Systems and should also be considered as hazard during the occupation health and safety risk assessment. A PCB management plan includes the following components.

3.1.1. Designation of a PCB Responsible

Every company has to assign to one or several people, depending on the size of the company, the responsibilities of implementing the procedures described below. In case of a PCB incident the PCB Representative will lead the emergency procedures.

3.1.2. Training and Instruction of Staff

Staff members must be instructed periodically about the risks for humans and the environment posed by these products and the safety measures as described in chapter 5. Precautions in order to prevent contamination of PCB free transformers (e. g. by refilling with untested oil) and the measures to take in case of an incident should be revised from time to time.

3.1.3. Inventory

All equipment in and out of use that may contain PCBs has to be identified and checked (also see chapter 2.1 Inventory). All tested devices must be correctly labelled as described in chapter 2.5.

3.1.4. Database on Locations with PCB Equipment, Waste or Contamination

As described in chapter 2.5 the inventoried devices, liquids, solids, soils and wastes shall be recorded in an appropriate database. This shall enable to categorize and visualize the data, and for example show all locations with PCB transformers on a map. For larger companies and authorities such a clearly arranged plan or map can serve as a useful working tool when planning the future elimination of equipment, and help make quick decisions in case of an incident.

3.1.5. Maintenance Plan

The maintenance of PCB containing equipment as described in chapter 4. must be performed regularly. In order to control its frequency, a **maintenance register** has to be kept that includes all PCB equipment of the company and in which every performed maintenance activity is noted. An example of a "PCB Equipment Monthly Maintenance Plan" follows in Annex 12.16.

3.1.6. PCB Spill Prevention, Control and Countermeasure Plan (SPCC Plan)

A SPCC plan has to be prepared to prevent spills into the environment, and to act accordingly to a situation if it should occur. More information about SPCC plan is given in chapter 3.2.

3.1.7. Disposal and Site Decontamination Plan

Equipment containing PCB and wastes must be decontaminated or disposed of solely by companies that have a special permit for treatment of such kind of materials and waste obtained by the authorized body in the field of environmental protection, or other foreign companies which provide such services and approved by the Government of their countries.

As decontamination or disposal of equipment containing PCB usually implies a great expense for a company, it is advisable to formulate a disposal plan, which defines dates of decontamination or disposal and replacement for every unit of equipment. In addition, financial planning for the disposal costs as well as for new equipment can be included in the plan.

PCB contaminated sites and soils should be decontaminated in order to avoid volatilisation and diffuse re-circulation of PCBs from contaminated water, soil and sewage sludge. Soils for example can be bio-remediated with the use of bacteria, which break down the chlorinated (and other) hydrocarbons, it can be also incinerated or extracted by means of venting (passage of air to remove vapours) or by solvent washing. The choice of technique is based on the previous analytical assessment, the extent and concentration of contamination, the matrix and the type of area (e.g. industrial, agricultural etc.). It shall also be taken into consideration that PCBs are a mixture, which may undergo biological degradation only to a certain extent. Highly chlorinated PCBs often remain intact (persistent).

3.2. Spill Prevention, Control and Countermeasure Plan (SPCC Plan)

The SPCC plan has to be elaborated to eliminate or minimize the potential environmental risk of a PCB spill, which could for example result from substation operations. The PCB Representative in the company will be in charge of the correct implementation of the following components:

3.2.1. Prevention

All doors to rooms where equipment containing PCB or wastes are located or stored must be clearly marked on the outside with a label. The use or storage of PCB transformers is prohibited in any location where human food or animal feed products could be exposed to PCBs released from the transformers. The storing of inflammable materials next to equipment containing PCB or waste is forbidden. Best working practices as described in chapter 4.2. have to be followed.

3.2.2. Spill Prevention Tools

Under each transformer a retention system has to be installed to prevent the dissemination of PCB into the environment in case of a leak. The best solution is a steel tray, however concrete or brick walls around the transformer are also acceptable as long as the basin is tight and its retention volume is greater than the volume of the fluid in the transformer.

In case of concrete basins they obviously should contain an oil resistant paint (e.g. appropriate kind of Epoxy).

Spare equipment or equipment out of use and other PCB wastes must be stored in steel drums or steel trays as described in chapters 7. and 8.

Picture 38: Labelling of a transformer room door



Picture 39: Retention system made from steel



The floors of workshops for activities like draining and dismantling of transformers has to be tight and fairly easy to decontaminate (e.g. Epoxy coating). The thresholds have to be elevated and all other openings close to the floor have to be sealed to prevent the dissemination of PCB into the environment in case of a spill.

3.2.3. Countermeasure

Emergency response plans as described in Annexes 12.8. and 12.9. have to be affixed near equipment containing PCB in an easily visible spot. In order to be able to react immediately in case of an incident it is recommended to keep appropriate materials and tools for immediate actions in an easily accessible place (protective gloves, drip tray, repair material, absorbents to seal leaks, etc.). Such storage depots can be recorded in the PCB register to allow immediate access in case of emergency.

3.3. Priorities for Disposal and Site Decontamination

According to the risk that a PCB containing equipment or contaminated sites and soil pose to humans or the environment there are different priority levels. These shall be stipulated in the national PCB regulation:

- (1) PCBs that are stored as spare oil, as waste or as electrical devices out of service have to be disposed of no longer than three years after their declaration to the Competent National Authority in the frame of the national inventory,
- (2) PCB containing electrical devices
 - of PCB concentrations higher than 0.05 mass percentages (500 mg/kg)
 - in a bad technical condition
 - situated near places of a higher risk for the people (hospitals, medical centres, commercial centres, schools and universities, food industries, water and sanitation services, highly frequented buildings) have to be decontaminated or disposed of with priority,
- (3) All other electrical equipment with a PCB concentration between 0.005 and 0.05 mass percentage (50 and 500 mg/kg) can remain in service until the end of their useful life, but no longer than the year 2025, and
- (4) PCB polluted soil and/or sites with direct impact to the environment or potential health risks, such as but not restricted to e.g. PCB contaminated agricultural land or sites close to food processing areas.

Particular importance should be given to get better insight in unknown sources, equipment or hotspots.

4. Maintenance of Equipment Containing PCB

The maintenance of a device should be performed according to the procedures issued by the manufacturer and by the corresponding national standards. In the following, a general view of the key elements of the maintenance of PCB containing transformers and capacitors is presented.

4.1. Maintenance of In-Service PCB Equipment

In-service equipment containing PCBs may need to be maintained according to the manufacturer's instructions for proper functioning or to clean up or prevent releases of PCBs. It is not within the scope of this document to discuss routine maintenance of equipment. The maintenance issues that are of importance for PCB Management are:

1. Transfer of liquid PCBs during maintenance
2. Replacement of leaking seals and repair of cracks and holes
3. Clean-up of minor leaks or spills during maintenance activities

All work on PCB containing equipment should be carried out in accordance with the site specific health and safety plan and applicable government regulations. Staff should be trained in the maintenance of the equipment and in the correct methods to handle hazardous materials.

If a piece of equipment containing liquid PCBs needs to have internal components "topped-up" or recharged, serviced or repaired (and is the type of equipment that is normally opened for servicing) serious consideration should be given to replacing the equipment or decontaminating it (removing the PCBs) and re-filling it with a non-PCB fluid. The Basel and Stockholm Conventions recommend phase-out of this equipment (under specific timelines) rather than continued use. Replacement fluids for electrical transformers include silicones, aliphatic hydrocarbons, poly- α -olefins, chlorinated benzenes and esters (Environment Canada, 1988).

If servicing of equipment is unavoidable, all work should be done with the objective of minimizing releases to the environment and minimizing the amount of contaminated material created through the servicing work. Recommended practice for this purpose includes:

- Plan the servicing in accordance with the manufacturer's recommendations, applicable regulations and codes and with the advice of experienced professional service persons.
- Turn the equipment off and disconnect it from the power source. De-pressurize the equipment if necessary. Allow the equipment and PCB liquid to cool to ambient temperature. Servicing equipment at ambient temperatures above 25°C should be avoided if possible due to the increased volatility of the PCBs at higher temperatures (i.e. more PCB vapours will be released at higher temperatures).
- Inspect the equipment before beginning service for leaks, holes, rust, low fluid level, high or low pressure (above or below specifications), high temperature (above specifications), malfunctions and gaseous emissions.
- Inspect the opening valves, latches, lids, etc. for blockages, breakage or malfunction.
- Re-consider and re-plan the servicing plan if any leaks, holes, malfunctions etc. are found.
- Ensure that spill containment measures are in good shape and adequate to contain the PCB liquid if spilled. It may be advisable to place plastic sheeting or absorbent mats under the equipment before opening it if the surface of the containment area is not coated with a smooth surface material (paint, urethane, epoxy, etc.).

- Additional ventilation may be required to keep the atmospheric PCB level below the recommended levels and to provide adequate oxygen for workers.
- Remove the liquid PCB either by removing the drain plug or by pumping with a peristaltic pump and Teflon or silicon tubing. Store the PCB liquid temporarily in one or more steel containers (drums) with tight-fitting lids or bungs. Leave a space of 8-10 cm at the top of the container for heat expansion and to avoid spillage when opening the container. Pumps, tubing and drums should be dedicated to the transfer of PCB liquids (not used for any other purpose).
- Inspect the inside of the equipment for damage, rust and cracks. Complete servicing and repairs.
- Replace any worn or broken seals.
- After completing the servicing replace the drain plug if applicable, replace the PCB liquid by pumping, add make-up fluid if necessary, and re-seal the equipment.
- Clean up any spills with cloths or paper towels. Triple rinsing contaminated surfaces with a solvent such as kerosene is usually necessary to remove all of the residual PCBs.
- All tools used for the servicing should be dedicated for PCB use.
- All absorbents, disposable protective clothing, plastic sheeting and removed components should be treated as PCB waste.

4.2. Best Working Practices

When performing light repair or maintenance work on PCB containing equipment, the following safety precautions for the protection of the employees and the environment have to be taken:

- Direct contact of the skin with PCB contaminated materials must be avoided by wearing gloves and safety goggles. According to the type of work to be performed, protective clothing and a respiratory mask must also be put at the workers' disposal (see also chapter 5.1. Personal Protective Equipment),
- The working area must be adequately ventilated,
- Spills must be prevented in every case by using drip trays or adequate plastic tarps,
- Every contact of PCBs with a flame or any other heat source over 300 °C and use of a grinder must absolutely be avoided (risk of highly toxic Dioxins and Furans),
- All used tools and other working materials that got in contact with PCBs must be disposed of as PCB contaminated waste in an environmentally sound manner or otherwise have to be decontaminated with an appropriate solvent (technical acetone). The only possible materials to be decontaminated are steel, glass, and ceramics. All other materials, such as rugs, PPE, etc. must be disposed of as hazardous wastes; tools and certain equipment (e.g. pumps and hoses) may be re-used but only for operations with PCB-containing equipment and must therefore be clearly marked/labelled as PCB-contaminated,
- Operations which involve draining, rewinding of coil, etc. may only be performed by companies approved for such tasks by the competent country authorities.
- The role of universities, NGOs and related stakeholders in promoting the dissemination of PCB management's best practices shall be strengthened.

In Annex 12.11 a proposal of a flyer can be found. It is recommended to print and distribute this flyer to owners of equipment containing PCB, so they can affix it to walls near the equipment or in workshops.

Picture 40: Transformer maintenance area



Picture 41: Active transformer part in Albanian workshop



4.3. Inspection of PCB Containing Transformers

4.3.1. Visual Checks

The simplest and the cheapest test of a transformer in service or in storage is the visual check. PCB Transformers shall be visually inspected quarterly by the equipment owner, who is also responsible for maintaining records of inspections.

The following areas shall be examined:

- Oil stains near the equipment
- Oil stains or weep marks on the equipment (welding seams, gaskets, valves, etc.
- Gross physical damage
- Tightness of drip tray

Table 8: Routine inspections for transformers

Inspection	What to look for (and corrective action)
Condition of gauges	➤ Cracked faceplates or damaged gauges (install a Plexiglas sheet over gauges for protection).
Reading of gauges	<ul style="list-style-type: none"> ➤ Change in readings since last inspection. ➤ Readings within the safe or acceptable range (if they are not, consider the addition of make-up fluid).
Corrosion on tank and radiator fins	➤ Condition of fins. They are manufactured of thin steel to obtain maximum cooling and will rust through more quickly than the rest of the transformer, especially in a caustic environment (clean to bare metal and paint if rusted).
Paint finish of tank and radiator fins	➤ Weathering paint (repaint as often as necessary).
Leakage of PCB from: <ul style="list-style-type: none"> ➤ tank ➤ radiator fins ➤ top cover (if gasketed) ➤ manhole cover ➤ top or bottom drain spout ➤ high and low voltage bushings 	<ul style="list-style-type: none"> ➤ Wet slickness and gummy residue. ➤ Deteriorating gaskets or seals. (Important – if there has been leakage, take steps to clean it up promptly and reported to the appropriate provincial authority. All materials used for cleaning up the PCB leakage must be safely stored as PCB-contaminated waste.)
Pressure-relief valve	➤ Improperly seated valve due to displaced gaskets.
High and low voltage bushings	➤ Cracking or chipping. (Replace cracked or chipped bushings.)
Colour of PCB	<ul style="list-style-type: none"> ➤ Colour changes. ➤ Take a small sample. If the color is changing from clear to a blue, green, red or black, the PCB is becoming contaminated (consider a laboratory test to check its quality).

4.3.2. Leaks of Transformers

When a leak or spills have been detected on or near a transformer, it is necessary to look into the cause of the leak to prepare remedial action. Most common are leaks at seals and gaskets. Various possibilities for effective reparations are apt and help avoid affecting the main body of the transformer in any way. However, only experienced electrical specialists who are aware of the dangers of PCBs shall perform such work.

A more serious situation occurs when the leakage or seepage is due to damage in the metallic structure of the transformer. Such leaks can be caused by mechanical and accidental damage to the transformer casing. In such cases, it is recommended to seal the leak temporarily with a sealing paste and place a drip tray underneath the leak for safety reasons. As this is only a temporary solution, a proper repair has to be carried out soon as possible.

A leak can also be caused by a slow degradation of the cooling fluid, which increases its corrosiveness. If corrosion is already advanced and causing leaks, then the transformer must immediately be sealed with a sealing paste, phased out as soon as possible and replaced by a new device.

4.3.3. Oil Level of Transformers

Most transformers have a direct or indirect device allowing the cooling fluid level to be controlled. Before topping up a decreased cooling fluid level, it is vital to check the PCB content of the transformer as well as the additional cooling fluid to avoid a possible contamination.

4.3.4. Temperature Gauge

The temperature gauge indicates the temperature of the dielectric fluid within the transformer. Excessive temperatures point towards an overheating of the transformer, possibly due to loss of dielectric fluid. Action should be taken immediately to detect the cause of the overheating, as the rate of the deterioration of insulating materials in the transformer can rise rapidly above the normal operating temperature.

4.3.5. Pressure-Vacuum Gauge

The pressure-vacuum gauge measures the pressure changes in the space between the dielectric liquid and the tank lid. Unusually high pressure indicates that short circuits and arcing may have occurred. In this case, a performance test has to be performed as soon as possible. An unusually low pressure reading indicates a low level of the dielectric fluid. Action should be taken immediately to identify the cause of the dielectric fluid loss.

4.3.6. Corrosion on Tank and Radiator Fins

The condition of the tank and the radiator fins has to be checked regularly, as they are prone to show corrosion. If corrosion occurs, the affected area has to be cleaned to the metal and painted.

4.3.7. Performance Tests

Transformers must be periodically checked to detect any changes which may be the first signs of degradation in the performance of the transformer, and therefore of possible risks arising. Among others, the following characteristics have to be checked:

- Functioning of all protection devices
- Electrical performance of the transformer
- Oil quality (physical and chemical tests)

4.4. Evaluation of PCB Containing Capacitors

Visual checks are easy and they can be carried out frequently if the conditions in the substation require so.

Visual checks allow detecting the following damages on capacitors:

- Leaks in the container
- Swelling out or deformation of the container
- Oxidation of the container
- Dirty bushings

In the first two cases, the capacitors must be phased out immediately and disposed of in an environmentally sound manner.

The swelling of the container is a clear indication of a soon short circuit in the capacitor!

Picture 42: Inflated capacitor



Visual checks must be complemented by technical examinations, which require qualified staff. Depending on the condition of the equipment, the frequency of the examinations is determined (at least once a year).

4.5. Substitute Fluids

PCB oils in transformers have often been replaced by common mineral oils like «Shell Diala B». However, other substitute fluids have also been used. The table below lists substitutes fluids for new transformers, together with their advantages and disadvantages.

Table 9: Substitute fluids




Substitute Fluid	Advantages	Disadvantages
Silicones	<ul style="list-style-type: none"> ➤ low pour point ➤ high fire point ➤ low rate of heat release upon combustion ➤ fairly low viscosities over the entire range of operating temperatures 	<ul style="list-style-type: none"> ➤ not compatible with some gasket materials, such as silicone rubbers and certain insulation materials. ➤ specific gravity of fluid is such that water will sink to bottom of transformer while ice crystals are buoyant and float to top. Melted ice crystals could migrate through fluid and reduce its dielectric strength ➤ cost is relatively high ➤ PCBs are soluble in silicones only up to 8 %
Aliphatic hydrocarbons (e.g., RTemp, produced by extensive refinement of crude oil and blending of anti-oxidants, stabilizers and other additives)	<ul style="list-style-type: none"> ➤ low degree of in-service degradation ➤ compatibility with all materials of construction normally used in electrical equipment ➤ fluid is compatible with all other dielectric fluids ➤ specific gravity is below that of both water and ice ➤ fluid is not a serious environmental hazard (same effects as other mineral oils), is biodegradable and can be disposed easily ➤ cost I lowest of all PCB substitutes and raw materials are plentiful 	<ul style="list-style-type: none"> ➤ high viscosity at lower temperatures ➤ high rate of heat release during combustion ➤ blended additives (proprietary to the supplier) are required to depress pour point and improve thermal and oxidative stabilities ➤ gassing tendency under electrical stress is equal to or higher than for conventional (naphthenic) transformer oils which are in turn higher than all other PCB substitute fluids
Poly-a-olefins (synthetic hydrocarbons)	<ul style="list-style-type: none"> ➤ compatibility with all materials used for transformer construction and all other hydrocarbon fluids ➤ lower pour point and slightly better low temperature viscosity than natural aliphatic hydrocarbons ➤ specific gravity below that of water and ice ➤ no gassing under electrical stress 	<ul style="list-style-type: none"> ➤ relatively high rate of heat release during combustion ➤ relatively high cost
Chlorinated benzenes (Tri-tetrachlorobenzenes are components of PCB but can also be use alone)	<ul style="list-style-type: none"> ➤ physical properties similar to properties of PCB ➤ transformers designed for PCBs are generally suitable for TTCBs 	<ul style="list-style-type: none"> ➤ not suitable for use at very low ambient temperatures because of high pour point ➤ exhibit some toxicity and not easily biodegradable
Esters (blend of pentaerithritol and fatty acids)	<ul style="list-style-type: none"> ➤ high dielectric strength ➤ low flammability ➤ low pour point ➤ no toxic substances generated during arcing conditions ➤ compatible with most materials used in transformers 	<ul style="list-style-type: none"> ➤ no significant disadvantages except higher cost than RTemp fluid

5. Safety

5.1. Safety and Personal Protective Equipment

People handling PCBs or people that can be potentially exposed to PCBs have to use adequate protective equipment. The level of protection and the choice of protective equipment depend highly on the tasks carried out.

Table 10: Description of personal protection equipment (PPE)

Task	Personal Protective Equipment
Sampling of liquids or soil 	<ul style="list-style-type: none"> ➤ Gloves (Vinyl or Nitrile, no Latex) ➤ Light respiratory mask (Filter A2P2; for organic vapors and particles, voluntary)
Sampling of a capacitor	<ul style="list-style-type: none"> ➤ Gloves (Vinyl or Nitrile, no Latex) ➤ Safety goggles, only while opening or drilling ➤ Light respiratory mask (Filter A2P2; for organic vapors and particles)
Sampling of concrete or brick wall (e.g. by drilling)	<ul style="list-style-type: none"> ➤ Leather gloves ➤ Safety goggles while drilling ➤ Light respiratory mask (Filter A2P2; for organic vapors and particles) ➤ Ear protection (while drilling)
Dismantling of capacitors (no leakage) 	<ul style="list-style-type: none"> ➤ Working overall ➤ Helmet (according to companies' safety rules) ➤ Steel capped (rubber) boots ➤ Leather gloves ➤ Light respiratory mask only in case of leakage (Filter A2P2; for organic vapors and particles)
Dismantling of capacitors (with leakage) 	<ul style="list-style-type: none"> ➤ Protective suit (Tyvek) ➤ Steel capped (rubber) boots ➤ Neoprene gloves ➤ Light respiratory mask (Filter A2P2; for organic vapors and particles)
Clean-up activities (choice of PPE according to type of contamination and extent of work)	<ul style="list-style-type: none"> ➤ Protective suit (Tyvek) ➤ Steel capped rubber boots ➤ Safety gloves (heavy duty) ➤ Respiratory mask (light or full face, Filter A2P2; for organic vapors and particles) ➤ Helmet (if necessary) ➤ Ear protection (if necessary)

The most important parts of Personal Protective Equipment (PPE) for handling PCB-containing materials are shown below:

Picture 43: Protection overall, one way, oil-resistant



Picture 44: Safety gloves, Neoprene



Picture 45: Breath protection masks, light, FFP2 or 3



Picture 46: Breath protection masks, medium, A2/P3



Table 11: Filter classification

Letter	Definition
A	High-boiling (>65 °C) organic compounds
P	Particles; classified as P1, P2, and P3 according to removal efficiency
ABEK, ABEK-P3, ABEK-HgP3	Combination filters against multiple hazards

Table 12: Particle filters

Class	Filter Penetration Limit
FFP2	Filters at least 94% of airborne particles
FFP3	Filters at least 99% of airborne particles

The appropriate choice of masks and filters respectively PPE in general shall be based on a risk evaluation, as other hazardous substances could be present depending on site, area and tasks to be performed.

Picture 47: Safety gloves, Nitrile, EN 388, oil resistant



Picture 48: Safety goggles



One-way gloves for the sampling of liquids should be made of Nitrile or Vinyl. Latex or Butyl rubber gloves should not be used as PCBs might penetrate through them!

5.2. Protection of the Environment

When handling PCBs, all necessary safety precautions need to be taken in order to prevent a contamination of the environment.

When taking samples of PCB suspected equipment or PCB suspected material, it must be worked tidily without losing or spreading sample material. Use oil absorbing carpet as foundation if needed.

All working material must be cleaned either with acetone or disposed of as hazardous waste, including PPE. Only metal and glass can be cleaned entirely, synthetic material and plastic, wood, etc. cannot be cleaned and have to be disposed of as hazardous waste.

When confronted with leaking equipment or equipment in bad technical condition during the inventory, it must be ensured that the leak can be stopped or that the entrainment of the contamination can be prevented.

In areas with spills: The contaminated area shall be marked and fenced off if possible. Clothing and footwear shall be changed when entering or leaving the contaminated area in a designated place (compartment). If possible, the leak shall be located and sealed e.g. with a sealing paste. Furthermore, the leaking device shall be placed in a steel basin or drip tray when out of service otherwise absorbent pads shall be placed around and replacement foreseen as soon as possible.

In case of leakage due to damaged equipment, uncontrolled spillage must be prevented by the appropriate positioning of a drip tray, as a first measure. Small leaks should be sealed, and suitable safety equipment must be used while carrying out this work. It is therefore advisable to always keep suitable material (drip tray, rubber gloves, sealing material) in the vicinity of such equipment.

Visibly contaminated soil or concrete should be removed as quickly as possible in order to avoid further contamination. Surfaces of objects (vehicles, sidewalks, buildings, etc.) should be cleaned by using oil absorbent materials and by wiping the surface with solvents. After the cleaning, the surfaces must be analytically tested to check the cleaning success. The used cleaning materials should be placed in drums for disposal.

6. Emergency Actions and Clean Up

Emergencies involving PCBs can occur with equipment in service, in storage, during transport or at a disposal facility. These emergencies may take the form of:

- A leak or spill of PCB liquid
- The failure of a piece of in-service equipment
- The accidental breach of a container of PCBs
- Fires

All companies operating storage facilities or transporting PCBs should develop and implement a fire and emergency action plan. Such a plan should be developed in conjunction with the local fire department.

All personnel working with PCBs should become familiar with the contents of the emergency plan. It is recommended that employees be trained in the use of the plan, preferably through emergency drills. As well, employees should be trained in the use of personal protection equipment, spill control kits, and fire extinguishers. They should also be made aware for the hazards of PCBs.

In case of incidents, accidents or spills the company shall notify all competent authorities in line with national regulation and environmental permit standards.

6.1. Emergency Actions for Cold Incidents

The seeping of PCB from a device in the environment is described as a «cold incident». Cold incidents can be caused by unintended mechanical damage to the transformer's cooling fins or by corroded transformer walls. Spills can, however, also occur during draining activities or the handling of stored oil.

The following measures must be taken:

Measures in case of «cold incidents»

- If a lot of PCB has leaked from the equipment and if there is a risk of the PCB contaminating the environment, the chemical brigade must be called immediately. If there are doubts whether or not the oil does contain PCB, then the oil should be regarded as containing PCB until the contrary has been proven.
- Inform the doctor in charge and equip the chemical response team with appropriate personal protective equipment according to chapter 5.1.
- Switch off the power supply to the concerned device and check grounding.
- Limit the spreading of the seeping oil by sealing the leak and using absorbing materials (sand, sawdust or cement) or by pumping in appropriate containers. If possible, a drip tray can be placed under the leak.
- Prevent the contamination of watercourses by PCB. Drains as well as channels and pipes that lead to open waters must be sealed. Furthermore, it must be ensured that no water can flow into the contaminated area (e.g. sprinkler systems). Consider: A pollution of watercourses or puddles does not necessarily have to be visible. PCB is heavier than water and thus there is no oil film on the water.
- Fence off and mark the contaminated area. A tent with different compartments must be set up to control the access of people and the movement of material into or out of the contaminated zone, in order to prevent clean areas from being contaminated. The personal protective equipment is put on/taken off in the tent every time when entering/leaving the contaminated zone.
- Within the contaminated zone, attention must be paid to the soles of the shoes. They must be clean; otherwise the floor could be contaminated with PCB by the soles.

- The contaminated floor or concrete should be removed as quickly as possible to prevent a further cross contamination.
- If the incident has happened inside a building: Evacuate people from all concerned rooms/buildings, switch off ventilation, close doors, and windows.
- Inform the competent authorities. All details about the incident have to be reported so that the population can be warned, if necessary (e.g. contamination of drinking water)

An Emergency Response Plan for cold incidents is given as a checklist for separate distribution in Annex 12.8. This checklist shall be regarded as a basic list and adapted to current actualities including contact addresses of competent authorities.

6.2. Emergency Actions for Hot Incidents

Incidents involving PCB equipment can also be caused by short circuits or a fire in the vicinity of the equipment. In case of a «hot incident», the temperature in the device exceeds the boiling point of PCB (approx. 300 °C).

If this happens locally even for a short time only (e.g. short circuit), PCB vapors can be released, and they can contain highly toxic Furans (PCDFs). If PCB gets in contact with oxygen (fire), not only Furans, but also Dioxins (PCDDs) can be formed.

6.2.1. Incident Caused by an Internal Failure

An electrical short circuit (arc) constitutes the greatest danger. In a capacitor, it gives rise to temperatures of several thousand degrees Celsius within fractions of a second.

Failures of this kind primarily occur in capacitors. The heat causes excess pressure in the equipment, resulting in the bursting of the capacitor. A black, viscous mass leaks out. This is PCB containing carbon black. Due to the increased temperatures gaseous PCB is formed, which is contaminated by Furans. These vapors can deposit viscous oil films on fittings, floors and walls, even at a distance from the place where the incident happened.

In addition to the measures mentioned in the previous chapter, the following points must be considered:

- Personal protective equipment must absolutely include respiratory protection.
- Lock the building immediately and stop air circulation by closing/sealing ventilation slits, if possible.
- Evacuate people from all rooms at risk.

Picture 49: Hot incident



Picture 50: Burst capacitor



Picture 50 above shows the former position of a burst capacitor within a capacitor battery. The oil squirted out and contaminated the wall behind the capacitors.

6.2.2. Fires

Fires of transformers or capacitors have been very rare. The causes of incidents usually were fires in the vicinity of the PCB containing equipment.

During a fire, there is danger of a decomposition of PCB caused by the heat and the effect of oxygen. Hydro-chlorinated gas is formed and the decomposition process can also result in highly toxic Furans (PCDF) and Dioxins (PCDD).

Picture 51: Fire near a substation



Picture 52: Remains of transformers in a scrap yard



The order of the measures to be taken in case of a fire is given below:

- Call the fire brigade immediately and carefully describe the situation so that the appropriate equipment can be chosen for the fire-fighting operations. If there are doubts whether or not the devices do contain PCB, then they should be regarded as containing PCB until the contrary has been proven. Calling the fire brigade immediately can highly reduce the effects of an incident.
- Inform the doctor in charge and equip the chemical response team with appropriate personal protective equipment. The protective equipment proposed in chapter 5.1 is not sufficient for areas where Dioxins and Furans have been released (and hardly kept handy everywhere). Consequently, the chemical response team should only approach the danger zone if absolutely necessary.
- Switch off power supply.
- Hermetically seal the rooms or the entire building. Switch off ventilation systems.
- Evacuate people from all concerned buildings, and on a larger scale in the direction of the wind.
- Inform the competent authorities: All details about the incident have to be reported so that the population can be warned or evacuated, if necessary.
- Fence off the contaminated zone and strictly control access. Only people wearing appropriate personal protective equipment are allowed to enter the zone. When fencing off, the direction of the wind must be considered.

An Emergency Response Plan for hot incidents as a checklist for separate distribution can be found in Annex 12.9.

Instructions for the fire brigade should include:

- To use CO₂ to extinguish the fire
- If water is used at all, then only to cool down the environment
- If water is used, it must not flow into the sewage system or open waters (pump!)
- To ensure that all skin is covered to prevent exposure to smoke containing PCBs
- Clothes and protective clothing that has come into contact with PCB or decomposition products (soot) must be regarded as being toxic and disposed of appropriately
- All firemen should shower thoroughly to remove any soot that may have contacted uncovered skin
- If a fireman develops a skin rash after a fire, he should go for a medical check-up

6.3. First Aid in Case of Contact with PCB

The following table summarizes the immediate actions that have to be taken after an exposure to PCB. Additionally, a doctor should be seen in any case.

Table 13: First aid measures

First Aid Measurements		
Kind of Exposure	First Action	Second Action
Liquid PCB on the skin	Use water and soap to wash thoroughly	See doctor if rash develops
Liquid PCB in the eyes	Rinse eyes with lukewarm jets of water for 15 minutes, always keeping eyes wide open*	See doctor
Liquid PCB in the mouth and in the stomach	Rinse mouth with water, do not drink anything else	Write down details about swallowed liquid, take victim to hospital emergency or doctor immediately
Highly concentrated vapors of PCB	Take affected people outside in the open air	If discomfort does not clear up, take victim to doctor

* An on-site eye wash station should be provided where PCBs are handled frequently

6.4. Clean Up after Incidents

6.4.1. Assessment of an Incident

In case of an incident, the operator/owner of the equipment must try to obtain the following information immediately, to enable a first assessment of the situation:

- Do the concerned devices really contain PCB?
- Is the PCB concentration known (e.g. from earlier analyses)?
- What is the assumed extent of the PCB or PCDF/PCDD contamination?
- Are there any visible billows of smoke, soot deposits?
- Weather conditions: Direction of the wind, wind force, rain, snow?
- Is the sewage system or the groundwater affected?
- Access roads used for possible fire-fighting operations (cross contamination)?
- When and where exactly did the incident happen (order of events)?
- If the incident happened in a closed room, it shall be reported if ventilation was in use and when it was switched off, respectively. Additionally, the names of all the people that came in contact with PCB or smoke shall be listed (for medical care, if necessary).

The assessment of the incident, which is done by experts, highly depends on the quality of the obtained information/responses to the above questions. Based on the received information, the experts take samples that are analyzed to determine the extent of the contamination. Cleaning activities should only be started with after the availability of the results, except for immediate actions, e.g. to control oil spills (to prevent a further contamination of soil, concrete and air). Incidents should immediately be reported to the competent authority in the field of Environmental Protection and Emergency Situations.

6.4.2. Decontamination Methods

The decontamination technique depends on the extent of the contamination; the pollutant(s), the concentration, and the contaminated material itself (concrete, soil, ceramic, plastic, etc.).

Table 14: Decontamination methods

First Aid Measurements	
	l: low concentration, dry, non-sticky soot, no visible oil film
	h: high concentration, visible oil film, spills, puddles, sticky soot
Material	Technique
Soil	Remove until material is below the limit of 50 mg/kg
	Remove until material is below the limit of 50 mg/kg
Uncoated concrete floors	Use industrial vacuum cleaners with appropriate filters and wet wipe the floor
	Repeated solvent scrub process followed by an absorbing clean up, until material is below the limit of 50 mg/kg
Walls, brick walls	Use water to clean, or remove plaster
	See concrete floors
Ceilings	Use industrial vacuum cleaners with appropriate filters to clean and wet wipe the ceilings
	See concrete floors
Untreated metal, window panes	Use solvents to clean carefully
	See above
Coated metal surfaces	Use solvents to clean
	Completely remove coating
Plastic parts (insulating material, etc.)	Use solvents to clean
	Remove, replace
Fittings	Dismantle completely and use solvents to clean
	Clean or remove, depending on concentration and quantity

The choice of the appropriate solvents or cleaning agents shall be made from case to case. It is recommended to use technical acetone to clean soot, dust, and similar materials. Spills are best cleaned by means of a biodegradable cleaning agent.

Visibly contaminated soil or concrete shall be removed in order to avoid further contamination. Surfaces of objects (vehicles, sidewalks, buildings, etc.) should be cleaned first by using oil absorbent materials and then by either a solvent scrub process or rather by using a biodegradable cleaning detergent. After the cleaning, the surfaces should be analytically tested to check the cleaning success. The decontamination process has to be repeated, until the remaining contamination is lower than the applicable limit value (50 mg/kg). If this procedure does not lead to a success, the structure has to be removed.

Spills into waters could pose a difficult clean-up problem and require special consideration. Since pure PCBs are denser than water, they will settle to the bottom and dredging of contaminated sediment will be necessary.

6.4.3. Protection of Workers and the Environment

In certain serious cases, the contaminated area should be sealed off by a protective tent around the zone. Such a tent must be air- and dust-tight, protect against the weather and control access by a system of compartments. The contaminated zone must only be entered through this system and personnel must wear personal protective equipment (PPE) when entering. The purpose of the sealing off is to prevent a cross contamination in the environment. A controlled exhaust system installed at the tent collects and filters (by an activated carbon filter) contaminated dust and particles that are formed during the clean-up activities.

6.4.4. Disposal

The appropriate disposal of the wastes is a very important part of clean-up activities after a PCB incident. Unfortunately, this aspect is often underestimated during the planning phase. Not only contaminated soil or removed contaminated building material, but also associated wastes like vacuum cleaner bags, solvents, personal protective equipment, cleaning material, sealing-off material, etc. must be disposed of in an environmentally sound manner. Please find more details about disposal in chapter 11.

6.5. Check of Clean Up (Monitoring)

The supervision of clean-up activities by an independent expert and/or representatives of the responsible authority is a key element of success and should be regarded as useful assistance. Representative sampling during and at the end of the clean-up activities shall prove that the remaining contamination does not exceed the tolerable and agreed values.

6.5.1. Tolerable Remaining Contamination after a Clean-up

The guide values for tolerable remaining contamination shall be decided in cooperation with the competent environmental authorities in case by case decisions. Furthermore, the control of the contamination after the clean-up shall be regulated. It can make sense to determine the limit values from case to case, depending on the project.

The following values can be regarded as a guidance based on limit values in various European Countries. Of course, the specific limit values of a country depend on its national laws and regulations.

Table 15: Proposed general guide values

Description	Substance	Guide value	Unit
Surfaces (for example cleaned/decontaminated metal surfaces)	PCB	100	µg/m²
Solids (for example concrete, building materials, etc.)	PCB	50	mg/kg
Indoor Air Rooms with a stay of eight hours per day (Intervention value)	PCB	> 6'000	ng/m³

Indoor Air Rooms with permanent stay (Intervention value)	PCB	> 2'000	ng/m ³
Indoor Air Value to be achieved after a PCB clean-up	PCB	300	ng/m ³

7. Phase Out

7.1. Phase Out of Transformers

The practical phasing out of transformers starts with the disconnecting procedure, which has to follow the local safety, rules for work on electrical equipment as well as (if available) the instructions of the manufacturer. Before any activity on the transformer can start it must be ensured that it has been switched off on the high- as well as the low voltage side, that the in- and out-coming lines are short circuited, safely and visibly earthed at the working place and that the operating panel of the circuit breaker and the low voltage power switchers are marked with a clear visible sign «do not switch works ahead». Furthermore, it must be ensured that access to the transformer is possible without any remaining risk.

The working area should be fenced off to avoid unauthorized access. A fire extinguisher must be positioned in a suitable place on site, ready to use in case of a fire hazard.


First of all inspect the transformer accurately on damage and leakage, then to avoid any further cross contamination it is, in case of leakages, essential to seal the leaking spots e.g. with SEDIMIT. Furthermore, remove all visible pollution on the metal parts e.g. with acetone to enable safe handling of the transformer afterwards.

Secondly it is, to avoid any risk of loss of PCB containing cooling fluid during dismantling and transport, advisable to drain the transformer on its location beforehand according to a well prepared work schedule and provision of all necessary equipment as PCB pumps, drums, personal protective equipment and tools. This procedure has also the advantage that it reduces the total weight of the transformer during transport considerably.

Before draining the oil, precautions for a spill have to be taken by covering the ground with one or two layers of extra strong plastic tarp and drip trays under the crucial parts like the oil pump, hose joints, etc. It is also advisable to have absorbents like sand, cement, or sawdust ready.

Due to the viscosity of the (pure) PCB cooling fluid, it might be difficult to open the drain tap. This has to be considered in advance to find the best possible solution. In case it is not possible to open the tap, drain the transformer via the oil filling cap or by removal of an insulator.

Picture 53: Draining of a PCB transformer



Picture 54: Phase out of an intact PCB transformer



Before the transformer is entirely drained off, it should be positioned at an angle to pump off as much cooling fluid as possible. It must be considered that there will remain some kilos of oil in the transformer after the draining off, which will be sweat out from the windings in time. The drain tap must be closed after the draining activities and, if possible, the transformer should be filled with an absorbent or some sawdust to bind the remaining PCB oil.

After removal of the device from its enclosure, investigate the area visually and decontaminate the floor, trench covers, walls and cables if necessary before installation of a new transformer.

If a transformer is free from damage and has no leakage and a clean surface, and the drainage is not performed on site, then the removal can be done in normal working overalls.

Filling the same drum with PCB contaminated oil from different transformers is allowed if their PCB content is known and of a similar concentration. If no information about the PCB content of the oil is available, the oil must be considered as PCB contaminated and the drums with the unidentified oil have to be marked as PCB contaminated.

All persons assigned to handle PCB equipment should be thoroughly instructed in the proposed procedures, particularly with respect to safety precautions, the use of safety equipment and the applicability of national regulations.

Wherever possible, PCB liquids should be transferred by pumping to minimize splashing and spillage. Centrifugal-type pumps, having all wetted surfaces made of stainless steel should be used. The shaft seal should be an external carbon ring type to eliminate exposure of the packing material to the deteriorating effects of PCBs. Valves should be brass or stainless-steel lined. Hoses should be flexible metal or lined with tetrafluorethylene or silicone polymers, and drip trays should be placed under all pumps, valves and hose couplings.

7.2. Phase Out of Capacitors

7.2.1. Preparation

The phase out of capacitors starts with the disconnecting procedure, which has to follow the applicable safety, rules for work on electrical equipment as well as manufacturer's instructions.

Before working on a capacitor or capacitor bank, the following operations must be carried out:

- Ensure that the circuit breaker or power switch and eventual line isolators for the affected capacitor are open and marked with a sign «do not switch works ahead»
- Short-circuit the incoming lines for the capacitor at the earliest 10 minutes after switch off.
- For high voltage capacitor banks connect earthing rods for each rack to the ground circuit by means of braids.
- Most capacitors are equipped with discharge resistors. Nevertheless, the terminals of the capacitor cases have to be shortened before any work is carried out on them, because the discharging circuits may be damaged.

The working area has to be fenced off by red/white plastic bands to avoid unauthorized access. A fire extinguisher has to be positioned, ready to use in case of a fire hazard.

Before the dismantling, it has to be checked if capacitors are leaking or if they are damaged. Leaks have to be sealed. Contaminated surfaces have then to be cleaned with e.g. rags and acetone solvent. Puddles of PCB containing dielectric have to be sucked up by pumps or soaked up by adsorbents. All arising waste has to be collected and disposed of as hazardous waste.

Picture 55: Dismantling of capacitor battery



Picture 56: Inventoried and labelled capacitor




If spills are situated in areas where workers have to enter during the dismantling activities, these areas must be covered with oil absorbent carpet to prevent an entrainment of the contamination by the sole of the rubber boots.

Before packing any UN-approved drum with waste, the drums must be checked (damage, leaks, UN approval).

7.2.2. Dismantling

While dismantling the capacitors, the bushings must be regarded as the «weakest» parts of the capacitors. Especially for heavy capacitors, it is not allowed to hold on to the bushings while carrying them, as they might loosen or break off and cause a spill of PCB-containing fluid. The capacitors must be safely packed into UN-approved steel drums on site.

Picture 57: Bad example of packing and storage



Picture 58: Packing of leaking caps into UN drums



If capacitors have to be stored temporarily, they have to be placed standing upright (bushings up). It is recommended to place them into steel trays or, if not available, on oil absorbing carpets to prevent any spills.

7.2.3. Phase Out of Other Equipment

Other electrical devices like circuit breakers mostly contain small quantities of oil. After the phasing out of such equipment containing oil, it has to be checked e.g. with a suitable test kit if

the cooling fluid is PCB contaminated. If the test kit shows a contamination of > 50 mg/kg the equipment must be considered as PCB contaminated and disposed as hazardous waste.

8. Packing

If there are no specific or sufficient national regulations referring to packaging, storage or transport of PCB, the international regulations shall apply.

Transport and packing of dangerous goods are regulated by various international regulations. There is a separate regulation for each means of transport (road, rail, sea) as you may see in chapter 10.1. The packing instructions are very similar to each other. The specifications of the different packaging types for PCB containing material according to the ADR (European Agreement concerning the International Carriage of Dangerous Goods by Road) are mentioned below:

8.1. Packing According to ADR

Due to the easy handling, open head steel drums are usually used for solids and tight head steel drums for liquids, respectively.

Table 16: Packaging types

Packaging Type	Purpose	Packaging Type Code
Tight head steel drum	Liquids	1A1*
Open head steel drum	Solids	1A2*

* Explanation of packaging type codes:

- The codes 1A1 and 1A2 describe the packaging type:
- The first figure specifies the kind of packaging (1 = drum)
- The letter describes the material (A= steel)
- The second figure characterizes the opening (1=tight head drum, 2=open head drum)

The maximum volume authorized by the ADR is 450 litres. However, drums with a volume of 220 litres are easier and safer to handle and therefore usually chosen. In addition, a volume of 220 litres is also permitted for a transport by sea (IMDG limit for liquid PCB: 250 litres).

Picture 59: Open head drum



Picture 60: In print UN approval



Packaging must conform to the construction and testing instructions stipulated in the ADR regulations. Strength and tightness are tested. UN approved steel drums have an imprint to prove a successful testing.

For the transport of PCB containing capacitors, the code can read as follows:

UN 1A2 Y 400 03 CH2025, meaning:

Table 17: Code for UN approved drums

UN	Symbol of the United Nations or the letters UN
1A2	Code for packaging type
Y	Two-part code: Letters of packaging group
400	For solids: Maximum gross weight in kg (example)
03	The last two figures of the year of manufacture (example)
CH2025	Manufacturer's code (example)

In case of liquid PCB, drums must never be completely filled. Approx. 50 mm or 10 % of the volume should be left empty for a possible extension of PCB in case of higher temperatures. Pumps should be used to fill the drums; pouring the liquid from one drum into another is no viable option. As disposal prices and techniques depend on the kind of waste, liquid and solid wastes should always be separated.

The European Agreement concerning the International Carriage of Dangerous Goods by Road (ADR) was done at Geneva on 30 September 1957 under the auspices of the United Nations Economic Commission for Europe, and it entered into force on 29 January 1968. The Agreement itself was amended by the Protocol amending article 14 (3) done at New York on 21 August 1975, which entered into force on 19 April 1985.

The Agreement itself is short and simple. The key article is the second, which says that apart from some excessively dangerous goods, other dangerous goods may be transported internationally in road vehicles subject to compliance with:

- the conditions laid down in Annex A for the goods in question, in particular as regards their packaging and labelling; and
- the conditions laid down in Annex B, in particular as regards the construction, equipment and operation of the vehicle transporting the goods in question.

Annexes A and B have been regularly amended and updated since the entry into force of ADR. The last amendments entered into force on 1 January 2007, and consequently, a revised consolidated version was published as document ECE/TRANS/185, Vol. I and II ("ADR 2007").

Annex A: General provisions and provisions concerning dangerous articles and substances

Part 1: General provisions

Part 2: Classification

Part 3: Dangerous goods list, special provisions and exemptions related to dangerous goods packed in limited quantities

Part 4: Packing and tank provisions

Part 5: Consignment procedures

Part 6: Requirements for the construction and testing of packaging, intermediate bulk containers (IBCs), large packaging and tanks

Part 7: Provisions concerning the conditions of carriage, loading, unloading and handling

Annex B: Provisions concerning transport equipment and transport operations

Part 8: Requirements for vehicle crews, equipment, operation and documentation

Part 9: Requirements concerning the construction and approval of vehicles

8.2. Summary of Possible Containers for PCB Transports

Apart from the commonly used steel drums, also other packaging types can be used, as long as they are UN approved and comply with the instructions of the ADR for the transport of the goods.

UN approved drums or containers should only be procured from an authorized manufacturer (ask for UN Certificate).

Table 18: Summary packaging

Packaging		
Waste Type	Containers	Dimensions
PCB liquids	UN approved steel drums for liquids 1A1 Large packaging IBC, 31A., 31B, 31N Tank Containers	60 to 220 liters 500 to 1250 liters Various sizes
PCB capacitors	UN approved steel drums for solids 1A2	Usually 220 liters
PCB transformers (only when drained!)	Steel trays 20' Box Containers with tip tray	Height over 800 mm Various
PCB solids, (metals, soil, debris)	UN approved steel drums for solids 1A2	Usually 220 liters
Damaged packaging (e.g. 220 liters steel drums)	Recovery drums Various types	Recovery drums Various types 307 liter und 427 liter

There are many different types of UN-approved packaging available. The choice of the appropriate packaging depends on type of waste, quantity, mode of handling/transportation but also foreseen method of disposal/treatment. For contaminated soil it might be advisable to use UN-approved Big Bags.

Picture 61: UN approved steel drums



Picture 62: Different types of alternative PE packaging



As described, UN approved steel drums have an imprint to prove a successful testing. Where an imprint is not possible, the containers must have an UN approval plate stating conformity to UN regulations.

Picture 63: Example of UN approval plate



Special bulk containers can be used for the storage or transport of PCB containing or contaminated solids as long as they conform to UN standards. A respective UN approval plate must be affixed to such bulk containers.

Picture 64: UN approved ICB solids



Picture 65: UN approved IBC liquids



Picture 66: 20' tank container liquids



Due to safety and handling reasons, however, PCB wastes should ideally be packed into UN approved steel drums. For example, capacitors shall be packed into UN approved drums (1A2). In the drum, they must always be stored standing upright. Any moving of the waste inside the drum has to be avoided, i.e. by using absorbents, wood, rugs, etc.

Picture 67: Phase out and cleaning of PCB capacitor



Picture 68: PCB capacitors in steel drum



Special attention is needed during dismantling and packing of leaking PCB containing capacitors. The main aim shall be to avoid cross contamination. Therefore immediately after phase out of the capacitors, the devices need to be placed in a drip tray. The surface should be cleaned and if necessary a leakage stop device can be used. When packing capacitors an appropriate part of the area shall be covered with e.g. chemical absorbing industrial carpet, an oil absorbent sheet or other suitable materials, in order to protect it from cross contamination or incidents during the packing procedure.

The lid should be removed from an empty drum and the drum carefully checked for damages as also new drums could be punctured due to careless handling. Ideally, PE-LD drum inlets are first placed in the drums. Then a thin layer of oil absorbent (e.g. absorbent material) should be placed in the drum. The PCB containing capacitors can then be carefully placed in the drum. As many capacitors as space allows may be placed in a drum. Ideally, appropriate material like Styrofoam should be placed between and around the single devices so that movement during transport will not be possible. Of course, all this depends on the size of the electrical devices and is mainly for low and medium voltage capacitors. If the height of the capacitors exceeds the drum, it might be necessary to carefully break off the bushings. Such activities shall only be allowed after the capacitors have been put into drums. Capacitors already placed in drums (upright position), but showing leaking isolators, do not pose a risk. Additionally, a layer of sawdust should be placed in each drum, in order to absorb any liquids if necessary.

According to today's regulations, unpackaged transformers and capacitors may be carried in cargo transport units fitted with a leak proof steel tray, having a volume of at least 125 % of the

remaining PCB liquid in the transformer and a height of at least 800 mm, and containing sufficient inert absorbent material to absorb at least 1.1 times the volume of any free liquid.

Picture 69: Preparation: transportation of PCB transformer



Picture 70: Covering the bottom with absorbent material



Adequate provisions shall be taken to seal the transformers and capacitors to prevent leakage during normal conditions of carriage.

Due to their size, transformers cannot normally be packed in boxes or even drums. Therefore, they have to be prepared and loaded on trucks in such a way, that no contamination of the surrounding materials is possible. Precautions have to be taken to prevent leakage and secure the devices.

Picture 71: Loading of transformers



Picture 72: Stowing of transformers



Due to safety reasons, UN approved drums or alternatively UN approved boxes, should be used, whenever possible.

Picture 73: Example of alternative metal boxes



Picture 74: Further alternative metal boxes



Damaged or leaking drums as well as drums that do not conform with the regulations must be stored and transported in recovery drums. Appropriate measures must be taken to prevent movements of the inner drum.

If the recovery drum carries liquid PCB, a sufficient quantity of absorbing material should be added to immediately absorb possible liquid coming out of the inner drum.

Picture 75: Recovery drum I



Picture 76: Recovery drum II



Picture 77: Plastic recovery drum



8.2.1. Labelling of the Packaging

The labels identify the dangers posed by the packed goods and is destined to attract the attention of the person handling the goods to take the necessary precautions during storage or transport.

The «Orange Book» defines the identification of a hazardous material or article. These assigned identification numbers are also generally referred to as «UN numbers».

Table 19: UN numbers for PCB


UN 2315	Polychlorinated biphenyls, liquid
UN 3151	Polyhalogenated biphenyls, liquid or Polyhalogenated terphenyls liquid
UN 3152	Polyhalogenated biphenyls, solid or Polyhalogenated terphenyls solid
UN 3432	Polychlorinated biphenyls, solid

8.2.2. Labelling for Storage or Transport


If waste is transported by road (ADR), each packaging must be marked clearly and durably with the UN number of the contained goods, the letters “UN” coming first. A label of class 9 “Miscellaneous dangerous substances and articles” must be affixed to each packaging (see Picture 78 and Picture 79). In case of recovery drums, the designation «OVERPACK» must be added.

Remark: The class 9 pictogram is included in the UN Model Regulations but has not been incorporated into the GHS because of the nature of the hazards. In the GHS system the nature of hazards has been defined in such a way that various class 9 materials are included in other more specific classes. Nevertheless, the transport labels are still the same as in the Dangerous Goods transport regulations. GHS only concerns the packaging of materials and concerning waste there are some exemptions, in other words, less stringent definitions concerning the exact composition of materials. Consequently, class 9 is used when transporting PCBs.

Picture 78: Labeling Acc. to ADR for liquid PCB



Picture 79: Labeling Acc. to ADR for solid PCB




The UN number for PCB capacitors is UN 2315.


The identification of containers for a transport by **sea** is different. The IMDG (International Maritime Dangerous Goods Code) applies for such shipments.

In addition to the UN number, the proper shipping name (PCB) must be mentioned and some indication about the condition of the contents (LIQUID or SOLID) must be made. The class 9 label as well as a marine pollutant label must be affixed on the containers. Since 2009 a new marine pollutant label shows a dead tree and dead fish.

Picture 80: Labelling of liquid PCB according to IMDG



Picture 81: Labelling of solid PCB according to IMDG



The weatherproof drum/container labels should at least contain the following data:

- UN number
- UN classification
- "HAZARDOUS WASTES"
- Waste identification code
- Waste designation
- Tracking form number

Additionally it is advisable to add the following:

- Origin of the wastes
- Weight of the drum
- Drum tracking number

Examples of labels to be used for PCB waste declaration:

HAZARDOUS WASTES DECHETS SPECIAUX / RIFIUTI SPECIALI SONDERABFÄLLE	
WASTE	Polychlorinated Biphenyls, Liquid
UN NO.	2315
EX SITE / ORIGIN	
MOVEMENT/TRACKING FORM NO.	
IDENTIFICATION NO.	

HAZARDOUS WASTES DECHETS SPECIAUX / RIFIUTI SPECIALI SONDERABFÄLLE	
WASTE	Polychlorinated Biphenyls, Solid
UN NO.	3432
EX SITE / ORIGIN	
MOVEMENT/TRACKING FORM NO.	
IDENTIFICATION NO.	

8.3. Handling of Packed Waste

It is essential to weigh the packed drums. If possible a mobile scale can be used on site. This allows a reliable planning of the transport of the waste. The following information shall be additionally written clearly on the lid of the drum:

- Contents
- Name of the location, where the packed goods originate from
- Date
- Weight and signature

Picture 82: Safety Drum lift



Picture 83: Marking the drums



The drums with open lid must be secured by «splints». Full drums should preferably be carried by a safety drum lift, forklift or crane. If using a crane, there are special drum clamps available for safe handling. Only checked and clean drums shall leave for disposal respectively to the temporary storage area.

Packaging depends on type of waste, waste quantity, mode of transport and method of treatment or disposal. Further details are mentioned in chapter 8.2.

9. Temporary Storage

9.1. Temporary Storage - On Site

PCB containing wastes should generally not be stored on sites that are not specifically designed for interim storage of hazardous wastes. Usually, there is no appropriate infrastructure to guarantee a safe storage. Uncontrolled and inexperienced interim storages as shown in the pictures below endanger people and the environment, and result in unnecessary additional costs.

Picture 84: Bad example I (open air storage)



Picture 85: Bad example II (no tip trays)



PCB containing devices should be packed safely and in compliance with the applicable laws (see chapter 8.1.) as soon as they have been phased out, even if their disposal takes place at a later stage. Irrespective of the quality of the temporary storage, the final and environmental sound disposal of the waste must be scheduled and coordinated so that **storage will not exceed twelve months**. Generally, electrical equipment should only be phased out and stored, once an appropriate method of disposal has been chosen.

When setting up a temporary storage for PCB wastes it is important to choose an appropriate storage area. Locations close to rivers, groundwater, residential or farming areas, and ecological reserves or for example food processing industries CANNOT be considered suitable. If possible, the interim storage should be specifically designed for PCB containing equipment and wastes.

Table 20: Minimum requirements for temporary storage on site

Packing

- Capacitors must always stand upright. The insulators are the weakest parts. Never lift a capacitor by holding the insulators, they can easily break off.
- Capacitors must be stored on steel drip trays and leaking devices should be sealed. It is advisable to add absorbents to the steel trays.
- It is possible to put capacitors and contaminated solids into containers that are not UN approved. However, such containers must be checked for damage and leaks before use and cannot be utilized for transports. After use, the containers must be regarded as contaminated and also be disposed of as hazardous waste!


Building

- The floor of a temporary storage must be solid and tight. The storage must be walled and protected against the weather on all sides.
- All entrances to the storage must be marked with an appropriate warning, and access for unauthorized people must be forbidden.
- The area must be fenced and controlled.
- Display emergency procedures and best working practices (see Annexes 12.8., 12.9.).
- The building should have some openings for permanent ventilation (ventilation systems with filters).
- Increased risks of fires must be excluded (no wooden shed, no storage of inflammable goods in the same building or in the neighbourhood). A smoke and fire alarm system should be installed.
- Fire extinguishers (powder) and absorbents (e.g. sawdust) must be available and easy accessible.
- The building should be separated in different areas (reception, handling, separate storage of different waste categories, equipment, etc.)
- No food storage or food processing companies in the neighbourhood.

All goods/wastes must be clearly marked giving information about the kind of waste, the date of packing, the weight, the origin and further important data. An up to date storage list must be accessible at any time.

Temporary storage CANNOT be accepted as long-term solution.

Picture 86: Example 1 of a sound storage platform



[Source: unknown]

Legend

- | | |
|--|--|
| A - security fence | H - recovery drum |
| B - padlocked door | I - spare drum |
| C - concrete floor (no drains) | J - clean-up materials, stored in bin |
| - all cracks and expansion joints between slabs sealed with compound | K - locker for PPE worn when working with PCBs |
| - floor painted with epoxy paint to prevent PCBs to penetrate in concrete | L - pumps and hoses for use with PCBs laid in a drip tray |
| D - concrete curb around perimeter of storage area; inside of curb painted with epoxy | M - scrapped transformer in protective crate |
| E - sealing compound (grouting) at corner of curb to prevent leakage under curb | N - delivered capacitors on pallets for packing |
| F - ramp over concrete curb, into storage area | O - first-aid kit |
| G - drums containing PCB-wastes | P - PCB label on door |
| - stored on pallets for mobility | Q - powder or foam-type fire extinguisher |

9.2. Central Storage Platform

A central storage platform shall provide the necessary storage room, where PCB devices and associated waste can be collected and stored until their final disposal. Such a platform could also be used as a «buffer zone» by regional or national authorities, or by waste treatment / disposal plants to guarantee a constant running of their plants.

PCB equipment and PCB wastes shall be stored according to their category or priority. Appropriate areas shall be defined for each type/category of PCB waste. Ideally, already existing storage facilities, for example the facilities of PCB equipment holders could be upgraded to meet safe and professional standards.

Available Site

The available site must be carefully monitored and reported in respect of existing groundwater and its level, existing soil contaminations as well as permeability of underground. The most suitable location shall be defined under consideration of the following criteria.

- The storage building shall be located and maintained in conditions that will minimize volatilization, including cool temperatures, reflective roofs and sidings, shaded location, etc.
- The surrounding land should be sloped to provide drainage away from the site
- The area must be fenced and controlled
- All entrances to the storage platform must be marked with appropriate warnings

- An access control system shall be installed to ensure access of authorized staff only

Human and Environmental Hazards

PCB belongs to the group of POPs banned by the Stockholm Convention. Therefore all relevant precautions must be provided to avoid human and environmental hazards. The entire interim storage facility must meet BAT and BEP requirements.

Technical Hazards

The whole area used by the interim storage facility must be protected against spillage of contaminated oil and of chemicals.

Area Preparation

- Wherever necessary, the ground must be sealed with adequate material, considering PCB but also associated solvents and chemicals when handling and treating PCB containing electrical equipment and oil. The sealed area must be dewatered with special sewers, capable for retaining any oils and other insoluble organics.
- Due to the possibility of fire hazards efficient fire protection and firefighting equipment must be provided. In combination with the firefighting equipment an appropriate collecting volume for effluent water must be provided.

Logistics

- The existing transport infrastructure to and from the area (road and railways) shall be used for the proposed storage facilities.
- The building shall be accessible by forklifts and trucks.
- There should be enough space for any truck or crane movement in front of the building. This central receiving area where PCB equipment and wastes are loaded and unloaded from transport vehicles should have a PCB impervious floor and containment system to properly control any spills during loading or unloading.

Handling of Incoming Goods

- Each incoming waste delivery shall be examined and checked as follows:
 - Internal information and weighing
 - Check of accompanying tracking forms/sheets, sampling and visual check of wastes
 - If necessary, screening of waste sample
 - Labelling and storage at defined storage area, according to waste category
- Only equipment accompanied by duly signed tracking forms/sheets shall be accepted and stored in the interim storage. Tracking of the waste generator must be ensured at any time.
- Transformers for dismantling or revision, delivered by rail or road transport must be kept in a covered and spillage protected area until they are tested for contamination with PCB. After testing they shall be stored inside the storage building in separate compartments for contaminated and not contaminated units. If ever possible, the transformers shall be stored on racks mounted on drain trays. But if stored on racks or not, all units must be placed in such drain trays.
- Handling equipment like overhead cranes and forklifts for all kind of transformers shall be provided.
- Every container with transformer oil, which is present in the intermediate storage facility must be tested, labelled and stored in compartments according to their contamination.

Capacity

- There shall be an intermediate storage in a suitable size for the needs of the area/region. It is recommended to store as a maximum 25 transformers in sizes of 200 to 1'500 kVA as well as boxes and drums with some 150 to 200 tons of PCB waste.

- These maximum capacity restrictions shall assist in keeping the intermediate storage platforms real temporary and no long-term solution storages.
- Capacitors and wastes which cannot be treated shall be shipped to a licensed disposal facility within Europe on a periodical basis.
- PCB wastes shall be packed in accordance with the instructions stipulated in the ADR, RID and in some cases also according to IATA.

Foundation

- The storage building must contain a foundation suitable for mounting metal sheet walls and roof as well as piles designed to support overhead cranes for the handling of the delivered transformers.
- All structures above ground level must be coated and sealed like the floor.

Floor

- The floor profile must be shaped in a way that no spillage from transformer handling or effluent from firefighting may flow outside the facility into the unprotected area.
- All floors inside the storage building must be industrial type floors (e.g. steel or concrete) and sealed with a PCB resistant sealant such as two-component epoxy paint.
- It is recommended that the sealant coating is inspected periodically to check its integrity.
- The building shall be set on asphalt or concrete.
- The floor inside the building shall be concrete; coated with a durable epoxy polymer to prevent PCBs to penetrate in concrete.
- The floor must be solid and tight, all cracks and expansion joints between slabs must be sealed.
- Floor drains shall be reduced to a minimum and must be connected with an internal sump.

Curbs

- The storage area for transformers within the intermediate storage shall contain 6 inch high curbs that provide a containment volume equal to at least twice the internal volume of the largest PCB item.
- Concrete curb around perimeter of storage area; inside of curb painted with epoxy. Sealing compound (grouting) at corner of curb to prevent leakage under curb.
- The storage building may not have any openings, expansion joints or drains that would permit liquids to flow from the curbed area.
- A ramp over the surrounding concrete curb shall be provided to allow access with forklifts into the storage and handling area.

Walls, Doors and Windows

- The walls of the storage building may consist of a light metal sheet construction. Doors and windows have to be foreseen according to the requirements of the user, logistics and treatment process.
- Doors must open to the outside. Minimum width for any door is 80 cm.
- Windows must be planned and built in such a way that they face each other.

Roofing

- In order to prevent the atmosphere in the storage building from extended temperatures (vapour pressure of PCB!) the roof shall be reflective.
- The roofs of the building shall be sloped so as to provide drainage away from the site.

Layout of the building

The building shall be separated in different areas:

- Reception area
- Handling area
- Treatment area
- Separate storage areas or rooms for each type of PCB waste:
 - PCB containing transformers
 - PCB containing capacitors
 - Drums with PCB oil
 - PCB solid wastes
- Equipment area
- Office
- Sanitary installations

There must be a fairly big working area, where e.g. transformers can be drained or waste handled and packed. The floor of this area should be preferably covered by steel (like a drip tray) and absolutely tight, optionally, a special, PCB resistant epoxy coating could be applied.

PCB wastes should be packed as to ensure that the potential for leakage or spills is kept to a minimum (e.g. in UN approved drums). The containers should be clearly labelled and marked with the date of entry to the storage. Drums or other portable containers of PCB and PCB equipment should be placed on pallets.

Sufficient space should be left between stored containers and equipment to permit inspection and allow the safe movement of vehicles such as forklifts. Drums or other containers of PCB liquids should be separated from each other by pallets and not stacked more than two containers high.

Ventilation

- A ventilation of the entire storage facility must be installed to avoid elevated concentrations in the atmosphere of PCB and other POPs which might be present. Generally the exhausted air must be cleaned by activated carbon filters. If necessary, the ventilation must be supported by an induced draft fan.
- A fresh air inlet shall be installed in accordance to induced draft fan specification. If there is no specific legislative requirement a guideline will be a twofold to sixfold air volume exchange during normal operation with the possibility to increase to tenfold or twelvefold in case of high gas concentration alarm.

Fire alarm / Fire protection

- Due to the extreme environmental and health hazards in case of a fire in the storage building, it is very important that a smoke- and fire alarm system covering the entire facility will be installed.
- The detection-, alarm- and fighting system must meet all relevant national and community regulations as well as international BAT and BEP standards.
- The building shall have a fire suppression system; preferably a non-water system. If the fire suppressant is water then the floor of the storage room shall be curbed and the floor drainage system must not lead to the sewer or storm-sewer or directly to surface water but should have its own collection system such as a sump.

- Fire extinguishers (powder) and absorbents (e.g. sawdust) must be available and easily accessible.
- A lightning protection system covering the whole interim storage facility must be installed.

Electrical Installations

- All the electrical installations must be installed at least 1.5 meters above ground level to assure a certain protection against explosion risks.
- The quantity and design of electrical connectors shall be defined in cooperation with the operator of the waste preparation units.

Installations for control of water run-offs

- The sumps within the protected area shall contain a level alarm high and high+.
- Water run-offs and canals must be leak-proof and easily accessible for cleaning purposes.

Pipelines

- Any pipeline to be installed in the interim storage facility must be over ground.

Emergency equipment

- All the necessary emergency equipment for a safe shut down of the plant and all necessary equipment for a safe and controlled evacuation of the storage facility in case of fire must be available and easily accessible.

Emergency response plan

- Emergency procedures and best working practices shall be displayed.

Health and safety plan

- A health and safety plan shall be displayed.

Spill prevention, control and countermeasure plan (SPCC)

- The site should be subjected to monthly inspections for leaks, degradation of container materials, floors, drains, draining systems, personal protection equipment, integrity of fire alarms and fire suppression systems, vandalism, security fences and general status of the site.


Database of Interim Storage Platform

- A complete database of the PCB wastes and other equipment and chemicals in the storage site shall be created and kept up to date as waste is added or disposed of. The records should include:
 - An inventory of each item of PCB waste and the quantity of PCB therein
 - The date and source of PCB waste transferred to storage and the date and destination of waste leaving storage
 - A description of the PCB waste including the quantity and concentration of PCBs, nameplate description where available
 - Identification number for the PCB waste
 - Name of carrier of PCB waste
 - Name of recipient of PCB waste
 - Date and quantity of PCBs spilled as a result of a leak or accident and clean-up procedures adopted
 - Dates and details of inspections by the competent authorities and the owner
 - The responsible fire brigades and environmental authorities shall be informed about the amount of PCB wastes in stock periodically (e.g. every 2 weeks), by providing them with a copy of the latest stock list/records.

Personnel working at the facility should be made clearly aware of and understand current PCB waste management procedures including the use of personal protection equipment and clean-up techniques.

The above inputs shall be taken as general advice and recommendation. However it is important to review them at the time of construction or upgrading of an existing storage facility together with the competent local and governmental authorities as regulations and guidance may change.

Picture 87: Example 2 of a sound storage platform




If there is neither a storage platform as previously described nor another possible interim storage building, a kind of mobile interim storage could be installed for short-term use. Depending on the quantity of the arising waste, 20' or 40' Box Containers with integrated drip trays as safety precaution could be an option.

Picture 88: Typical 20' Box Container with trip tray



Picture 89: Short term storage in containers



It should be considered that usual Box Containers do not contain a steel ground but only wood and therefore need to be adopted.

9.3. Authorization and Control

The establishment of an interim storage facility or a central storage area is only possible after submission of an Environmental Impact Assessment study and is subject to authorization of the competent authorities.

It is further recommended that an extension of temporary storage beyond the period of 12 months shall also be subject to authorization by the competent authorities.

10. Transport

10.1. International Regulations for the Transport of Hazardous Goods

Depending on the means of transport for hazardous goods, the following regulations are applicable:

- ADR (European Agreement concerning the International Carriage of Dangerous Goods by Road)
- IMDG (International Maritime Dangerous Goods code/transport by sea)
- RID (Regulation for the international transport of hazardous goods on railways)
- IATA DGR (IATA regulations on the transport of hazardous goods/air transport)
- United Nations Recommendations on the Transport of Dangerous Goods Model Regulations (Orange Book)

Picture 90: ADR



Picture 91: IMDG



It should be noted that various regulations (ADR/IMDG/RID/IATA-DGR) are substantially similar to one another. The only difference is that special packaging, labels or quantity limits are specified for the different means of transport, depending on the type of hazardous goods.

10.2. ADR

10.2.1. Obligations of Main Actors

Basically, the ADR distinguishes between three main actors, whose obligations are described as follows:

Exporter

- To check if the goods to be transported are classified and approved for shipment.
- To supply all necessary transport documents.
- To only use UN approved packaging that are correctly marked and labeled.

Carrier

- To make sure that all necessary documents are carried along in the vehicle.
- To check if the freight is in good condition, i.e. no visible damages like leaks or cracks.
- To make sure that the vehicle is not overloaded.
- To make sure that the placards and labels are affixed.

- To make sure that the equipment as stipulated in the written instructions for the driver are carried along in the vehicle.
- Not to transport the freight if it does not comply with the regulations.

Importer

- Not to delay the acceptance of the goods without compelling reason, and to check after the unloading if the ADR instructions concerning the import are fulfilled.
- To clean and decontaminate vehicles and containers.
- To make sure that any labels, marks and signs are no longer visible on the completely unloaded, cleaned and decontaminated container.

10.2.2. Documentation

The following documents must accompany every shipment in accordance with the ADR:

Movement document

The following data of every single good/waste must be mentioned on the movement document:

- UN number, with the letters «UN» in front of the number
- If the goods are wastes, the word «WASTE» must be written in front of the UN number
- The official designation (Polychlorinated Biphenyl) plus the technical term (PCB)
- UN class (9)
- Packaging group
- Packaging type and number of packaging
- Total quantity of each dangerous good with different UN number
- Name and address of exporter
- Name and address of importer

Container packing certificates

If dangerous goods are transported in box containers by sea, a container packing certificate must be enclosed to the movement document. Basically, the container packing certificate confirms that the goods have been packed and loaded according to paragraph 5.4.2 of the IMDG Code. The container packing certificate can be integrated in the movement document. An example is shown in Annex 12.19.

Written instructions

To be able to take actions immediately in case of an accident or an incident, the driver must be provided with transport emergency cards for each transported dangerous good briefly informing about the following:

- Designation, class and UN number
- Possible dangers that can be posed by the goods
- Necessary additional equipment
- Measures to be taken

Not only ADR regulations but also Basel Convention procedures and documents must be considered for international transports of hazardous wastes. The two regulations sometimes overlap and it is e.g. sufficient to use the Basel Convention Movement Document (see Annex 12.18.) to accompany the transport.

10.3. National Transports

National transports of PCBs and PCB wastes have to be in accordance with the national hazardous goods regulations and laws.

If necessary, national legislation to regulate criteria for the transport of hazardous wastes, such as insurance, registration and license and safety aspects, shall be developed.

Also during national transport a movement document shall accompany the wastes at any time.

Picture 92: Example of possible nation tracking form

Tracking Form		No. AA 123 123 123	
Consignor (name, address)	Contact person: Telephone: Date:		
Waste (designation / chemical composition of waste)	Waste identification code: UN number: Quantity: (kg / litres) Packaging: (Type / number)		
Consignee (name, address)	Contact person: Telephone: Quantity: (kg / litres) Method of disposal: Date:		
Carrier (name, address)	Contact person: Telephone: Means of transport: Date:		

10.4. Transboundary Movement of Hazardous Waste

When exporting PCB wastes to other countries, the procedures stipulated by the Basel Convention (see chapter 1.2.) have to be followed. One important condition under the Basel Convention is that a transboundary movement of hazardous wastes or other wastes can take place only upon prior written notification to the competent authorities of the States of export, import and transit, and upon consent from these authorities permitting the transboundary movement of waste.

Furthermore each shipment of hazardous waste or other waste shall be accompanied by a movement document from the point at which a transboundary movement begins to the point of disposal (see Annex 12.18.).

Please contact the competent National authority for specific information:

10.5. Loading and Safety Check before Transport Takes Place

The type of packaging and transport depends on the chosen method of disposal and may vary. It should be considered that beside the national and international packaging regulations also the disposal facility might have special specifications.

No person shall handle, offer for transport or transport PCBs or devices containing PCBs, including waste, unless he is trained to do so, or is performing those activities under the direct supervision of a trained person.

10.5.1. Loading on a Truck for Local Transports

All hazardous wastes ready for transport have to be packed and labelled according to the ADR (see chapter 8.).

10.5.2. Loading of Containers for International Transport

Due to safety reasons, it must be considered that PCB containing waste should be loaded at one go. Therefore, the loading of containers is performed shortly before their transport.


The containers have to undergo an examination by an accredited Customs Office. Before the containers are loaded, it is first necessary to check their condition again. Dust and dirt on the loading surface have to be removed.

Each single drum has to be checked for safety and possible damages. The drums have to be handled carefully. The code, content, number and weight of every loaded drum have to be recorded in a Container Loading List.

For the weighing activities a calibrated mobile scale has to be used. Only units that are given free from inspection and weighing may be loaded.

There are various types of Containers which can be used for the transport of hazardous wastes:

Picture 93: Different types of containers




When wastes are transported over long distances, it is particularly important to ensure that the load cannot shift. The load can be ideally secured by optimal utilisation of space and by safety

measures like tightening belts, antislip wooden boards and air bags. It is also necessary to ensure that the weight of the individual packaging in trucks or containers is evenly distributed.


Furthermore, the total gross loading weights, which vary from country to country, must be considered.

Picture 94: Movements of containers e. g. on ships to be considered




If 20' Box Containers will be used for transportation, there is space for 36 UN approved drums in one layer. The containers shall be loaded with two layers of drums, therefore a total of 72 drums may be loaded into one container. The next picture illustrates how the drums are loaded in the container with a floor between the layers, made of plywood planks.

Picture 95: Top View of loaded 20' box container



Picture 96: Side view of loaded 20' box container



1st layer: 36 drums
 2nd layer: 36 drums
 Total: 72 drums per Container

Picture 97: Loading of container




Picture 98: Lifting of containers to truck



When transporting (drained) transformers, the devices must be tightened by using sufficiently strong belts fixed to the lifting eyes. The loading is easier if open top containers are used. However, such containers must be covered by a tarpaulin to protect against the rain.

Picture 99: Open top container



Picture 100: Loading of transformers



There are also special containers for the safe transport of PCB containing transformers that have not been drained (see picture above). Such units, however, are rather expensive.

10.6. Waste Transportation by Air

Air transports of UN no. 2315 and 3432 are basically possible. However, IATA regulations do generally refer to substances in their original, pure form only, and NOT to wastes.

It is therefore not appropriate and not recommended to transport Hazardous Waste wastes by air.

In the frame of a GEF financed disposal project in Eastern Europe, PCB wastes were however transported by airplane to their final destination in Western Europe. The usual proceeding according to the Basel Convention was undertaken.

Picture 101: PCB waste ready to be transported by air



If this option is seriously considered by a country, detailed investigation with all competent authorities incl. IATA, have to be made.

Furthermore, specific packing instructions have to be followed. The staff in charge of packing, loading and shipping must have attended a special training, and they must have official permission to perform this task (specific approval).

11. Pre-treatment, Treatment and Disposal

To select the most appropriate technology several rateable and non-rateable criteria have to be considered. Among “non-rateable”, or relative criteria, are included public acceptability, risk and environmental impacts, which depend on the specific geographic site location. The rateable criteria may include the applicability of the method (in accordance with its development status), BAT and BEP, already approved technologies, overall cost, resources, minimum achievable concentration, clean-up time required, reliability, maintenance, post treatment cost and ability to use soil after treatment. Furthermore, an Environmental Impact Assessment study shall be carried out to evaluate a technology.

An important requirement of a professional PCBs disposal technology is the destruction efficiency greater than 99.99%. Destruction efficiency (DE) is defined as the total mass of a chemical into a process, minus the mass of the chemical in all products, by-products and environmental releases, divided by the input mass (to give a percentage). This may differ significantly from the other common measure, destruction and removal efficiency (DRE) which only takes into account stack emissions; with no regard for other releases and residues. A process must be able to handle upsets, such as power supply failure, without danger to personnel or equipment. Handling and loading of POPs into the process must always be safe, straightforward and controlled. Equipment and controls must be simple and robust, and will preferably make use of local resources. The operating procedure must be extremely basic and virtually fail-safe. Loading and unloading, start up and shut down must all be straightforward.

The difference between technologies that only separate and/or concentrate a pollutant (e.g. solvent extractions, thermal desorption) and those which destroy the contaminant (e.g. incineration, dechlorination or biodegradation) must be considered. Those technologies that only immobilize contaminants (e.g. landfill systems, stabilization and vitrification) should also be clearly differentiated.

11.1. Technologies and Methods in General

The technologies listed below and presented more in detail in Annexes 12.3-12.6 cover a wide range of degree of treatment and recovery of transformer components, a factor which must be taken into account in comparing technologies. Decontamination is never completely applied to all components, and this means that a residue remains which must be incinerated. In the best case this will be just the porous parts (wood and paper) unless the solvent technique is applied for long process times, and a product finally obtained which may be sent for land filling if the residual PCB levels are legally acceptable. In other words, the total cost of treatment, including the cost of final disposal of residues, must be taken into consideration.

Table 21: Overview Pre-treatment and Non-Combustion Technologies

Autoclaving
Alkali metal reduction (e.g. dechlorination/dehalogenation processes)
Ball milling
Base catalysed decomposition
Catalytic hydrodechlorination
Gase-phase chemical reduction
Plasma Arc
Potassium tert-butoxide method
Pyrolysis / waste-to-gas conversion technology
Supercritical water oxidation

Vitrification
Bio-degradation

Table 22: Overview Combustion Technologies

High-temperature incineration
Co-incineration in cement kilns

„POPs Technology Specification and Data Sheets” providing detailed information on various decontamination/disposal methods are currently being prepared by the Basel Convention Secretariat.

Two sets of factsheets will describe technologies recommended for the destruction or irreversible transformation of waste consisting of, containing or contaminated with POPs. These factsheets will mainly focus on the following destruction technologies:

- Autoclaving
- Alkali metal reduction
- Base catalysed decomposition
- Co-incineration in cement kilns
- Supercritical Water Oxidation
- Thermal Desorption
- Waste-to gas conversion
- Hazardous waste incineration
- Plasma arc

The latest factsheets shall be published on the website of the BRS Secretariat before the COP 2015. At the moment the provisional data sheets can be downloaded at: <http://www.ihpa.info/resources/library/>. For further details on the current status of the factsheets the BRS Secretariat in Geneva can be contacted: brs@brsmeas.org.

Incineration, is the most widely available and used technology for PCB destruction and remains a final solution. Because of the cost-factor of incineration and its non-availability in many countries, alternative technologies are widely used. Some of those technologies have the advantage not only of lower cost, but also of being able to treat economically much lower volumes of waste material.

Co-processing technologies, if not prohibited by national legislation, shall be implemented according to Basel Convention Technical Guidelines on the environmentally sound co-processing of hazardous wastes in cement kilns as well as the relevant national legislation and regulations

Although oil decontamination can be achieved with technologies allowing complete destruction of PCBs, the carcass of transformers and capacitors can present problems because of the presence of a small amount of porous, organic materials which are costly to treat to obtain complete decontamination.

The techniques and the procedures for the decontamination should be appropriately validated and documented, such that it is possible to predict the reduction, elimination and/or decomposition of specific undesired compounds and elements down to the concentration limit required, without potential hazards or unreasonable risk.

The decontamination activities should utilise Best Available Techniques (BAT) and Best Environmental Practices (BEP) to ensure that, throughout the residual life of equipment and insulating liquids, the quality of dielectric performances and the good functional state of the equipment is maintained. Such techniques should also ensure:

- The best operational conditions for decontamination to prevent direct and indirect damage. Prior to performing the operations, an appropriate safety plan should be prepared which evaluates risk and the appropriate corrective actions in the event of problems, failures, fires, uncontrolled spills or emissions into the environment;
- The dielectric quality and the physical and functional features of the insulating liquids in accordance with the relevant Standards and guides;
- The achievement of the objectives set by the decontamination operations, to be checked by measurement of the concentration of PCBs at the end of the decontamination and after

a period of at least 3 months from the re-commissioning of the equipment, under service conditions.

Transport of PCBs and equipment containing PCBs to companies performing decontamination in locations other than the site of installation of the equipment, should comply with all applicable transport and waste regulations, including the use of identification forms for waste and the waste input/output register. For trans-boundary movements, the Basel Convention applies.


Whatever technology is chosen, it has to be performed by a company which is approved for this task by the competent authorities, and the same if the PCB waste is exported, approved by the competent authority in the country concerned.

In December 2004, the United Nations Environment Programme published an updated version of the inventory of worldwide PCB Destruction Capacity. The UNEP also conducted a survey on currently available non-incineration PCB destruction technologies in 2000. Both documents can be downloaded:


http://www.chem.unep.ch/pops/pcb_activities/pcb_dest/PCB_Dest_Cap_SHORT.pdf;

<http://www.chem.unep.ch/Publications/pdf/SurvCurrAvNIncPCBDestrTech.pdf>

Picture 102: Worldwide PCB destruction capacity 2004



Picture 103: Non-incineration PCB technologies 2000



Further UNEP guidance documents as well as training manuals are available from:

http://www.chem.unep.ch/Pops/pcb_activities/default.htm;

<http://www.basel.int/meetings/sbc/workdoc/techdocs.html>

Picture 104: UNEP training manual for Hazardous Waste Project Managers from October 2002



12. Annexes

12.1. In-Depth Information on the Internet: Conventions and Guidance Documents

- Basel Convention
www.basel.int
- Stockholm Convention
www.pops.int
- PEN PCB Elimination Network
www.pops.int/pen/
- Guidance documents on PCBs
<http://chm.pops.int/Implementation/PCBs/DocumentsPublications/tabid/665/Default.aspx>
- Rotterdam Convention
www.pic.int
- UNEP Chemicals, many useful reports can be viewed and downloaded via this website
www.chem.unep.ch
- GPA Global Programme of Action for the Protection of the Marine Environment from Land-based Activities, a lot of useful information
www.gpa.unep.org

Identification of PCB containing capacitors, manual for electricians, very detailed list, Australia, 1997 <http://www.scew.gov.au/sites/www.scew.gov.au/files/resources/378b7018-8f2a-8174-3928-2056b44bf9b0/files/anzecc-gl-identification-pcb-containing-capacitors-information-booklet-electricians-and-electrical.pdf>

Guidelines for the Identification of PCBs and Materials Containing PCBs, UNEP 1999
<http://www.pops.int/documents/guidance/nipsfinal/pcb1.pdf>
- GEF - Global Environment Facility
www.gefweb.org
- UNITAR - United Nations Institute for Training & Research
www.unitar.org
- UNIDO – United Nations Industrial Development Organization
www.unido.org
- Recommendations on the Transport of Dangerous Goods – Model Regulations
http://www.unece.org/trans/danger/publi/unrec/rev16/16files_e.html
- International Chemical Safety Cards
<http://www.cdc.gov/niosh/ipcs/icstart.html#language>
- Minamata Convention
<http://www.mercuryconvention.org/>
- SAICM – Strategic Approach to International Chemicals Management
<http://www.saicm.org/>
- REACH – Registration, Evaluation, Authorisation and Restriction of Chemicals
http://ec.europa.eu/enterprise/sectors/chemicals/reach/index_en.htm

Please note that many documents and publications are under revision. Therefore please check the actualities in the World Wide Web periodically.

Guidance documents for identification, management and destruction of PCB

- Destruction and decontamination technologies for PCBs and other POPs wastes under the Basel Convention. A training manual for hazardous waste project managers Secretariat of the Basel Convention
<http://archive.basel.int/meetings/sbc/workdoc/TM-A.pdf>
<http://archive.basel.int/meetings/sbc/workdoc/TM-B.pdf>
- Guidelines for the identification of PCBs and materials containing PCBs
UNEP Chemicals
<http://www.chem.unep.ch/Publications/pdf/GuidIdPCB.pdf>
- Inventory of World-wide PCB Destruction Capacity
UNEP Chemicals
http://www.chem.unep.ch/pops/pcb_activities/pcb_dest/PCB_Dest_Cap_SHORT.pdf
- PCB Transformers and Capacitors - From Management to Reclassification and Disposal
UNEP Chemicals
<http://www.chem.unep.ch/Publications/pdf/PCBtranscap.pdf>
- Provisional POPs Technology Specification and Data Sheets
Secretariat of the Basel Convention
<http://www.ihpa.info/library/2009/08/02/pops-technology-specification-and-data-sheets/>
- Selection of Persistent Organic Pollutant Disposal Technology for the Global Environment Facility
A STAP advisory document
<http://www.thegef.org/gef/pubs/STAP/selection-persistent-organic-pollutant-disposal-technology-gef>
- Survey of Currently Available Non-Incineration PCB Destruction Technologies
UNEP Chemicals
<http://www.chem.unep.ch/Publications/pdf/SurvCurrAvNIncPCBDestrTech.pdf>
- Updated general technical guidelines for the environmentally sound management of wastes consisting of, containing or contaminated with persistent organic pollutants (POPs)
Basel Convention
http://chm.pops.int/Portals/0/flash/pops wastetrainingtool/eng/All_technical_guidelines_on_POPs_4.pdf
- Updated technical guidelines for the environmentally sound management of wastes consisting of, containing or contaminated with polychlorinated biphenyls (PCBs), polychlorinated terphenyls (PCTs) or polybrominated biphenyls (PBBs)
Basel Convention
<http://archive.basel.int/pub/techguid/tg-PCBs.pdf>
- Draft guidelines on best available techniques and provisional guidance on best environmental practices relevant to Article 5 and Annex C Stockholm Convention
http://www.pops.int/documents/guidance/batbep/batbepguide_en.pdf

Please note that many documents and publications are under revision. Therefore please check the actualities in the World Wide Web periodically.

12.2. Detection Kits and Other Instruments

Clor-N-Oil (oil samples) and Clor-N-Soil (soil samples)

This kit can test transformer oil for PCB presence. This test uses a colour charge to indicate the presence of chlorine and therefore the likely presence of PCBs. This detection kit can be obtained from the Dexsil Corporation. For more information the manufacturer may be reached at:

Dexsil Corporation	Phone: +1 203 288 3509
One Hamden Park Drive	Fax: +1 203 248 6523
Hamden, Connecticut 06517	E-mail: info@dexsil.com
USA	Internet: www.dexsil.com

L2000 PCB/Chloride Analyser (oil, soil, water and surface wipe samples)

This kit is designed to be used in the field to test for PCBs in soil, transformer oil, water, and on surfaces. The test first react the sample with a reagent that strips all chlorine from the organic molecule. Then a chloride specific electrode determines PCB concentration in the reacted sample. For more information the manufacturer may be reached at:

Dexsil Corporation	Phone: +1 203 288 3509
One Hamden Park Drive	Fax: +1 203 248 6523
Hamden, Connecticut 06517	E-mail: info@dexsil.com
USA	Internet: www.dexsil.com

DR/800 Series Colorimeters (water samples)

This is a small colorimeter that can check for PCBs (chloride) in water. It is designed for field use. For more information the manufacturer may be reached at:

Hach Company	Phone: +1 970 669 3050
P.O. Box 389	Fax: +1 970 669 2932
Loveland, Colorado 80539-0389	E-mail: csays@hach.com
USA	Internet: www.hach.com

DR/4000 UV-VIS Spectrophotometer (water samples)

This kit can perform water quality analysis. This spectrophotometer allows for both manual and sipper testing. It comes pre-programmed with 130 Hach methods of analysis but it can be programmed to perform other water quality analyses as well. For more information the manufacturer may be reached at:

Hach Company	Phone: +1 970 669 3050
P.O. Box 389	Fax: +1 970 669 2932
Loveland, Colorado 80539-0389	E-mail: csays@hach.com
USA	Internet: www.hach.com

12.3. PCB Pre-Treatment Technologies (Extract only)

Transformers are drained in a first step. The liquids will be disposed of separately. The “empty” transformer still contains approx. 3 to 10 % liquid. 10 % is related to Askarel because of the higher density. Additionally, the content of wood, paper etc. is responsible for the remaining liquid. Separate treatment is necessary for transformers. “Pure” PCB transformers cannot be cleaned economically for re-use. The same applies to all other devices that contain “pure” PCB.

Thus transformers need specific treatment. In case of Askarel transformers, solvent extraction is a possibility. Some companies put the core into an autoclave and extract PCB by solvent and vacuum. Empty carcasses are cleaned the same way. Alternatively, the transformer itself can be used as autoclave, and solvent is circulated through the empty transformer. In both cases the solvent is re-distilled, and the PCBs are exported to be incinerated. Various studies have shown that only solvent can remove Askarel from non-porous materials. The use of unchlorinated solvents would be more ecological, their low flashpoint, however, increases the inflammability risk. Therefore, chlorinated solvents like Perchloroethylene are used. Special attention must be paid to the potentially occurring emissions.

After these cleaning processes transformer coils are carefully disassembled. Porous parts still do contain PCB in the interior parts, and are packed into suitable packaging for final disposal at licensed facilities. Even after that pre-treatment by solvent, PCBs are still present the winding and between the core sheets. Therefore, core sheets and winding require additional cleaning processes in specific washing machineries using again solvent. After that procedure random samples must be taken in order to check the success of the process. If all metal parts are PCB-free they can be sold as secondary raw material.

12.4. PCB Non-Combustion Technologies

Dechlorination in general: Chemical dechlorination is based on reactions with either an organically bound alkali metal or an alkali metal oxide or hydroxide. Dechlorination processes are well developed for the treatment of liquid PCBs and PCB contaminated oil. The chlorine content is converted to inorganic salts which can be removed from the organic fraction by filtration. Reactions take place under inert atmosphere. Some companies provide mobile treatment plants, which can be used on an operating transformer in the field. There are several types of this technology available. Two suppliers of dechlorination technologies, and their processes are briefly described below:

Continuous Dehalogenation Process (CDP)

The CDP Process®, developed and patented by Sea Marconi, is a process capable of detoxifying and dehalogenating the PCBs present both in the oil and the inner parts of the transformer **on-site**, in continuous mode and closed circuit, with circulation of warm oil, with an efficiency of 99.9 %, in accordance with European Directive 59/96. The Decontamination Mobile Units (D5MU) used for the process designed and developed by Sea Marconi implement innovative technologies and unique environmental protection systems, to ensure safe working conditions. The D5MU are modular, thus they can operate in all logistic scenarios and thanks to specially developed ad-hoc protocols, they can also operate on energized and under load transformers.

SDMI Oil Dechlorination Process

The process developed by SD Myers (<http://sdmyers.com/pcb-dechlorination.html>) is very specific in the scheduled wastes it is able to treat, as it is designed to treat PCB contaminated transformer oils with concentrations below 10'000 mg/kg without the need to remove the transformer or take the transformer out of service. Concentrations below 2 ppm are achievable. It involves circulating the transformer fluid through a filtration system until the residual PCB concentrations are below those required. The continued circulation of the fluid through the transformer largely flushes the PCBs from the transformer windings and other internal components. The treated oil is then suitable for continued use. Leaching from the porous parts of the transformer such as wood and paper insulation can occur and the transformer may require another treatment after some time.

A general overview of non-combustion technologies is given in the next paragraphs:

Alkali metal reduction: Alkali metal reduction involves the treatment of wastes with dispersed alkali metal. Alkali metals react with chlorine in halogenated waste to produce salts and non-halogenated waste. Typically, the process operates at atmospheric pressure and temperatures between 60°C and 180°C. Treatment can take place either in situ (e.g. PCB-contaminated transformers) or ex situ in a reaction vessel.

There are several variations of this process. Although potassium and potassium-sodium alloy have been used, metallic sodium is the most commonly used reducing agent. *[Technical Guideline, Basel Convention]*. Sodium- and ammonium reduction technologies are capable for any kind of contamination of PCB, but not economical at higher level. The maximum economical level of PCB varies between 2'000 to 5'000 mg/kg PCB. The technologies have been widely used in Canada, USA and Europe for treatment of PCB-contaminated transformer oil. One of the advantages is that the oil after further treatment can be reused. There are several providers of the technology around the globe. The ammonium technology is comparable to sodium technology but rather seldom and not easy to handle.

Ball milling: This is an interesting new technology where a ball mill is used with excess CaO resulting in decomposition of chlorinated compounds. Reports show high destruction efficiencies for individual chemicals. However, the method is still in development stage and there is a lack of independent emission statistics. The operating costs may be high due to the amount of CaO and electricity needed in the process.

Base catalysed decomposition (BCD): The BCD process involves treatment of wastes in the presence of a reagent mixture consisting of hydrogen-donor oil, alkali metal hydroxide and a proprietary catalyst. When the mixture is heated to above 300°C, the reagent produces highly reactive atomic hydrogen. The atomic hydrogen reacts with the waste to remove constituents that confer the toxicity to compounds. *[Technical Guideline, Basel Convention]*.

The BCD process is limited to a certain PCB content, which however is above 10'000 ppm. BCD has been used at two commercial operations within Australia, with one still operating. Most recent experiences have been gained at one of the largest Dioxin sites in the world, the Spolana Site in Czech Republic, where tens of thousands of tons of contaminated soils and several thousands of tons of 50 % chlorine pesticides, etc. have been treated. Thanks to these experiences in Spolana, BCD units have been improved in such a way that up to 1000 t/y of high chlorine content PCBs or pesticides (50%) can now be treated in a single line.

Catalytic hydrodechlorination (CHD): CHD involves the treatment of wastes with hydrogen gas and palladium on carbon (Pd/C) catalyst dispersed in paraffin oil. Hydrogen reacts with chlorine in halogenated waste to produce hydrogen chloride (HCl) and non-halogenated waste. In the case of PCBs, biphenyl is the main product. The process operates at atmospheric pressure and temperatures between 180°C and 260°C. *[Technical Guideline, Basel Convention]*

In Japan the CHD technology is implemented by JESCO (Japan Environmental Safety Corporation) which is a special company wholly owned by the government, established in 2004. JESCO's mission is to construct and operate five regional facilities to treat PCBs wastes in Japan, and one of them is the CHD Osaka PCB Waste Treatment Facility. The Japanese plant can treat up to 100% PCBs and is also combined with units to clean PCB transformers: Solvent Cleansing Method and the Vacuum Heating Separation Method. An interesting option is the CHD technology implemented by Hydrodec, which has treatment facilities in Young, NSW, Australia, and Canton, Ohio, USA. They transform used oil into a high quality naphthenic based transformer oil or base oil called SUPERFINE™. The plant in Ohio, can treat low level PCB-contaminated transformer oil up to 49 ppm, (EPA permit for up to 2,000 ppm pending approval) (<http://www.hydrodec.com/product-and-services/north-america/used-oil-collection-and-treatment>).

In 2011, the company started a joint-venture with Kobelco Eco-Solutions. It is planned to set up the first plant in Japan during the second half of 2012.

Gas-phase chemical reduction (GPCR): The GPCR process involves the thermochemical reduction of organic compounds. At temperatures greater than 850°C and at low pressures, hydrogen reacts with chlorinated organic compounds to yield primarily methane and hydrogen chloride. [Technical Guideline, Basel Convention]. All PCBs from Western Australia were treated by GPCR in the 2000s. No commercial facility is in operation today, the methodology is rather expensive.

Plasma Arc: The Plascon™ process uses a plasma arc with temperatures in excess of 3,000° C to pyrolyse wastes. Together with argon, wastes are injected directly into the plasma arc. The high temperature causes compounds to dissociate into their elemental ions and atoms. Recombination occurs in a cooler area of the reaction chamber, followed by a quench, resulting in the formation of simple molecules. [Technical Guideline, Basel Convention]. This technology can destroy up to the highest level of PCB with an efficiency of 99.99999 %. The plasma arc technology is used regionally on a commercial basis but is rather low in capacity. Due to the extreme high temperature the disposal costs are very high. Installations are small with standard units (each unit 150kW) and can be used as mobile or as fixed plants. A PLASCON® plant can destroy pure PCBs at a rate of 35 to 40 kg/h (<http://www.plascon.com.au/destruction-of-pcbs.html>). In January 2011 there were 10 commercial plants operating with licenses from the Victorian and Queensland EPAs in Australia, the UK EPA, the US EPA, the Mexican EPA, and the Japanese Ministry of the Environment. 4 commercial 150 kW “in-flight” plasma arc units are operating in Australia. 2 units were installed at Nufarm Ltd (Pesticides producer).

Potassium tert-butoxide method: PCBs in insulating oils are dechlorinated by reaction with potassium tert-butoxide (t-BuOK). It reacts with chlorine in PCBs to produce salt and non-chlorinated waste. Typically, the process operates at atmospheric pressure and temperatures between 200°- 240°C. [Technical Guideline, Basel Convention]. (up to now only implemented in Japan).

Pyrolysis / waste-to-gas conversion technology: The process is a gasification pre-treatment and treatment technology for the recovery of hydrocarbon-containing waste operating at high temperatures (1300°C–2000°C) and high pressure (about 25 bar) using steam and pure oxygen in a reducing atmosphere. All hydrocarbon molecules in the waste are irreversibly cleft into small gaseous molecules such as hydrogen (H₂) and carbon monoxide (CO), methane (CH₄) and carbon dioxide (CO₂). Short-chain hydrocarbons such as ethane (C₂H₆), propane (C₃H₈) and butane (C₄H₁₀) and other compounds are produced in small amounts (< 1 vol. %). PCBs contained in the waste are effectively destroyed. The resulting raw gas is subsequently converted in a multistage process to pure synthesis gas for the production of highest-grade methanol. [Technical Guideline, Basel Convention] There was only one plant in the world using this technology, Schwarze Pumpe, Germany, which, however, was already closed some years ago.

Supercritical water oxidation: SCWO and subcritical water oxidation treat wastes in an enclosed system using an oxidant (such as oxygen, hydrogen peroxide, nitrite, nitrate, etc.) in water at temperatures and pressures above the critical point of water (374°C and 218 atmospheres) and below subcritical conditions (370°C and 262 atmospheres). Under these conditions, organic materials become highly soluble in water and are oxidized to produce carbon dioxide, water and inorganic acids or salts. [Technical Guideline, Basel Convention]. At present the largest SCWO plant (10 000 t/y) in the world is under construction in the US for the destruction of Chemical Warfare agents (ACWA programme).

Vitrification (Geomelt): This technology has been widely applied for remediation of PCBs in soil. The process works by establishing a melt between pairs of electrodes inserted into the soil-bound waste materials. This treatment of PCB containing equipment and oil can only be recommended under certain specific conditions.

Bio-degradation: The bio-degradation is very limited in the contamination level and can be excluded for treatment of PCB-containing equipment and oil. From experience we know, however, that Bio-degradation can be considered for treatment of low-contaminated soils.

12.5. PCB Combustion Technologies

High-temperature incineration is the most common technology for destruction of waste with high PCB content in Europe and North America. Modern incinerators have an efficiency of at least 99.99999 % for highest levels of PCB. In order to reach this destruction efficiency the incinerators operates at temperatures higher than 1,100 °C, with a residence time greater than 2 seconds, under conditions that assure appropriate mixing. The disposal costs are in general lower for waste with high content PCB than for the other disposal methods. In some countries public resistance against hazardous waste incineration has led to the development of different non-incineration technologies although the disposal costs may be higher for these technologies. The formation of dioxins and furans by the incineration has been one of the main concerns. If high temperature incineration is used the incinerator should meet a limit value for emission of dioxins and furans of <0.1 ng I-TEQ/Nm³ at 11% O₂. Most incinerators are large stationary facilities but in some countries e.g. Canada also small mobile incinerators are operating on a commercial basis. Their capacities are low compared to the stationary ones.

High temperature incineration is the main solution in Europe for “pure” PCB. Various incinerators guarantee extreme low emissions. The incinerators can accept all types of PCB waste that can either be pumped (liquids) or packed into drums. PCBs in drums are fed into the incinerator kiln by elevator. Liquids are usually pumped from storage tank through injectors into the kiln. Transformers have to be dismantled prior to disposal, due to their size.

Co-incineration in cement kilns: The co-incineration of PCB containing liquids is usually limited to the range of 50 to 1,000 ppm PCB in the oil. Higher levels of chlorine would have negative impact to the quality of cement. As rule of thumb, chlorine should usually be limited to 300 to 500 g/t cement clinker for a kiln without by-pass and 400 to 750 g/t for a kiln with by-pass, but the chlorine tolerance must be known in each instance. It is important that the process owner knows the chlorine tolerance of the process in question. Additionally, the co-incineration requires proper flue gas cleaning systems.

A number of tests of PCB destruction have demonstrated that the PCB can be satisfactorily destructed in the kilns, but large scale use of cement kilns for destruction of PCBs has not been reported from developing countries. If cement kilns are used to incinerate wastes, the standards of the applicable regulations have to be met. One can refer to the regulation 94/67/EG of the European Council on the incineration of toxic wastes.

12.6. PCB Emerging Technologies

There are a number of emerging technologies, which are not presented in the frame of this handbook. There is a GEF supported “review of emerging, innovative technologies for the destruction and decontamination of POPs and the identification of promising technologies for the use in developing countries” available in the internet:

http://www.chem.unep.ch/pops/pcb_activities/PCB_proceeding/Presentations/PCB%20Global%20McDowall.pdf
and
http://www.chem.unep.ch/Pops/pcb_activities/default.htm#Guidance

12.7. PCB Treatment and PCB Disposal Companies

Enterprises from all around the world are listed under the following link:

http://www.chem.unep.ch/pops/pcb_activities/questionnaire/default.htm

Please note that some websites might be archived in March 2015. Please check periodically the WWW about new publications and downloads.

12.8. Emergency Response Plan for Cold Incidents

The following table shows the measures to be taken in case of PCB incidents. For each nature of spill the order of the actions to be taken is indicated by the numbers.








Emergency Response for Cold PCB Incidents				
	Nature of spill			
	Leakage into containment system	Spill on concrete and asphalt	Spill on soil	Spill into water
Notify plant personnel, chemical response and competent authorities	1	1	1	1
Inform responsible doctor and put on adequate Personal Protective Equipment (avoid personal contamination!)	2	2	2	2
Prevent people and/or vehicles from entering the contaminated areas	3	3	3	3
If applicable: Disconnect the concerned equipment from power Check earthing	4	4		
Plug or dike all drains to sewers and ditches, use absorbents (sand, cement)		5	4	
Stop source: Seal leak by using appropriate materials, place drip-tray under leak	5	6	5	4
Spill confinement: Build dikes to contain PCB in small area		7	6	
Cover with plastic to minimize runoff from rain		8	7	
Dam area if possible, and close off to vessels in navigable water				5
Confine contaminated area, Erect tent with compartments	6	9	8	
Use pump to transfer PCBs into drums, Soak up PCB with absorbents	7	10	9	6
Use dredges to collect the contaminated soil / sediment			10	7
Repeated solvent scrub process followed by a sorbent clean-up	8	11		
Take core sample to determine remaining contamination		12 (2,5 cm depth)	11 (60 cm depth)	
Break off contaminated concrete		13		
Pack wastes according to ADR and dispose as hazardous waste	9	14	12	8
Monitor wells and other bodies of water in the vicinity for PCB contamination			13	

12.9. Emergency Response Plan for Hot Incidents

The following table shows the measures to be taken in case of PCB incidents. For each nature of spill the order of the actions to be taken is indicated by the numbers.

Emergency Response for Hot PCB Incidents			
	Nature of Incident		
	Internal failure No bursting of equipment	Internal failure of capacitor Bursting of equipment with spill	Fire in vicinity of equipment
		Beware of highly toxic furans!	Beware of highly toxic furans and dioxins!
Notify fire brigades			1
Notify plant personnel, chemical response and competent authorities		1	2
Inform responsible doctor and put on adequate Personal Protective Equipment (respiration mask!)		2	3
Prevent people from entering the contaminated areas		3	4
Disconnect the concerned equipment from power	1	4	5
Phase out equipment	2		
Evacuate and close the building, cut out air circulation by plugging vents		5	6
Stop source: Seal leak with appropriate materials, place drip-tray under leak		6	
Confine contaminated area		7	7
If not protected by a heavy protective overall keep clear from danger zone, Let the specialists extinguish the fire			8
Erect tent with compartments		8	9
Repeated solvent scrub process followed by a sorbent clean-up		9	10
Take core sample to determine penetration		10 (2,5 cm deep)	11 (60 cm deep)
Take wipe samples for dioxin			12
Break off contaminated concrete		11	13
Use dredges to collect the contaminated soil / sediment		12	14
Pack wastes according to ADR and dispose as hazardous waste	3	13	15

12.10. Best Working Practices

<h3>Best Working Practices</h3>	
When performing light repair or maintenance work with PCB-containing equipment, the following safety precautions for the protection of the employees and the environment have to be followed:	
	Direct contact of PCB-contaminated materials with the skin and eyes has to be absolutely avoided by wearing gloves and safety goggles. According to the type of the work performed, protection clothing and a respiratory mask has also to be put to the workers disposal.
	
	The working area has to be adequately ventilated.
	Spills have to be prevented in every case by use of drip trays or adequate plastic tarps.
	Every contact of PCBs with a flame or any other heat source over 300°C has to be absolutely avoided (risk of highly toxic dioxines and furanes).
	All used tools and other working materials, which got in contact with PCBs, have to be disposed of as PCB-containing waste in a environmentally sound manner or otherwise have to be decontaminated. The only suitable materials to be decontaminated with an appropriate solvent (technical acetone) are steel, glass and ceramics.
	Operations which involve decanting, rewinding of coil, etc. must only be performed by companies approved for this task by the competent authorities.

12.11. PCB Instructions for Workers

The below instruction card shall be regarded as an adequate example of PCB instructions for workers and emergency cases. However, the information and pictograms may change.

Instruction No. 03/2010 | Company:
Acc. §14 Ordinance on Hazardous Substances
Building site/Work:

Printdate:



Polychlorierte Biphenyle PCB are suspected of causing cancer!



Hazards for human health and the environment

Breathing in, swallowing or absorption through the skin may result in health damage. May cause irritation (respiratory tract, eyes, skin, organs of digestion). Temporary complaints (dizziness, fatigue, nausea, loss of appetite) are possible. Can cause acne, digestive disorders, liver damage, blood picture changes, mood disorders. Carcinogenic effect is suspected. PCB can affect reproductive fertility. PCB can be injurious to the unborn child. Reichert sich im Körper an! Beim Erhitzen oder Verbrennen können sehr giftige Dioxine und Furane entstehen.
Hazardous to water - avoid ingress into the ground, water and sewage!

Protective measures and behaviour rules

Ensure a fresh air supply when working! In the event of vapours, work only with exhaust ventilation! Nicht mit Feuer, offenen Flammen oder heißen Metallteilen in Berührung bringen! Do not leave vessels open! Avoid splashes! Do not mix with other products or chemicals! Avoid contact with eyes, skin and clothing! Preventive skin protection necessary. Thoroughly clean hands and face after completing work and before every work break! Use skin care agent! Store street clothing separately from work clothing! Change clothing after completing work! Change soiled clothing!

Observe restrictions on activity!

Eye protection: Full protection goggles!

Hand protection: Gloves made of: fluororubber.

It is advisable to wear cotton gloves underneath protective gloves.

Breathing protection: The use of A2-P3 (braun-weiß) is recommended.

In pits, shafts and silos, only use ambient air-independent breathing apparatus!

Skin protection: Use grease-free skin protection ointment for all uncovered parts of the body:

Body protection: (Disposable) chemical protective suit and plastic boots. Bei Bedarf partikeldichte Schutzkleidung!



Behaviour in danger situations

Collect and dispose of with absorbent non-combustible material (e.g. kieselguhr, sand)! Evacuate the workplace if large quantities should leak! Remove only after applying persönlicher Schutzausrüstung! Product is not combustible. In the event of a fire in the environment, cool the receptacle with sprayed water! Hazardous vapours are produced in the event of fire! Only fight larger fires using self-contained breathing equipment and suitable protective equipment!

Responsible physician or clinic:

Accident phone:

First Aid

During all First Aid assistance: protect yourself and immediately inform a doctor.

After eye contact: Rinse for 10 minutes with water or with eye-wash solution.

After skin contact: Take off soiled clothing immediately. Clean with abundant amounts of water and soap. No thinners!

After breathing in: Fresh air. Keep airways clear: remove false teeth, vomit etc.. If breathing or heartbeat stops: immediately apply artificial respiration and heart massage.

After swallowing: Do not cause vomiting. If conscious, see that plenty of water is drunk a little at a time. No domestic agents.

First Aid specialist:



Proper disposal

Do not pour into the sewage or a refuse bin!

Product residues:

For disposal, collect in:

12.12. First Aid in Case of Contact with PCBs

Table 23: First Aid Measures

Kind of Exposure	Measure
➤ Liquid PCB on the skin	➤ Use water and soap to wash thoroughly
➤ Liquid PCB in the eyes	➤ Rinse eyes with lukewarm jets of water for 15 minutes, always keeping eyes wide open
➤ Liquid PCB in the mouth and in the stomach	➤ Rinse mouth with water, do not drink anything else, see doctor immediately
➤ Highly concentrated vapors of PCB	➤ Take affected people outside in the open air

12.13. Guidelines for the Inspection of Sites and the Sampling of Transformers and Capacitors (two persons)

The Field Teams for the identification of PCB equipment comprise of three members. The inspector as official authority will monitor the process of sampling and ensure the quality of the inventory process.

Field Team Member 1		Field Team Member 2
Unlock the door/gate to the room with capacitors	1	
Locate capacitors, read the producer's plate	2	Fill in the inventory form for the capacitor and in the upper right space copy the number from the label
Read each line of the producer's plate	3	Fill in the necessary data from the producer's plate, line by line
Measure the capacitors' dimensions	4	Write down the dimensions of the capacitors
Prepare the label for capacitors and affix it on a clean and accessible place on the capacitor (example: 10404)	5	
Take picture of the capacitor	7	
Check if there is any leakage or damage on the capacitor	8	Note down in the inventory form where the leakage or damage has been detected on the capacitor
Lock the room with capacitors	9	
Unlock the door/gate to the room with transformers	10	
Locate transformers, read the producer's plate	11	Fill in the inventory form for the transformer and in the upper right space copy the number from the label
Read each line of the producer's plate	12	Fill in the necessary data from the producer's plate, line by line
Take sample of transformer oil	13	
Affix sampling label on transformer, sampling vial, and write it on the inventory form	14	Check if there is any leakage or damage on the transformer
	15	Take picture of the transformer (if there are any leakages, damages, corrosion)
Dispose the sampling materials (pipettes, adsorbent pads, gloves) in plastic bags that will later be stored in barrels and containers for that purpose.	16	Note down in the inventory form where the leakage or damage has been detected on the transformer
Lock the room with transformers	17	

12.14. Draft Inventory Questionnaires

There are a number of inventory questionnaire proposals, amongst them also the initial UNEP proposal from 2002, see e.g. on this site:

<http://www.google.ch/url?sa=t&rct=j&q=&esrc=s&source=web&cd=1&ved=0CB4QFjAA&url=http%3A%2F%2Fwww.pops.int%2Fdocuments%2Fguidance%2FPCBinvform.doc&ei=bnb1VMaJFYvnUr6xgtAK&usg=AFQjCNE8mfNujwIGZxuycEuZbNle2lg99g&sig2=yuimZwcO4WVxExE39Y7ZLejQ>

It is recommended that countries design their own country-tailored questionnaires, based on the UNEP recommendation respectively the BRSMEAS Guidelines and respective experiences.

Below and until page 99, there are some draft forms based on the initial UNEP Questionnaire which have been used in many countries as a basis for the PCB Assessment.

Often these forms have been used at the same time as sampling reports.

Form A:

Information about the company, site and equipment which contains / is contaminated with PCB

№	Information about the company, site and equipment which contains / is contaminated with PCB	
1	Name:	
2	Address:	
3	Address of site:	
4	Phone :	
	Fax:	
	E-mail:	
5	Name/Position of contact person:	
6	Type of company / industry type/ production at specific site:	
7	Public or private company?	
8	Location: Industrial zone	
	Urban area	
	Rural area	
9	Number of personnel: >50	
	10-50	
	<10	
10	Total number of pieces of equipment at site: Transformers	
	Capacitors	
	Others	

Form B:

Information related to the potentially PCB containing equipment

Oil-filled Equipment Inventory Form
(to be filled for each piece of equipment)

Oil-filled Equipment Inventory Form			
1	Name of the equipment		
2	Individual Identification Number (IIN) of the equipment		
3	Type and trademark of the equipment		
4	Serial number		
5	Manufacturer and country of origin		
6	Location of equipment		
7	Maximum permissible power capacity		
8	Year of production		
9	Physical parameters:	Total weight (kg)	
		Volume/weight of oil (liters or kg)	
		Equipment (dry weight, kg)	
		Dimensions of equipment (length, width, height, m)	
10	Oil trademark		
11	Does the oil contain PCB?		
12	How did you identify the oil as PCB-containing or PCB-free?		
13	Operational status	In service	
		Stand-by	
		Decommissioned	
14	Condition of the equipment	Any leakages detected?	
		Is the floor under equipment (concrete, soil) contaminated?	
		Any external evidence of the equipment damage (corrosion, cracks etc.)?	
		Storage situation (e.g. open air, in a workshop etc.).	

15	Service, maintenance and care; current repair of the equipment.	What company provides equipment maintenance services?	
		Type of oil used for refilling?	
		Fluid replaced? If yes, when was the last replacement done?	
		What company replaced the fluid?	
		What was the trademark of replacement insulation fluid or oil? (Name in original language)	
Name, position of person in charge and executor, signature, date			
16	Person in charge:	_____	_____
		Signature	Date
17	Executor:	_____	_____
		Signature	Date

Form C:

Information on wastes liable to contain PCB

C Information on wastes liable to contain PCB			
1	Nature of the wastes (e.g., transformer oil in drums or reservoirs)		
2	Estimated quantity		
3	Are containers leak-proof?		
4	Is the place of storage clearly marked to show the presence of PCB?		
5	Have soil or buildings been contaminated by leaking PCB? (indicate magnitude of problem if possible, e.g. tonnes or cubic metres of contaminated soil)		
6	Brief history of any previous remediation efforts, e.g., removal of PCB-containing equipment and waste PCB for disposal (when, by whom, where to, etc.)		
7	Other relevant information (e.g., results of any sampling and analysis already undertaken)		
8	Fill in:	Name and surname	Signature
			Date

12.14.1. Preliminary Inventory Form used in the Regional Pilot Project

Preliminary Inventory form of PCBs

General Data			
1	Inventory record No.		
2	Date		
3	Inspector name		
4	Name of establishment		
5	Address, phone, mail, fax		
6	Name of managing head		
7	Position GPS		
8	Land use classification	<ul style="list-style-type: none"> • Urban • Industrial • Rural 	
9	Industry Classification		
	Code		
	Description	<ul style="list-style-type: none"> • Manufacturing • Service • Transport • Commercial • Utilities • Other (<i>please specify</i>) 	
10	Potential Receptors	<ul style="list-style-type: none"> • School • Hospital • Commercial Buildings • Storage of Flammable Material • Other (<i>please specify</i>) 	km
	<i>Indicate distance (in kilometers) for each applicable receptor.</i>		km
			km
			km
			km
Analysis			
11	Sampling No.		
12	Date of sampling		
13	Density test*	Positive	
		Negative	
		No test	
14	Chlorine test	< 50 ppm	
		> 50 ppm	
		No test	
15	Chlorine concentration ppm		
16	PCB concentration ppm		
17	Name of laboratory		
18	Laboratory recognition/ accreditation number		

*only in case of emergency

** : if applicable

Preliminary Identification of PCBs

Technical Data			
19	Serial number		
20	Type of equipment/ appliance/ packing	• Transformer	
		• Capacitor	
		• Circuit breaker	
		• Drum containing liquid	
		• Drum containing solid	
		• Contaminated soil associated to the equipment	
21	Operational Status of equipment	• Others, please specify	
		• In use	
		• Out of use	
		• Stand by	
		• In storage area	
22	Manufacturer name list no**	• Ready for decommissioning	
23	Dielectric name list no**		
24	Power [KVA] (KVAR) **		
25	Year of manufacture **		
26	Year of installation on site **		
27	Total weight **		
28	Weight of dielectric oil **		
29	Filling level **	• Full	
		• Half	
		• Empty	
30	Leaking of appliance	• Top	
		• Middle	
		• Bottom	
		• No leaking	
31	Corrosion on the appliance	• Top	
		• Middle	
		• Bottom	
		• No corrosion	
32	Refilling**	Yes, indicate when	
		No	
33	Any nearby flammable material?	If Yes give the chemical or technical name	Estimate distance from PCB appliance
		No	km
			km

Please stick here the label of the sample.

*only in case of emergency

** : if applicable

12.15. Example of a Possible Register

Ord. No	Type of equipment	Trade-mark	IIN	Manufacturer	Year of production	PCB tested	Total Weight kg	Oil Weight kg	Location	Operation status	Condition	Maintenance and servicing data	Maintenance organization (contact info)
1	Transformer	TM	TC-301	Kentau Transformer Plant	1995	PCB-Free (L2000 Screening)	2500	800	Workshop No 1	In service	Satisfactory	Regular topping up	Iskra Ltd., Kokshetau, Abay str. 2
2	Transformer	TH	TH - 121	Chirchick Transformer plant	1967	PCB-contaminated 486 mg/kg by L2000 & GC Verification	4530	1800	Transformer substation TIIС-010	Phased out	There are oil leaks	Maintenance by Iskra Ltd/	Iskra Ltd., Kokshetau, Abay str. 2
3	Transformer	TON 394/22	THII - 222	Poland	1976	PCB-containing pure PCB (nametag)	2800	1200	Transformer substation	In service	Satisfactory	Regular topping up and gasket replacement in 2004 .	Iskra Ltd., Kokshetau, Abay str. 2
4	Capacitor	KCK2-1,05-125-2Y	KC - 089	Ust-Kamenogorsk capacitor plant	1985	no testing yet	58	15	Capacitor substation	In backup	Burnt	No maintenance	Iskra Ltd., Kokshetau, Abay str. 2

12.16. PCB Equipment Monthly Maintenance Plan

Place: _____

Date: _____

No.	Item for inspection	Compliant		Observation	Corrective action
		Yes	No		
PCB Transformers					
1.	Inventory number				
2.	Condition of gauges				
3.	Reading of gauges				
4.	Corrosion on tanks and radiator fins				
5.	Paint finish of tank and radiator fins				
6.	PCB leakage from: <ul style="list-style-type: none"> • tank • radiator fins • top cover • manhole cover • top or bottom drain spout • high and low voltage bushings 				
7.	Pressure relief valve				
8.	Drain valve				
9.	High and low voltage bushings				
10.	Color of PCB oil				
11.	Electrical and chemical tests to indicate the physical and electrical properties (dielectric test, power factor test, acidity test, interfacial test) (to be tested yearly)				
12.	Driers (silica gel) state				
13.	Abnormal vibration and noise				
PCB Capacitors					
14.	Inventory number				
15.	Corrosion on casing				
16.	Physical damage				
17.	Leakage of PCB oil				
18.	Melted fuses				
19.	Temperature of capacitor casing				
20.	Bulging				
21.	Bursting				
22.	Repairing and servicing operations, if any				
23.	Was PCB equipment repaired on or off-site (if off-site, state the servicing and transport company)				

Completed By: _____

Contact Phone: _____

12.17. PCB Interim Storage Facility Monthly Inspection Report

Overview: The competent authority is required to inspect the institutions' PCB storage site on a monthly basis. This inspection is completed by a qualified individual, recorded below, and forwarded to the environmental authorities.

Place: _____ **Date:** _____

No.	Question	Yes	No
1	Signage is posted on the exterior of the PCB storage areas and storage areas are secure and only accessible to authorized personnel.		
2	PCB equipment and drums of PCB material are stored in a manner that makes them accessible for inspection and that protects them from catching fire or being released.		
3	PCB storage site is in good condition, including:		
	• Floors		
	• Curbing		
	• Sides		
	• Drains (if present)		
	• Weatherproof roofs		
	• Fences and walls		
4	Indoor PCB storage sites are equipped with, where practical, an appropriate fire suppression system and alarm system to adequately address the quantities of PCBs stored on site.		
5	Has the fire extinguisher been inspected within the last month? Is it in working condition?		
6	Where PCB equipment that is not in a container (other than drained PCB equipment) and contains PCB liquids, is stored on a floor of steel, concrete or any other similar durable material that is capable of absorbing any PCB liquid. The concrete floor and sides are sealed with an impervious, durable, PCB-resistant coating.		
7	PCB equipment not stored in containers and contains PCB liquids is stored on a floor of steel, concrete or any other similar durable material, is dyked to contain: a) for one piece of equipment or container, 125% of the volume of the PCB liquid present; or b) for more than one piece of equipment or container, the greater of twice the volume of the PCB liquid in the largest piece or 25 per cent of the volume of all the PCB liquid stored.		
8	PCB storage site floor drains, sumps or other openings in the floor are: a) closed and sealed to prevent the release of liquids, or b) connected to a closed drainage system suitable for PCB collection that terminates at a location where any spilled liquids are contained and recovered and where the spilled liquids, and c) will not create a fire hazard or a risk to public health or safety.		
9	Stacked containers of PCB material, other than drums, are used only if the containers are designed for stacking, and are stacked not more than two containers high.		
10	Where drums containing PCB material are stacked, separate the drums from each other by pallets and, in the case of drums of PCB liquid, stack the drums not more than two drums high.		

Completed By: _____ **Contact Phone:** _____

Please retain a copy for your records and forward the original to:

12.18. Transboundary Movement and Notification Documents for Hazardous Waste

For the transboundary movement of Hazardous Waste the Proceedings according to the Basel Convention have to be followed and the appropriate forms prepared (see also chapter 1.2).

The Conference of the Parties to the Basel Convention at its eighth meeting (December 2006) adopted revised versions of the forms for the notification and movement documents, including the instructions for completing these forms. These forms can be accessed from the links below:

<http://www.basel.int/Portals/4/Basel%20Convention/docs/techmatters/forms-notif-mov/vCOP8.pdf>

There are other forms available such as e.g.

<http://www.pccdaman.info/pdf/Hw%20Forms/HW%20Form%20-%208.pdf>

Many forms are under revision at the time and will be published soon on the appropriate websites. Please check the actualities in the WWW periodically.

12.19. Dangerous Good Declaration and Container Packing Certificate

DANGEROUS GOODS DECLARATION AND CONTAINER PACKING CERTIFICATE

This form meets the requirements of SOLAS 74, Chapter VII, Regulation 4; Marpol 73/78 Annex III, Regulation 4 and Chapter 5.4 (Documentation), Vol. 1 of IMDG Code.

1 Shipper (Name and Address)		2 Page 1 of ___ pages									
		3 B/L Number:									
4 Consignee (Name and Address)		5 Shipper's Reference Number:									
		6 Carrier:									
SHIPPER'S DECLARATION: I hereby declare that the contents of this consignment are fully and accurately described below by the proper shipping name, and are classified, packaged, marked and labelled/placarded and are in all respects in proper condition for transport according to the applicable international and national government regulations.											
7 Port of Loading	8 Vessel/Voyage	9 1 st Relay Port	10 1 st Relay Vessel/Voyage								
11 2 nd Relay Port	13 2 nd Relay Vessel/Voyage	14 Port of Discharge	15 Port of Destination								
16 Dangerous Goods Details											
Proper Shipping Name	IMO Class	Sub Risk	UN No.	PG	FP	MP Y/N	Gross Wt. (kg)	Net Wt. (kg)	Cube (m ³)	Package No. & Type	
										Inner	Outer
17 Container No.		18 Container Size & Type		19 Seal No.							
20 Container Tare Wt. (kg)		21 Total Wt. (kg) (Including Container Wt.)		22 24 hrs Emergency Contact Tel No.							
23 Additional Handling Information				CONTAINER PACKING CERTIFICATE: I hereby declare that the goods described above have been packed/loaded into the container identified above in accordance with provision 5.4.2.1 of IMDG Code.							
				24 Name of Company							
				25 Name/State of Declarant							
				26 Place and Date							
				27 Signature of Declarant							
* DANGEROUS GOODS: You must specify: proper shipping name, hazard class, UN Number, Packaging Group, Marine Pollutant (where assigned) and observe the mandatory requirements under applicable national and international governmental regulations. For the purposes of the IMDG Code see Provision 5.4.1.4 and DOT-E - CFR 172.203(a)											

12.20. Application Form for Membership in the PEN



APPLICATION FORM FOR MEMBERSHIP TO THE PCB ELIMINATION NETWORK (PEN)



1. Personal information

I wish to register as an: Institution Individual person

Institution			
First name		Title (<i>Mr., Ms., Mrs., Dr.</i>)	
Family name			
Job title			
Mailing address		Postal code	
City		Country	
Telephone	<i>(please include international code)</i>	Mobile	<i>(please include international code)</i>
Fax		E-mail	

2. Additional information

Please specify to which category of stakeholders you belong (please choose only one category):

- Government (ministries, agencies, environmental inspectorates, etc.)
- PCB disposal service industry (entities offering maintenance, treatment or destruction of PCB)
- PCB owner or holder (private or state enterprises holding contaminated equipment or oils)
- Regional centre for the Stockholm or Basel Convention for capacity building and the transfer of technology
- Inter-governmental organization
- Non-governmental organization
- Research institution or academia
- Other: _____

In the field below, please briefly describe your involvement with PCB.

I am interested in the following topics of the thematic group (multiple checks possible):

- Inventory of PCB
- Maintenance, Handling, and Interim Storage of Equipment Containing PCB
- Disposal of PCB and Remediation of Contaminated Sites
- Open Applications of PCB
- Other: _____

3. Declaration

I hereby declare that I will make determined effort towards achieving environmentally sound management of PCB. I accept that all information provided can be shared publicly.

Date: _____

Signature: _____

Please e-mail or mail the completed form to:
 Secretariat of the PEN, Chemicals Branch, DTIE, UNEP
 11-13 Chemin des Anémones, CH-1219 Châtelaine (GE), Switzerland
 E-mail: pen@pops.int or heidlore.fiedler@unep.org

Annex IV
Fact Sheets



Factsheet II

IDENTIFICATION OF PCB TRANSFORMERS

Sampling Material

- Absorbent pads / rugs
- Drip trays (metal or PE)
- Glass vials, 30-50 ml (robust, wide opening)
- Flexible plastic hoses, 5mm
- Syringes, 10-100 mm
- Hand pumps
- Funnels
- Carrying box (incl. racks for vials/bottles)
- Sampling labels (for vials, transformer, report)
- Waterproof pens
- Sampling/Inventory reports

Personal Protective Equipment and Tools

- One-way protective gloves (Nitrile, PVC, Neoprene or rubber)
- Safety goggles
- Toolbox with set of maintenance tools (screwdrivers, pincers, locking pliers, hammer)

Caution!

- Always use new or clean(ed) sampling materials
- Collect waste in appropriate/protected place
- Waste disposal in environmental sound manner

Step-by-Step Sampling of a Transformer



Prepare sampling material and label the glass vial before sampling



Place drip tray under drain tap, wearing gloves and goggles



Open drain tap/valve (usually by local electrical technician)



Sample the oil (30-50ml for PCB screening, 1 if also oil quality is tested)



Affix sampling label on transformer (after cleaning the surface)



Record sample in sampling report, affix sampling label to report



Screen the oil sample by Clor-N-Oil or L2000 DX Analyzer (on site or off site)



Collect and dispose of screening materials as hazardous wastes




When test results are available, re-label the tested transformer



Factsheet II


IDENTIFICATION OF PCB TRANSFORMERS



Screening by Clor-N-Oil

This field test kit has become the worldwide standard in testing for PCB in insulating fluid. Dexsil Clor-N-Oil is fast, accurate, inexpensive and easy-to-use.

The total chlorine concentration is determined and indicated by a colorimetric reaction. The kit is a «GO / NO GO» type of test where the result is either positive or negative.



Also non-technical staff may just follow the instructions to test transformer oils within minutes.

The test kits are ideal for emergency and on site testing. In the case of extensive inventories, however, the L2000 Analyzer should be used.

Screening by L2000

The L2000DX Analyzer relies on the same basic chemistry as the Clor-N-Oil test kits, however, instead of a colorimetric reaction; the L2000DX uses an ion-specific electrode to quantify the contamination in the sample and provides the result in ppm (mg/kg respectively).

The L2000DX Analyzer is pre-programmed with conversion factors for all major Aroclors. The usable measurement range for oils is 2 to 2'000 ppm. A specific Manual will help quantify PCBs in transformer oils - step by step.





Factsheet II

IDENTIFICATION OF PCB TRANSFORMERS



Site Visit

Sites with possibly PCB containing equipment shall be inspected by inventory teams that should be assisted by a local electrical engineer.

During the inspection relevant transformer data shall be collected and recorded, for example *manufacturer, KVA rating, brand name of cooling fluid, type of fluid, serial number, year of manufacture, weight, and location.*

The site shall also be visually checked for spills, pollution and environmental risks.

In order to facilitate the inspection, national standard inventory forms shall be used for the inventory purposes.

Risk Assessment

An inventory is always an opportunity for preventive measures. Thus, a basic risk assessment of the site and the surrounding land shall be integrated in the PCB inventory.

Details and particulars, such as *the technical condition of the equipment, maintenance status, leakage, oil spills, safety of the site, location of the site (e.g. proximity to watercourses or food-processing companies), etc.*, will allow assessing the specific situation.

The opportunity should also be taken to consider partially open and open applications of PCBs.

Identification

Only sampling and screening will prove whether or not a transformer contains PCBs. Experience has shown that numerous transformers that were manufactured as PCB free equipment today actually **do** contain PCBs. In the 70s transformer manufacturers and oil suppliers were often not aware of the potential of cross-contamination of PCBs by using identical cisterns, transport containers, pipe systems and fittings for mineral oils and PCBs. Therefore many new transformers were unintentionally contaminated by PCBs. Such contamination can still occur today during maintenance and service works.

Consequently, each not hermetically sealed electrical device needs to be sampled even if it is of recent date of manufacture, because a later unintended contamination could have occurred.

Not only the PCB content of transformers in use has to be checked, but also the oil of phased out and spare transformers. Rigorous examinations must include spare oils in drums/containers and other equipment that could contain PCBs, *e.g. capacitors, regulators, circuit breakers, heat exchangers, oil cisterns, pipe systems, etc.*

Sampling

Oil samples can be taken by using the drain tap, which usually is at the bottom of the transformer. If a transformer has been disconnected from power for over 72 hours the sample should generally be taken from the bottom, as PCB may sink to a lower level because of its higher density. Alternatively transformers can be sampled via the oil filling cap by using a hand pump (a new pump must be used for each transformer). Oil samples from the expansion receptacle cannot always be regarded as representative, because the oil does not circulate and thus it is not really mixed.

Usually, transformers are sampled when they are in use and thus when they are live. Corresponding precautions must be taken and safety regulations must be known and considered at any time! Samples must only be taken under the supervision of skilled staff.

Important: Labelling of Tested Equipment

Once the PCB content has been determined the PCB equipment must be labelled appropriately. Correct labelling guarantees an easy and immediate recognition whether or not a device contains PCBs. In the event of an incident, the label will allow an immediate assessment of the situation and the associated potential hazards.





Factsheet II

IDENTIFICATION OF PCB TRANSFORMERS

Country Profile

Text to be provided by the countries based on their specific national management system and related project (s).

To write the overview we suggest to use **the 5W &H method**. The content should be specific to the country highlighting the aim of the activity and more importantly showcasing its impact.

The examples given here are only indicative. Writers of this section are free to add whatever detail they deem appropriate

Overview of the activity implemented in the country:

Country and specific location

Brief introduction about the country Reason for undertaking this activity (EX: country electricity companies still using PCB contaminated equipment in producing XX% of their power etc...)

Information about projects' timeframe and procedures, and phases of the activities undertaken

Impact: end result of the activity and its impact on the country

The conclusion could be about future needs or challenges.



Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem

Together for the Mediterranean Sea

MedPartnership



Factsheet II

IDENTIFICATION OF PCB TRANSFORMERS

UNEP/MAP- MedPartnership

The Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem (MedPartnership) is a collective effort of leading environmental institutions and organizations together with countries sharing the Mediterranean Sea to address the main environmental challenges that Mediterranean marine and coastal ecosystems face. The project is led by UNEP/MAP and is financially supported by the Global Environment Facility (GEF) and other donors, including the European Commission and all participating countries.

The MedPartnership's overarching goal is to enable a coordinated and strategic approach to catalyze the policy, legal and institutional reforms, and the investments necessary to reverse the degradation trends affecting the Mediterranean, including its coastal habitats, pollution and biodiversity.

Within the framework of the project, UNEP/MAP, through its MEDPOL programme, aims to support countries in the implementation of the SAP-MED (Strategic Action Programme to address pollution from land-based activities in the Mediterranean Region) and associated National Action Plans adopted in accordance with Land Based Sources and Activities Protocol of the Barcelona Convention. The project is supporting the ESM disposal of up to 870 tons PCB as well as undertaking important capacity building activities in four Mediterranean countries, including the preparation of ESM Guidelines for PCB.

The SAP-Med provides for the disposal of all hazardous wastes in a safe and environmentally sound manner and in conformity with the provisions of the Land Based Sources and Activities Protocol of the Barcelona Convention and other international agreed provisions by 2025.

Links

Country links:

Text to be provided by the countries:

Links to country institutions/projects dealing with PCBs management

Other links:

www.unepmap.org
www.themedpartnership.org
www.basel.int
www.chm.pops.int
www.pic.int

[Please insert the PCB network website](#)
[Watch the PCB documentary](#)

Contact

For further information please contact:

(key persons in the country/ministry)

Country:

[National MED POL Focal Point](#),
[Other contacts and focal points](#)



Factsheet III

IDENTIFICATION OF PCB CAPACITORS

Sampling Material

- Absorbent pads / rags
- Drip trays (metal or PE)
- Glass vials, 30-50 ml (robust, wide opening)
- Flexible plastic hoses, 5mm
- Syringes, 10-100 mm
- Hand pumps
- Funnels
- Carrying box (incl. racks for vials/bottles)
- Sampling labels (for vials, transformer, report)
- Waterproof pens
- Sampling/Inventory reports





Personal Protective Equipment and Tools

- One-way protective gloves (Nitrile, PVC, Neoprene or rubber)
- Safety goggles
- Toolbox with set of maintenance tools (screwdrivers, pincers, locking pliers, hammer)

Caution!

- Always use new or clean(ed) sampling materials
- Collect waste in appropriate/protected place
- Waste disposal in environmentally sound manner

Identification of PCB Capacitors

<p>Step 1 - Year of Manufacture:</p>	<p>Check nameplate for year of manufacture. If capacitor was manufactured in or after 19** → "PCB free"</p> <p>There is no global regulatory policy on a deadline. The decision is based from where electrical devices were imported and experience data. Therefore, it may vary from country to country. In many countries the deadline is set on 1993.</p> <p>** Final Year and/or additional test to be provided by the countries.</p>	
<p>Step 2 - Declaration:</p>	<p>Check nameplate for declaration "PCB" or "PCB trade name", e.g. Aroclor, Askarel, Clophen, Delor, Elal, Fenclor, No Flamol/Phenoclor, Pyralene, Pyranol, Sovol, etc. → "PCB containing"</p>	
<p>Step 3 - Capacitor Lists:</p>	<p>Compare nameplate/serial number with capacitor lists. Many devices can be identified or categorised according to information in capacitor lists. → "PCB free or PCB suspect"</p>	
<p>Step 4 - Sampling/Analysis:</p>	<p>If capacitor cannot be identified according to Steps 1-3 above, it must be sampled and analysed according to the procedure with transformers. Alternatively, the capacitor can be regarded as PCB containing. Please see the appropriate Factsheets.</p>	



Factsheet III

IDENTIFICATION OF PCB CAPACITORS



Site Visit

Sites with possibly PCB containing equipment shall be inspected by inventory teams that should be assisted by a local electrical engineer.

During the inspection relevant capacitor data shall be collected and recorded, for example *manufacturer, brand name, type, kVA, type of fluid, serial number, year of manufacture, weight, and location.*

The site shall also be visually checked for spills, pollution and environmental risks.

In order to facilitate the inspection, national standard inventory forms shall be used for the inventory purposes.

Risk Assessment

An inventory is always an opportunity for preventive measures. Thus, a basic risk assessment of the site and the surrounding land shall be integrated in the PCB inventory.

Details and particulars, such as *the technical condition of the equipment, maintenance status, leakage, oil spills, safety of the site, location of the site (e.g. proximity to watercourses or food-processing companies), etc.*, will allow assessing the specific situation.

The opportunity should also be taken to consider partially open and open applications of PCBs.

Identification

Capacitors are sealed entities. A contamination after manufacture can be excluded. Considering the fact that after 1993-1996 (deadline set by the countries), no PCB was produced anymore, it can be assumed that capacitors manufactured after this date are PCB free.

In many cases, the manufacturer provided information about the type of dielectric liquid, either with identification on the nameplate or with a separate tag confirming that the contents are harmful for the environment.

Such capacitors do not need any further investigation. They definitely do contain PCBs and must be treated accordingly.

After the PCB ban most of the power capacitors were declared as *PCB free/Non PCB* either on the nameplate or with a separate tag, and they can be disposed of as normal oil containing waste.

In some cases, capacitor lists providing information about the PCB content of capacitors can be used to determine whether or not a capacitor contains PCBs.

If a designation is missing and no other information is available, the capacitor must be sampled.

Capacitors still in service and manufactured before 1993-1996 (deadline set by the countries), with missing information about the dielectric liquid have to be labelled as PCB suspected equipment.

Sampling

The only way to test the dielectric liquid of a capacitor is to drill a hole in the casing on the top or cut the isolator and retrieve an oil sample. This can be done by e.g. using a one-way pipette.

Only phased out capacitors can undergo this procedure. If there is a series of the same capacitors, it is usually sufficient to sample only two devices out of the series. Preferably a mixed sample originating from the two capacitors with the lowest serial numbers should be analyzed.

Important: Labelling of Tested Equipment

Once the PCB content has been determined the PCB equipment must be labelled appropriately. Correct labelling guarantees an easy and immediate recognition whether or not a device contains PCBs. In the event of an incident, the label will allow an immediate assessment of the situation and the associated potential hazards.





Factsheet III

IDENTIFICATION OF PCB CAPACITORS

Country Profile

Text to be provided by the countries based on their specific national management system and related project (s).

To write the overview we suggest to use the SW &H method. the content should be specific to the country highlighting the aim of the activity and more importantly showcasing its impact. The examples given here are only indicative. Writers of this section are free to add whatever detail they deem appropriate

Overview of the activity implemented in the country:

Country and specific location

Brief introduction about the country Reason for undertaking this activity (EX: country electricity companies still using PCB contaminated equipment in producing XX% of their power etc...)

Information about projects' timeframe and procedures, and phases of the activities undertaken

Impact: end result of the activity and its impact on the country

The conclusion could be about future needs or challenges.



Factsheet III

IDENTIFICATION OF PCB CAPACITORS

UNEP/MAP- MedPartnership

The Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem (MedPartnership) is a collective effort of leading environmental institutions and organizations together with countries sharing the Mediterranean Sea to address the main environmental challenges that Mediterranean marine and coastal ecosystems face. The project is led by UNEP/MAP and is financially supported by the Global Environment Facility (GEF) and other donors, including the European Commission and all participating countries.

The MedPartnership's overarching goal is to enable a coordinated and strategic approach to catalyze the policy, legal and institutional reforms, and the investments necessary to reverse the degradation trends affecting the Mediterranean, including its coastal habitats, pollution and biodiversity.

Within the framework of the project, UNEP/MAP, through its MEDPOL programme, aims to support countries in the implementation of the SAP-MED (Strategic Action Programme to address pollution from land-based activities in the Mediterranean Region) and associated National Action Plans adopted in accordance with Land Based Sources and Activities Protocol of the Barcelona Convention. The project is supporting the ESM disposal of up to 870 tons PCB as well as undertaking important capacity building activities in four Mediterranean countries, including the preparation of ESM Guidelines for PCB.

The SAP-Med provides for the disposal of all hazardous wastes in a safe and environmentally sound manner and in conformity with the provisions of the Land Based Sources and Activities Protocol of the Barcelona Convention and other international agreed provisions by 2025.

Links

Country links:

Text to be provided by the countries:

Links to country institutions/projects dealing with PCBs management

Other links:

www.unepmap.org
www.themedpartnership.org
www.basel.int
www.chm.pops.int
www.pic.int

Please insert the PCB network website
Watch the PCB documentary

Contact

For further information please contact:

(key persons in the country/ministry)

Country:

National MED POL Focal Point:

Other contacts and focal points



Factsheet V

PCB HANDLING, PACKING, TRANSPORT



Maintenance and Repair

When performing light repair or maintenance work on PCB containing electrical devices, safety precautions for the protection of the employees and the environment (leakage) have to be taken.



See Best Working Practices.

Dismantling and Phase-out

Before the phase out or dismantling of PCB containing electrical devices, it has to be checked if there are any damages or leaks. In case of leaks, they have to be sealed for example with a sealing paste prior to any further work, or alternatively a transformer could be drained on site before removal.

During the dismantling of capacitors, the bushings have to be regarded as their «weakest» parts. Especially for high, medium and low voltage capacitors, it is not allowed to hold on to the bushings while carrying them, as they might loosen or break off and cause a spill of PCB containing fluid.

Leaking devices must immediately be placed in a drip tray, an appropriate drum or container to prevent cross-contamination. The surface must be cleaned and if necessary a leakage stop device can be applied. All arising associated waste has to be collected and disposed of as hazardous waste.

Interim Storage

PCB equipment and wastes should generally not be stored in areas which are not specifically designed for interim storage of hazardous wastes.

Uncontrolled and inexperienced interim storages endanger human health and the environment.

PCB containing devices shall be packed safely and in compliance with the applicable laws as soon as

they have been phased out, even if their disposal takes place at a later stage.

Interim Storage of PCB wastes shall never exceed twelve months. Generally, electrical equipment should only be phased out and stored, once an appropriate method of disposal has been chosen (unless the devices are in bad condition).

General Criteria for Interim Storage:

- No nature reserves nearby
- Distance to rivers and groundwater
- Distance to residential or farming areas
- Distance to other industries (e.g. food-processing companies)
- Possible effects of incidents

Possible General Layout of Interim Storage



Packing

Packaging and labelling of PCB wastes must conform to the construction and testing instructions stipulated in the ADR regulations.

Due to safety and handling reasons PCB wastes should ideally be packed into UN approved steel drums: Open head steel drums for solid PCBs, and tight head steel drums for liquids.

In case of liquid PCB, drums must never be completely filled. Approx. 50 mm or 10 % of the volume should be left empty for a possible extension of PCB in case of higher temperatures.

When capacitors are packed into drums, they must always be stored standing upright.





Factsheet V

PCB HANDLING, PACKING, TRANSPORT

Any movement of the waste inside the drum has to be prevented. If the height of the capacitors exceeds the drum, it might be necessary to carefully break off the bushings. Such activities shall only be allowed after the capacitors have been placed into drums. As an additional safety measure, a layer of sawdust should be added to each drum, in order to absorb any liquids if necessary.

Due to their size, transformers can normally not be packed in boxes. Therefore, they have to be prepared and loaded on trucks in such a way, that no contamination of the surrounding materials is possible. Precautions have to be taken to prevent leakage (for example steel drip trays) and secure the devices. The best option, however, remains the draining of cooling fluids into UN approved steel drums before transport.



UN approved drums with PCB wastes are ideally loaded and transported in box containers for national or international transport.

Transport

Transport and packing of dangerous goods are regulated by various international regulations, for example the ADR.

In case of international transports also Basel Convention procedures must be considered. In 1989, the Basel Convention on the "Control of Transboundary Movements of Hazardous Wastes and their Disposal" was adopted to protect people and the environment from the negative effects of the inappropriate management of hazardous wastes worldwide.

There are different types of sea containers which can be used for the (international) transport of hazardous wastes, and therefore PCB containing wastes. If 20' containers are used, there is space for 72 UN approved drums.

When wastes are transported over long distances, it is particularly important to ensure that the load cannot shift. The load can be ideally secured by ideal utilisation of space and by safety measures like safety straps, antislip wooden boards and air bags. It is also necessary to ensure

that the weight of the individual packaging in trucks or containers is evenly distributed. Furthermore, the total gross loading weights, which vary from country to country, must be considered.

Examples of 20' and 40' types of Containers



When transporting (drained) transformers, the devices must be tightened by using sufficiently strong straps fixed to the lifting eyes. The loading is easier if open top containers are used. However, such containers must be covered by a tarpaulin to protect against the rain.



Factsheet V

PCB HANDLING, PACKING, TRANSPORT



however, are rather expensive.

There are also special containers for the safe transport of PCB containing transformers that have not been drained. Such units,

Best Working Practices

When performing light repair or maintenance work on PCB containing equipment, the following safety precautions for the protection of the employees and the environment have to be taken:

- Direct contact of the skin with PCB contaminated materials must be avoided by wearing gloves and safety goggles. According to the type of work to be performed, protective clothing and a respiratory mask must also be put at the workers' disposal;
- The working area must be adequately ventilated;
- Spills must be prevented in every case by using drip trays or adequate plastic tarps;
- Every contact of PCBs with a flame or any other heat source over 300 °C and use of a grinder must absolutely be avoided (risk of highly toxic Dioxins and Furans);
- All used tools and other working materials that got in contact with PCBs must be disposed of as PCB contaminated waste in an environmentally sound manner or otherwise have to be decontaminated with an appropriate solvent (technical acetone). The only possible materials to be decontaminated are steel, glass, and ceramics;
- Operations which involve draining, rewinding of coil, etc. may only be performed by companies approved for such task by the appropriate authority.

No person shall handle, offer for transport or transport PCBs unless he is trained to do so, or is performing those activities under the direct supervision of a trained person.

Country Profile

Text to be provided by the countries based on their specific national management system and related project (s).

To write the overview we suggest to use the 5W &H method. The content should be specific to the country highlighting the aim of the activity and more importantly showcasing its impact.

The examples given here are only indicative. Writers of this section are free to add whatever detail they deem appropriate

Overview of the activity implemented in the country:

Country and specific location

Brief introduction about the country Reason for undertaking this activity (EX: country electricity companies still using PCB contaminated equipment in producing XX% of their power etc...)

Information about projects' timeframe and procedures, and phases of the activities undertaken

Impact: end result of the activity and its impact on the country

The conclusion could be about future needs or challenges.



Factsheet V

PCB HANDLING, PACKING, TRANSPORT

UNEP/MAP- MedPartnership

The Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem (MedPartnership) is a collective effort of leading environmental institutions and organizations together with countries sharing the Mediterranean Sea to address the main environmental challenges that Mediterranean marine and coastal ecosystems face. The project is led by UNEP/MAP and is financially supported by the Global Environment Facility (GEF) and other donors, including the European Commission and all participating countries.

The MedPartnership's overarching goal is to enable a coordinated and strategic approach to catalyze the policy, legal and institutional reforms, and the investments necessary to reverse the degradation trends affecting the Mediterranean, including its coastal habitats, pollution and biodiversity.

Within the framework of the project, UNEP/MAP, through its MEDPOL programme, aims to support countries in the implementation of the SAP-MED (Strategic Action Programme to address pollution from land-based activities in the Mediterranean Region) and associated National Action Plans adopted in accordance with Land Based Sources and Activities Protocol of the Barcelona Convention. The project is supporting the ESM disposal of up to 870 tons PCB as well as undertaking important capacity building activities in four Mediterranean countries, including the preparation of ESM Guidelines for PCB.

The SAP-Med provides for the disposal of all hazardous wastes in a safe and environmentally sound manner and in conformity with the provisions of the Land Based Sources and Activities Protocol of the Barcelona Convention and other international agreed provisions by 2025.

Links

Country links:

Text to be provided by the countries:

Links to country institutions/projects dealing with PCBs management

Other links:

www.unepmap.org
www.themedpartnership.org
www.basel.int
www.chm.pops.int
www.pic.int

[Please insert the PCB network website](#)
[Watch the PCB documentary](#)

Contact

For further information please contact:
(key persons in the country/ministry)

Country:

National MED POL Focal Point.
Other contacts and focal points



Factsheet V

PCB HANDLING, PACKING, TRANSPORT



Maintenance and Repair

When performing light repair or maintenance work on PCB containing electrical devices, safety precautions for the protection of the employees and the environment (leakage) have to be taken.



See *Best Working Practices*.

Dismantling and Phase-out

Before the phase out or dismantling of PCB containing electrical devices, it has to be checked if there are any damages or leaks. In case of leaks, they have to be sealed for example with a sealing paste prior to any further work, or alternatively a transformer could be drained on site before removal.

During the dismantling of capacitors, the bushings have to be regarded as their «weakest» parts. Especially for high, medium and low voltage capacitors, it is not allowed to hold on to the bushings while carrying them, as they might loosen or break off and cause a spill of PCB containing fluid.

Leaking devices must immediately be placed in a drip tray, an appropriate drum or container to prevent cross-contamination. The surface must be cleaned and if necessary a leakage stop device can be applied. All arising associated waste has to be collected and disposed of as hazardous waste.

Interim Storage

PCB equipment and wastes should generally not be stored in areas which are not specifically designed for interim storage of hazardous wastes.

Uncontrolled and inexpert interim storages endanger human health and the environment.

PCB containing devices shall be packed safely and in compliance with the applicable laws as soon as


they have been phased out, even if their disposal takes place at a later stage.

Interim Storage of PCB wastes shall never exceed twelve months. Generally, electrical equipment should only be phased out and stored, once an appropriate method of disposal has been chosen (unless the devices are in bad condition).

General Criteria for Interim Storage:

- No nature reserves nearby
- Distance to rivers and groundwater
- Distance to residential or farming areas
- Distance to other industries (e.g. food-processing companies)
- Possible effects of incidents

Possible General Layout of Interim Storage



Packing

Packaging and labelling of PCB wastes must conform to the construction and testing instructions stipulated in the ADR regulations.

Due to safety and handling reasons PCB wastes should ideally be packed into UN approved steel drums: Open head steel drums for solid PCBs, and tight head steel drums for liquids.

In case of liquid PCB, drums must never be completely filled. Approx. 50 mm or 10 % of the volume should be left empty for a possible extension of PCB in case of higher temperatures.

When capacitors are packed into drums, they must always be stored standing upright.





Factsheet V

PCB HANDLING, PACKING, TRANSPORT

Any movement of the waste inside the drum has to be prevented. If the height of the capacitors exceeds the drum, it might be necessary to carefully break off the bushings. Such activities shall only be allowed after the capacitors have been placed into drums. As an additional safety measure, a layer of sawdust should be added to each drum, in order to absorb any liquids if necessary.

Due to their size, transformers can normally not be packed in boxes. Therefore, they have to be prepared and loaded on trucks in such a way, that no contamination of the surrounding materials is possible. Precautions have to be taken to prevent leakage (for example steel drip trays) and secure the devices. The best option, however, remains the draining of cooling fluids into UN approved steel drums before transport.



UN approved drums with PCB wastes are ideally loaded and transported in box containers for national or international transport.

Transport

Transport and packing of dangerous goods are regulated by various international regulations, for example the ADR.


In case of international transports also Basel Convention procedures must be considered. In 1989, the Basel Convention on the "Control of Transboundary Movements of Hazardous Wastes and their Disposal" was adopted to protect people and the environment from the negative effects of the inappropriate management of hazardous wastes worldwide.

There are different types of sea containers which can be used for the (international) transport of hazardous wastes, and therefore PCB containing wastes. If 20' containers are used, there is space for 72 UN approved drums.

When wastes are transported over long distances, it is particularly important to ensure that the load cannot shift. The load can be ideally secured by ideal utilisation of space and by safety measures like safety straps, antislip wooden boards and air bags. It is also necessary to ensure

that the weight of the individual packaging in trucks or containers is evenly distributed. Furthermore, the total gross loading weights, which vary from country to country, must be considered.

Examples of 20' and 40' types of Containers



When transporting (drained) transformers, the devices must be tightened by using sufficiently strong straps fixed to the lifting eyes. The loading is easier if open top containers are used. However, such containers must be covered by a tarpaulin to protect against the rain.



Factsheet V

PCB HANDLING, PACKING, TRANSPORT



There are also special containers for the safe transport of PCB containing transformers that have not been drained. Such units, however, are rather expensive.

Best Working Practices

When performing light repair or maintenance work on PCB containing equipment, the following safety precautions for the protection of the employees and the environment have to be taken:

- Direct contact of the skin with PCB contaminated materials must be avoided by wearing gloves and safety goggles. According to the type of work to be performed, protective clothing and a respiratory mask must also be put at the workers' disposal;
- The working area must be adequately ventilated;
- Spills must be prevented in every case by using drip trays or adequate plastic tarps;
- Every contact of PCBs with a flame or any other heat source over 300 °C and use of a grinder must absolutely be avoided (risk of highly toxic Dioxins and Furans);
- All used tools and other working materials that got in contact with PCBs must be disposed of as PCB contaminated waste in an environmentally sound manner or otherwise have to be decontaminated with an appropriate solvent (technical acetone). The only possible materials to be decontaminated are steel, glass, and ceramics;
- Operations which involve draining, rewinding of coil, etc. may only be performed by companies approved for such task by the appropriate authority.

No person shall handle, offer for transport or transport PCBs unless he is trained to do so, or is performing those activities under the direct supervision of a trained person.

Country Profile

Text to be provided by the countries based on their specific national management system and related project (s).

To write the overview we suggest to use the 5W &H method. The content should be specific to the country highlighting the aim of the activity and more importantly showcasing its impact.

The examples given here are only indicative. Writers of this section are free to add whatever detail they deem appropriate

Overview of the activity implemented in the country:

Country and specific location

Brief introduction about the country Reason for undertaking this activity (EX: country electricity companies still using PCB contaminated equipment in producing XX% of their power etc...)

Information about projects' timeframe and procedures, and phases of the activities undertaken

Impact: end result of the activity and its impact on the country

The conclusion could be about future needs or challenges.



Factsheet V

PCB HANDLING, PACKING, TRANSPORT

UNEP/MAP- MedPartnership

The Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem (MedPartnership) is a collective effort of leading environmental institutions and organizations together with countries sharing the Mediterranean Sea to address the main environmental challenges that Mediterranean marine and coastal ecosystems face. The project is led by UNEP/MAP and is financially supported by the Global Environment Facility (GEF) and other donors, including the European Commission and all participating countries.

The MedPartnership's overarching goal is to enable a coordinated and strategic approach to catalyze the policy, legal and institutional reforms, and the investments necessary to reverse the degradation trends affecting the Mediterranean, including its coastal habitats, pollution and biodiversity.

Within the framework of the project, UNEP/MAP, through its MEDPOL programme, aims to support countries in the implementation of the SAP-MED (Strategic Action Programme to address pollution from land-based activities in the Mediterranean Region) and associated National Action Plans adopted in accordance with Land Based Sources and Activities Protocol of the Barcelona Convention. The project is supporting the ESM disposal of up to 870 tons PCB as well as undertaking important capacity building activities in four Mediterranean countries, including the preparation of ESM Guidelines for PCB.

The SAP-Med provides for the disposal of all hazardous wastes in a safe and environmentally sound manner and in conformity with the provisions of the Land Based Sources and Activities Protocol of the Barcelona Convention and other international agreed provisions by 2025.

Links

Country links:

Text to be provided by the countries:

Links to country institutions/projects dealing with PCBs management

Other links:

www.unepmap.org
www.themedpartnership.org
www.basel.int
www.chm.pops.int
www.pic.int

[Please insert the PCB network website](#)
[Watch the PCB documentary](#)

Contact

For further information please contact:

(key persons in the country/ministry)

Country:

[National MED POL Focal Point,](#)
[Other contacts and focal points](#)

Annex V
Presentations

Day 1 presentations



Presentation of Environmentally Sound PCB Management Guide

Regional Meeting on ESM and combating Illegal Traffic of Chemicals and Hazardous Waste in the Mediterranean


7-9 April 2015

The Central Palace Hotel - Istanbul - Turkey

Urs K. Wagner




PCB Management Guide (and Factsheets)



Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

Five Specific Factsheets

- Factsheet I: PCB Awareness Raising
- Factsheet II: Identification of PCB Transformers
- Factsheet III: Identification of PCB Capacitors
- Factsheet IV: PCB Open Applications
- Factsheet V: PCB Handling, Packing, Transport



Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

Extent of this Powerpoint Presentation

- Introduction:
Context with SC and situation analysis /
Objectives of Guide and Factsheets
- Each chapter will be presented:
 - › Chapter 1 to Chapter 11
 - › Incl. Annexes
- Only extracts of important subchapters,
details and data will be presented by ppt
- Each chapter/page will then be mutually
reviewed, discussed and agreed before
the next chapter is presented



Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

SC, Annex A, Part II (PCBs) 1



Annex A requires all Parties to cease production of new PCBs immediately

- All Parties using the (Part II) PCB specific exemption shall eliminate use of in-place equipment containing PCBs by 2025:
- make determined **efforts to identify, label and remove from use** equipment with > 10 % or > 0.05 % and > 5 litres of PCB
- endeavour to identify and remove from use equipment with > 0.005 % (50 ppm) and > 0.05 litres of PCB
- give higher priority to equipment with higher PCB levels

... but priorities may vary ... Homework?

Equipment with > 5 litres of PCB

Contaminated Transformer

- Content 1'000 litre Oil
 - 100 mg/kg PCB (0.1g Oil)
 - Specific weight: 1.00 kg/l
- 100 g PCB



Capacitor with pure PCB

- Content 1 litre Oil
 - Specific weight: 1.350 kg/l
- 1.35 kg PCB

SC, Annex A, Part II (PCBs) 3

All Parties using the PCB specific exemption shall:

- **not export or import PCB** equipment, except for the purpose of environmentally sound management (ESM) of waste
- not recover liquids with more than 0.005 % PCBs for reuse in other equipment, except for maintenance and servicing
- **make determined efforts to achieve ESM of wastes containing > 0.005% PCBs ASAP, and by 2028**
- endeavour to identify articles with > 0.005 % PCB for ESM
- report to the COP every five years on their progress in eliminating PCBs (per Article 15)

COP will review progress toward the 2025 and 2028 targets at 5 year intervals, taking into account reports from Parties

Demands of the Stockholm Convention

Article 10 requires adequate provision of education, information and awareness to the members of the public



- Countries have to develop a communication strategy
- Countries shall involve NGOs



Inventories Review by PEN/UNEP Chemicals



5th Meeting of the AC in Geneva

Extract: Draft Report on Progress towards Elimination of PCB for COP 2015:

- A lot of progress has been made, however only some 32 % of PCB equipment and materials destroyed so far
- Need of “complete” inventories / assessments
→ PCB estimations → usually too high or too low
- PCB inventories must be more reliable, existing data must be evaluated → **Need of HARMONIZATION of Proceedings**
- **Focus must be widened to address OA, too**
- Insufficient characterisation of waste types
- AR & CP must continue



2.2 Fallen into Oblivion: SC, Annex A, Part II, PCB (f)

In lieu of note (ii) in Part I of this Annex, endeavour to identify **other articles** containing **> 0.005 % PCB**

(**e.g. cable-sheaths, cured caulk and painted objects**) and **manage them in accordance with paragraph 1 of Article 6.**



Aims and Objectives I


The purpose of this PCB Management Guide is:

- To provide technical guidance on different aspects of PCB life cycle environmentally sound management
- To provide guidance on the inventory and monitoring of PCBs (...) until their final phasing out and disposal
- The Guide does not aim to be “complete”; it however covers the main aspects of ESM of PCB (equipment), existing Guidelines of SBC and experiences in the four pilot countries of this regional project.
- The Guide shall be an ideal ground for country and/or industry specific Guidelines as well as general AR & CB



Aims and Objectives II

- To provide sound information for “training activities” and “PCB Management in General” with the aim to **HARMONIZE** the proceedings in the Region



Countries

- The PCB Management Guide is an «extract» of the main topics of a comprehensive PCB Management
- The Guide shall be regarded as a useful, primary tool in order to implement best practices in the countries
- The Guide can be further amended, adapted and specified with regard to the current and specific situations, experiences, proceedings, infrastructures, regulations, etc. in the countries
- **IMPORTANT:** Please add the country specific contacts into the Factsheets and preferably also the Guide!



Target Groups

The PCB Management Guide is intended for:

- Electrical engineers, chemists and laboratory staff, technicians and safety responsables at mid-management level
- Environmental and Fire/Chemical Response Authorities as well as Customs Authorities
- These stakeholders may use the PCB Management Guide (and the specific Factsheets) to train technicians and workers in the environmentally sound handling of PCBs



PCB Management Guide - Approach = Chapters



General PCB Management Approach I

Sampling



Screening



Emergency Actions (if necessary)



Preliminary Inventory



Physical Site Inspection



... Approach II


Priority Setting

1. ...
2. ...
3. ...
4. ...

Lab (if necessary)



PCB Management Options



Maintenance



Database



Approach III

Tracking System



Phase Out




Interim Storage



Update Database



Treatment / Disposal



Transport



PCB Management Guide

Presentation & Discussion: Chapter by Chapter

1. General Information on PCBs and International Conventions
2. Data Collection, Identification, Sampling and Monitoring
3. PCB Management of Closed Applications
4. Maintenance of Equipment Containing PCB
5. Safety
6. Emergency Actions and Clean Up
7. Phase Out
8. Packing
9. Temporary Storage
10. Transport
11. Treatment and Disposal
12. Annexes



Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

Chapter 0 - Abbreviations and Definition of Terms



To be reviewed and adapted, also country specific

Abbreviations and Definition of Terms

ADR	European agreement on the international road transport for hazardous goods
Aksoel	Trade name of PCB cooling fluid (USA, Monsanto)
BAT	Best Available Technique
BC	Basel Convention on the transboundary movement of hazardous wastes and their disposal
BEP	Best Environmental Practice
BRS	Basel, Rotterdam, Stockholm Convention (Secretariat)
Capacitor	Equipment or unit to supply lagging kilovars for power factor correction of an electric system, some capacitors were manufactured with PCB as cooling fluid
Capacitor Bank (General)	Practically there are three different ways of power factor (PF) correction: the capacitor is directly connected to the terminals of an equipment (motors, welding machine etc.) producing the "lagging kilovars"
Capacitor Bank (LV)	Capacitors for "group" PF correction, the capacitor(s) is (are) connected to the LV-busbar of a transformer station, which feeds a number of consumers with individual motors.
Capacitor Bank (MV)	Capacitors for "central" PF correction, large capacitor installation connected to the Middle- or High Voltage busbars of a substation where many individual electrical appliances (motors etc.) of various sizes operate at different times and periods.
Closed Systems	Capacitors and transformers, where the PCB itself is in completely closed containers. PCBs rarely emit from closed systems (in good conditions)
Congener	Depending on the number and position of the chlorine atoms in the Biphenyl molecule, 209 isomers and homologous Chlorine Biphenyls are theoretically possible. A single compound from this group is called PCB congener
Container 20'	Internationally used expression for Transport or Storage Containers with the Standard size of 2 x 2.45 meters (40' Container - 2 x 2 x 12 meters)
Container Box	There are various types of 20' and 40' Containers available, the most common is the Box Container with a front door. From an open Box Container the roof can be removed for loading and off-loading activities (e.g. ideal for transformers)
Cooling Fluid	Dielectric fluid
COP	Conference of the Parties

Abréviations et définitions des termes

ADR	Accord européen relatif au transport international des marchandises dangereuses par route
Aksoel	Marque d'un liquide de refroidissement contenu des PCB (Ebas-Unis, Monsanto)
MTD	Meilleure technique disponible
CB	Convention de Bâle sur les mouvements transfrontières et l'élimination des déchets dangereux
MPE	Meilleures pratiques environnementales
BRS	Conventions de Bâle, de Rotterdam et de Stockholm (Secrétariat)
Condensateur	Équipement ou unité destinée à compenser la puissance réactive insuffisante d'un système électrique en kilo-volt-ampères-réactifs (kVar) ; certains condensateurs ont été fabriqués avec un liquide de refroidissement contenant des PCB.
Batterie de condensateurs (Général)	En pratique, il existe trois modes de compensation de puissance réactive (CPR) : par un condensateur de CPR « individuelle » ; le condensateur est directement connecté aux équipements (moteur, machine à souder, etc.) pour compenser l'insuffisance en kVar.
Batterie de condensateurs (BT)	Condensateurs de CPR « groupée » : les condensateurs sont connectés au bus de barres BT d'un poste transformateur qui alimente un certain nombre de consommateurs équipés de moteurs, de machines à souder, etc.
Batterie de condensateurs (MT)	Condensateurs de CPR « centrale » : grande installation de condensateurs connectés au jeu de barres MT et BT d'une sous-station dans laquelle de nombreux appareils électriques (moteurs, etc.) de tailles diverses fonctionnent à différents moments et pour des durées différentes.
Système clos	Condensateurs et transformateurs, dans lesquels les PCB sont contenus dans des récipients clos : les PCB circulent au sein d'un système clos (en bon état)
Congénère	En fonction du nombre et de la position des atomes de chlore dans la molécule de biphenyle, 209 isomères et biphenyles chlorés homologues sont théoriquement possibles. Un composé unique de ce groupe est appelé congénère de PCB.
Conteneur 20 pieds	Terme utilisé internationalement pour désigner les conteneurs de transport ou d'embarquement présentant une taille normalisée de 2 x 2 x 6 mètres (conteneur 40 pieds = 2 x 2 x 12 mètres)
Conteneur cube	Il existe divers conteneurs 20' et 40' pieds. Les plus utilisés sont les conteneurs cubiques standards équipés d'une porte sur le devant et d'un toit amovible qui facilite le chargement et le déchargement (idéale pour les transformateurs, par ex.)
Liquide de refroidissement	Liquide diélectrique
CdP	Conférence des Parties

Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

Chapter 1 - General Information on PCBs and International Conventions



1.2 to 1.5: Chemical Conventions



Waste Management

Parties must develop strategies to identify POPs waste and manage them in an **ENVIRONMENTALLY SOUND MANNER**



- **BAT**
Best Available Techniques
- **BEP**
Best Environmental Practices

BAT/BEP: On our Doorstep!



Let's review and discuss Chapter 1!



Chapter 2 - Data Collection, Identification, Sampling and Monitoring



Sub-chapters 2





2.	Data collection, Identification, Sampling and Monitoring.....	13
2.1.	Data collection and Inventory.....	13
2.2.	PCB Applications	15
2.2.	Periodic Examinations and Maintenance of PCB Containing Devices.....	16
2.2.1.	Sampling of Transformers, Capacitors and Construction Materials	16
2.2.2.	General Sampling Procedures.....	18
2.2.3.	Sampling of Capacitors.....	18
2.2.4.	Sampling of Transformers	20
2.2.5.	Sampling of Phased Out and Drained Transformers.....	22
2.2.6.	Sampling of Concrete and Brick Walls.....	23
2.2.7.	Sampling of Soil	25
2.3.	Screening Test Kits and Laboratory Analysis.....	25
2.3.1.	Analysis by Gas Chromatography (GC)	28
2.3.2.	Analysis Proceedings	29
2.4.	Database.....	30
2.5.	Labelling of Checked Equipment	31
2.6.	Site Monitoring	32
2.6.1.	Land Register of Areas and Storage Facilities with Possible PCB Contamination or contaminated equipment.....	33
2.6.2.	Risk Assessment	33
2.6.3.	Analysis	33
2.6.4.	Extent of Contamination.....	34

Inventory: Basis for most other actions



Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

1999 Inventory Guidelines UNEP Chemicals



<http://www.chem.unep.ch/irptc/Publications/pcb1.pdf>

Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

2.1 Data Collection



Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

2.1 Identify and involve ALL potential stakeholders!

- Electric Utilities
- Maintenance Workshops
- Industrial Facilities
- Railroad Systems
- Mining Industry
- Army, Navy & Air Forces
- Residential or Commercial Buildings
- Holiday Resorts / Hotels
- School Buildings
- Cold Storage Depots
- Customs Authorities
- Scrap Dealers
- Hospitals
- Research Laboratories
- Manufacturing Plants
- Waste Water Discharge Facilities
- Car Service Stations
- Small/Medium sized Co.
- Airports
- Wood Processing Co.
- Exporters
- Port Authorities
- Shipbuilding Industry
- Landfill sites
- Obsolete Waste Dumps

Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

2.2: PCB Applications - Closed Systems

Insulation and/or cooling fluid in **transformers**

Dielectric fluid in **capacitors**

Hydraulic fluid in **lifting equipment, trucks and high pressure pumps**



Open Applications of PCBs



Caulks/sealants

Paints and plaster

Anti-corrosion coatings

Surface coatings

Cables and cable sheaths

Sealed double glazing windows

Lubricating fluid in oils and grease; cutting oils

PCBs as flame retardant and impregnating agent

Adhesives

Carbonless copy paper

Inks

Liquid filled electrical cables etc.

12.14 PCB Inventory Forms

The image displays three overlapping copies of the 'PCB Inventory Form' dated August 2002. The forms are organized into several sections:

- Section A: Identification of PCB-containing equipment** (Page 1 of 4)

Inventory of PCB-containing Equipment	
Serial number	
Name	
Address of site (if different from A2)	
City	
State	
Country	
Type of company / industry / type of production / specific use	
Type of PCB-containing equipment	
Location	
Number of units at site	
Total number of units of each type	
Total weight of PCBs (kg)	
Total weight of PCBs (kg) in 1995	
Total weight of PCBs (kg) in 2002	
Total weight of PCBs (kg) in 2002 (if different from 2002)	
Total weight of PCBs (kg) in 2002 (if different from 2002)	
- Section B: PCB content** (Page 2 of 4)

Inventory of PCB-containing equipment	
Serial number	
Name	
Address of site (if different from A2)	
City	
State	
Country	
Type of company / industry / type of production / specific use	
Type of PCB-containing equipment	
Location	
Number of units at site	
Total number of units of each type	
Total weight of PCBs (kg)	
Total weight of PCBs (kg) in 1995	
Total weight of PCBs (kg) in 2002	
Total weight of PCBs (kg) in 2002 (if different from 2002)	
Total weight of PCBs (kg) in 2002 (if different from 2002)	
- Section C: PCB content** (Page 3 of 4)

Inventory of PCB-containing equipment	
Serial number	
Name	
Address of site (if different from A2)	
City	
State	
Country	
Type of company / industry / type of production / specific use	
Type of PCB-containing equipment	
Location	
Number of units at site	
Total number of units of each type	
Total weight of PCBs (kg)	
Total weight of PCBs (kg) in 1995	
Total weight of PCBs (kg) in 2002	
Total weight of PCBs (kg) in 2002 (if different from 2002)	
Total weight of PCBs (kg) in 2002 (if different from 2002)	

Page 1 of 4

Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

UNEP MedPartnership

2.2.1 Sampling – Necessary Material Supply

The image is a collage illustrating the necessary material supply for sampling. It features several photographs of workers in various settings:

- Top left: Workers in white protective suits and respirators handling large cylindrical equipment.
- Bottom left: A worker in a full white protective suit and respirator.
- Right: Workers in blue and red shirts performing tasks near a brick wall and large equipment.

In the center, there is a prominent yellow square warning sign with a black silhouette of a person being struck by a red lightning bolt, indicating a high-voltage or electrical hazard.

Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

UNEP MedPartnership

2.2.1-2.2.5 Sampling General / Transformers



Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

2.2.3 Capacitors - Different Approach



Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

Do not forget the hidden problems...







Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

Ballasts and Small Capacitors



Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

2.2.3 Capacitors - Different Approach

Step 1 - Year of Manufacture:	Check nameplate for year of manufacture. If capacitor was manufactured in or after 19...? → "PCB free"	
Step 2 - Declaration:	Check nameplate for declaration "PCB" or "PCB trade name", e.g. <i>Aroclor, Askarel, Clophen, Delor, Elaol, Fenclor, No FlamolPhenoclor, Pyralene, Pyranol, Sovol, etc.</i> → "PCB containing"	
Step 3 - Capacitor Lists:	Compare nameplate/serial number with capacitor lists. Many devices can be identified or categorised according to information in capacitor lists. → "PCB free or PCB suspect"	
Step 4 - Sampling/Analysis:	If capacitor cannot be identified according to Steps 1-3 above, it must be sampled and analysed according to the procedure with transformers. Alternatively, the capacitor can be regarded as PCB containing. Please see the appropriate Factsheets.	

Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

Capacitor Lists



<http://www.pops.int/document/guidance/NIPsFinal/eagov.pdf>

http://www.chemsuisse.ch/downloads/kondensatorenverzeichnis-v3.1_d.pdf
<http://www.chemsuisse.ch/downloads/repertoire-des-condensateurs-3.1-f.pdf>
<http://www.chemsuisse.ch/downloads/elenco-dei-condensatori-4.0-i.pdf>

Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

2.3 Screening and Analysis




2.3 Screening of Oils – Chlorine Detection



2.3 PCB Field Screening Test Kits

Clor-N-Oil and Clor-N-Soil



2.3.1 Laboratory Analysis



2.3.1 Global Inventory POPs Laboratories


NAME	COUNTRY	ISML
Desarrollo Analitico Servicios	Argente and Dobado	<input type="checkbox"/>
INEL - Centro de Analisis Organico	Argentina	<input type="checkbox"/>
LECA - Laboratorio Elemental de Calidad de Agua	Argentina	<input type="checkbox"/>
LAGAB - Laboratorio de Analisis Ambiental y Biogeoquimico	Argentina	<input type="checkbox"/>
CEI - Centro de Investigaciones Toxicológicas	Argentina	<input type="checkbox"/>
CEBA - Centro de Estudios Toxicológicos del Agua	Argentina	<input type="checkbox"/>
National Biochemistry Institute	Australia	<input type="checkbox"/>
Umweltanalytisches Institut	Austria	<input type="checkbox"/>
Synlab - Synlab Umwelt GmbH	Austria	<input type="checkbox"/>
Cairo Central Center Laboratory for Environmental Monitoring in EEAA (Egyptian Environmental Affairs Agency)	Egypt	<input type="checkbox"/>
Central Laboratory of Residue Analysis of Pesticides and Heavy Metals in Food	Egypt	<input type="checkbox"/>
IL - Central Investigation Laboratory	Daluz	<input type="checkbox"/>
SPECTROLAB	Daluz	<input type="checkbox"/>
TUTITAK IIRC Mass Spectrometry Laboratory	Turkey	<input type="checkbox"/>
Farmaco Study Center, An. Vianello's Health and Dietetics Faculty/National School of Public Health - Operative Cross Coordination	Brazil	<input type="checkbox"/>
Analytical Solutions S.A.	Brazil	<input type="checkbox"/>
COMECO - Laboratorio de Microcontaminantes, Organicos e Control de Qualidade Ambiental	Brazil	<input type="checkbox"/>

<http://www.unep.org/chemicalsandwaste/POPsandScience/AnalysisandMonitoring/POPsLaboratoryDatabank/tabid/1059820/Default.aspx>

2.4 Database



- Identification of ALL electrical equipment
- Ensure Access and Updates
- Accompany inventorised Equipment / Waste from cradle to grave





2.5 Easy Identification



AIM:
Harmonized labelling system in the regions



2.5. Labels for tested Equipment





Let's review and discuss Chapter 2!



Chapter 3 - PCB Management of Closed Applications





Sub-chapters 3

3.	PCB Management of Closed Applications.....	35
3.1.	PCB Management Plan.....	35
3.1.1.	Designation of a PCB Responsible	35
3.1.2.	Training and Instruction of Staff.....	35
3.1.3.	Inventory	35
3.1.4.	Database on Locations with PCB Equipment, Waste or Contamination.....	35
3.1.5.	Maintenance Plan.....	35
3.1.6.	PCB Spill Prevention, Control and Countermeasure Plan (SPCC Plan).....	35
3.1.7.	Disposal Plan	36
3.2.	Spill Prevention, Control and Countermeasure Plan (SPCC Plan).....	36
3.2.1.	Prevention	36
3.2.2.	Spill Prevention Tools.....	36
3.2.3.	Countermeasure	37
3.3.	Priorities for Disposal.....	37

Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

27

3.1 PCB Management Plan

A PCB management plan includes the following components:

- Designation of a PCB Responsible
- Information, Instruction and Training of Staff
- Inventory / Risk Assessment (Insurance if any)
- Database on Locations with PCB Devices, Waste, Contamination
- Maintenance
- Phase Out and Disposal Plan
- Spill Prevention, Control and Countermeasure Plan

3.1.7 Disposal Plan means also Financial Plan!



Leistung in kVA	Fc-Verluste	Cu-Verluste	Anschaffungspreis
83	528	635	8286
100	728	1188	8148
150	296	1798	8756
200	346	2278	8100
400	446	3278	13440
500			
630	630	4368	16850
800	640	5758	19240
1000	856	6158	22500
1200	988	6618	20550
1500	1188	8268	26720
2000	1388	16318	38640

Leistungsleistung	800kVA	1000kVA	1200kVA	1500kVA	2000kVA	2500kVA	3000kVA	3500kVA	4000kVA	5000kVA	6000kVA	7000kVA	8000kVA	9000kVA	10000kVA
800kVA	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400
1000kVA	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500
1200kVA	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600
1500kVA	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700
2000kVA	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800
2500kVA	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900
3000kVA	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000
3500kVA	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100
4000kVA	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200
5000kVA	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300
6000kVA	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400
7000kVA	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500
8000kVA	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600
9000kVA	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700
10000kVA	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800

3.2 Fire/Spill Protection and SPCC Plan



3.2 Incidents: Be ready!



Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015



MedPartnership



33

3.3 Priorities for Disposal

- High PCB concentration equipment
- Equipment in bad technical condition
- Equipment located in areas of high priority respectively sensitive areas
- All other equipment with PCB concentration > 50 mg/kg



Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015



MedPartnership



34

Let's review and discuss Chapter 3!



Chapter 4 - Maintenance of Equipment Containing PCB



Sub-chapters 4



4.	Maintenance of Equipment Containing PCB.....	38
4.1.	Best Working Practices.....	38
4.2.	Maintenance of PCB Containing Transformers.....	39
4.2.1.	Visual Checks.....	39
4.2.2.	Leaks of Transformers.....	39
4.2.3.	Oil Level of Transformers.....	40
4.2.4.	Temperature Gauge.....	40
4.2.5.	Pressure-Vacuum Gauge.....	40
4.2.6.	Corrosion on Tank and Radiator Fins.....	40
4.2.7.	Performance Tests.....	40
4.3.	Maintenance of PCB Containing Capacitors.....	41
4.4.	Substitute Fluids.....	41

7.2.4 Maintenance In-Service Equipment

Aim: Establish a mechanism to prevent cross-contamination during Operation & Maintenance (spare oil, filtering, hoses, pumps etc.)



7.2.4 Maintenance In-Service Equipment

Key Issues to be considered for ESM:

- Transfer of Cooling Fluids during Maintenance:
 - › prevent cross-contamination via pumps, hoses, oil recovery etc.
- Replacing of leaking seals and repair of cracks and holes
- Clean up of minor leaks/spills



4.1.2 Maintenance – Best Working Practices I

Safety precautions for light repair or maintenance work:

- Avoid direct contact with PCBs:
 - › Wear gloves and safety goggles
 - › Wear protective clothing and mask (if necessary)
- Ventilate working area
- Prevent spills



4.1.2 Maintenance – Best Working Practices II

- **Never heat or burn PCBs or PCB containing materials!**
 - › **Dioxins and Furans are unintentionally formed and released from thermal processes involving PCBs**
- Dispose of tools and working materials in ES manner
- ONLY steel, glass and ceramics can be decontaminated/cleaned
- Only authorised companies may drain, rewind coil, etc. PCB transformers



4.2.1 Visual Checks

Check for/examine:

- Oil stains near the equipment
- Oil stains or weep marks on the equipment
- Severe physical damage
- Tightness of drip tray (if any)



- *Regarding leaks see also chapter 4.2.2*


4.2.1 Inspection of (PCB) Transformers

Routine Inspections:

New Title:

4.2. Maintenance Inspection of PCB Containing Transformers

- Condition/reading of gauges
- Corrosion on tank or radiator fins
- Paint on tank and radiator fins
- Leakages
- Pressure-relief valve
- Bushings
- Color of Cooling Fluid



Review of ESM Guide and Factsheets on PCB - Istanbul, April 7, 2015

4.2.7 Performance Tests

- Function of all protection devices
- Electrical performance of the transformer
- Oil Quality Test



Review of ESM Guide and Factsheets on PCB - Istanbul, April 7, 2015

4.3 Inspection of Capacitors

Check for:

New Title:

4.3. Maintenance Inspection of PCB Containing Capacitors


- Leaks
- Swelling or deformation of the casing
- Oxidation of the casing
- Dirty bushings



In case of leaks or swelling,
the capacitor must be phased out immediately.

4.4 Substitutes of PCB Cooling Fluids

- Mineral Oils
 - 👍: Less Expensive, Slightly Toxic
 - 👎: Fire Hazard
- Heavy Oils
 - 👎: Higher Viscosity, Environmental Risks
- Silicon Oils
 - 👍: Non-Toxic
 - 👎: Higher Viscosity, Non-Biodegradable, Bad Dielectric Properties



Conclusion

👍 Mineral oils have become the best alternative to PCBs again. 👍



Let's review and discuss Chapter 4!



Chapter 5 - Safety



Sub-chapters 5

<p>K. Sicilite</p> <p>5.1. Safety and Personal Protective Equipment</p> <p>The choice of the adequate personal protective equipment depends largely on the tasks to be performed and the surrounding conditions.</p> <p>Table 5.1. Selection of personal protective equipment (PPE)</p> <table border="1"> <thead> <tr> <th>Task</th> <th>Personal Protective Equipment</th> </tr> </thead> <tbody> <tr> <td>Handing of samples in case of spillage</td> <td> <ul style="list-style-type: none"> 1. Gloves (leak or liquid, no liquid) 2. Light respiratory mask if there is PCB in vapour phase and particles, mist/aerosol </td> </tr> <tr> <td>Handing of samples in case of spillage and handling</td> <td> <ul style="list-style-type: none"> 1. Goggles (leak or liquid, no liquid) 2. Safety goggles (leak, splash, mist/aerosol) 3. Light respiratory mask if there is PCB in vapour phase and particles (leak, splash, mist/aerosol) </td> </tr> <tr> <td>Handing of samples in case of spillage and handling (leakage)</td> <td> <ul style="list-style-type: none"> 1. Goggles (leak) 2. Safety goggles (leak, splash, mist/aerosol) 3. Full respiratory mask (leak, splash, mist/aerosol) 4. Light respiratory mask (leak, splash, mist/aerosol) (leak, splash, mist/aerosol) </td> </tr> <tr> <td>Handing of samples in case of spillage and handling (leakage)</td> <td> <ul style="list-style-type: none"> 1. Protective suit (leak) 2. Full respiratory mask (leak, splash, mist/aerosol) 3. Light respiratory mask if there is PCB in vapour phase and particles </td> </tr> <tr> <td>Storage of samples in case of spillage and handling (leakage)</td> <td> <ul style="list-style-type: none"> 1. Protective suit (leak) 2. Full respiratory mask (leak, splash, mist/aerosol) 3. Light respiratory mask (leak, splash, mist/aerosol) (leak, splash, mist/aerosol) 4. Full respiratory mask (leak, splash, mist/aerosol) (leak, splash, mist/aerosol) 5. The protection of footwear </td> </tr> </tbody> </table>	Task	Personal Protective Equipment	Handing of samples in case of spillage	<ul style="list-style-type: none"> 1. Gloves (leak or liquid, no liquid) 2. Light respiratory mask if there is PCB in vapour phase and particles, mist/aerosol 	Handing of samples in case of spillage and handling	<ul style="list-style-type: none"> 1. Goggles (leak or liquid, no liquid) 2. Safety goggles (leak, splash, mist/aerosol) 3. Light respiratory mask if there is PCB in vapour phase and particles (leak, splash, mist/aerosol) 	Handing of samples in case of spillage and handling (leakage)	<ul style="list-style-type: none"> 1. Goggles (leak) 2. Safety goggles (leak, splash, mist/aerosol) 3. Full respiratory mask (leak, splash, mist/aerosol) 4. Light respiratory mask (leak, splash, mist/aerosol) (leak, splash, mist/aerosol) 	Handing of samples in case of spillage and handling (leakage)	<ul style="list-style-type: none"> 1. Protective suit (leak) 2. Full respiratory mask (leak, splash, mist/aerosol) 3. Light respiratory mask if there is PCB in vapour phase and particles 	Storage of samples in case of spillage and handling (leakage)	<ul style="list-style-type: none"> 1. Protective suit (leak) 2. Full respiratory mask (leak, splash, mist/aerosol) 3. Light respiratory mask (leak, splash, mist/aerosol) (leak, splash, mist/aerosol) 4. Full respiratory mask (leak, splash, mist/aerosol) (leak, splash, mist/aerosol) 5. The protection of footwear 	<p>K. Sicilite</p> <p>5.2. Security of Equipment or protection individuelle</p> <p>Le choix de l'équipement de protection individuelle dépend largement des tâches à effectuer et des conditions de travail.</p> <p>Tableau 5.1. Sélection de l'équipement de protection individuelle (EPI)</p> <table border="1"> <thead> <tr> <th>Tâche</th> <th>Équipement de protection individuelle</th> </tr> </thead> <tbody> <tr> <td>Manutention d'échantillons en cas de déversement</td> <td> <ul style="list-style-type: none"> 1. Gants (fuite ou liquide, pas de liquide) 2. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) </td> </tr> <tr> <td>Manutention d'échantillons en cas de déversement et manipulation</td> <td> <ul style="list-style-type: none"> 1. Lunettes (fuite ou liquide, pas de liquide) 2. Lunettes de sécurité (fuite, éclaboussure, brouillard, aérosol) 3. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) </td> </tr> <tr> <td>Manutention d'échantillons en cas de déversement et manipulation (déversement)</td> <td> <ul style="list-style-type: none"> 1. Casque (fuite) 2. Lunettes de sécurité (fuite, éclaboussure, brouillard, aérosol) 3. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) 4. Masque respiratoire (fuite, éclaboussure, brouillard, aérosol) </td> </tr> <tr> <td>Manutention d'échantillons en cas de déversement et manipulation (déversement)</td> <td> <ul style="list-style-type: none"> 1. Combinaison de protection (fuite) 2. Masque respiratoire (fuite, éclaboussure, brouillard, aérosol) 3. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) </td> </tr> <tr> <td>Stockage d'échantillons en cas de déversement et manipulation (déversement)</td> <td> <ul style="list-style-type: none"> 1. Combinaison de protection (fuite) 2. Masque respiratoire (fuite, éclaboussure, brouillard, aérosol) 3. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) 4. Masque respiratoire (fuite, éclaboussure, brouillard, aérosol) 5. Protection des chaussures </td> </tr> </tbody> </table>	Tâche	Équipement de protection individuelle	Manutention d'échantillons en cas de déversement	<ul style="list-style-type: none"> 1. Gants (fuite ou liquide, pas de liquide) 2. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) 	Manutention d'échantillons en cas de déversement et manipulation	<ul style="list-style-type: none"> 1. Lunettes (fuite ou liquide, pas de liquide) 2. Lunettes de sécurité (fuite, éclaboussure, brouillard, aérosol) 3. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) 	Manutention d'échantillons en cas de déversement et manipulation (déversement)	<ul style="list-style-type: none"> 1. Casque (fuite) 2. Lunettes de sécurité (fuite, éclaboussure, brouillard, aérosol) 3. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) 4. Masque respiratoire (fuite, éclaboussure, brouillard, aérosol) 	Manutention d'échantillons en cas de déversement et manipulation (déversement)	<ul style="list-style-type: none"> 1. Combinaison de protection (fuite) 2. Masque respiratoire (fuite, éclaboussure, brouillard, aérosol) 3. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) 	Stockage d'échantillons en cas de déversement et manipulation (déversement)	<ul style="list-style-type: none"> 1. Combinaison de protection (fuite) 2. Masque respiratoire (fuite, éclaboussure, brouillard, aérosol) 3. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) 4. Masque respiratoire (fuite, éclaboussure, brouillard, aérosol) 5. Protection des chaussures
Task	Personal Protective Equipment																								
Handing of samples in case of spillage	<ul style="list-style-type: none"> 1. Gloves (leak or liquid, no liquid) 2. Light respiratory mask if there is PCB in vapour phase and particles, mist/aerosol 																								
Handing of samples in case of spillage and handling	<ul style="list-style-type: none"> 1. Goggles (leak or liquid, no liquid) 2. Safety goggles (leak, splash, mist/aerosol) 3. Light respiratory mask if there is PCB in vapour phase and particles (leak, splash, mist/aerosol) 																								
Handing of samples in case of spillage and handling (leakage)	<ul style="list-style-type: none"> 1. Goggles (leak) 2. Safety goggles (leak, splash, mist/aerosol) 3. Full respiratory mask (leak, splash, mist/aerosol) 4. Light respiratory mask (leak, splash, mist/aerosol) (leak, splash, mist/aerosol) 																								
Handing of samples in case of spillage and handling (leakage)	<ul style="list-style-type: none"> 1. Protective suit (leak) 2. Full respiratory mask (leak, splash, mist/aerosol) 3. Light respiratory mask if there is PCB in vapour phase and particles 																								
Storage of samples in case of spillage and handling (leakage)	<ul style="list-style-type: none"> 1. Protective suit (leak) 2. Full respiratory mask (leak, splash, mist/aerosol) 3. Light respiratory mask (leak, splash, mist/aerosol) (leak, splash, mist/aerosol) 4. Full respiratory mask (leak, splash, mist/aerosol) (leak, splash, mist/aerosol) 5. The protection of footwear 																								
Tâche	Équipement de protection individuelle																								
Manutention d'échantillons en cas de déversement	<ul style="list-style-type: none"> 1. Gants (fuite ou liquide, pas de liquide) 2. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) 																								
Manutention d'échantillons en cas de déversement et manipulation	<ul style="list-style-type: none"> 1. Lunettes (fuite ou liquide, pas de liquide) 2. Lunettes de sécurité (fuite, éclaboussure, brouillard, aérosol) 3. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) 																								
Manutention d'échantillons en cas de déversement et manipulation (déversement)	<ul style="list-style-type: none"> 1. Casque (fuite) 2. Lunettes de sécurité (fuite, éclaboussure, brouillard, aérosol) 3. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) 4. Masque respiratoire (fuite, éclaboussure, brouillard, aérosol) 																								
Manutention d'échantillons en cas de déversement et manipulation (déversement)	<ul style="list-style-type: none"> 1. Combinaison de protection (fuite) 2. Masque respiratoire (fuite, éclaboussure, brouillard, aérosol) 3. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) 																								
Stockage d'échantillons en cas de déversement et manipulation (déversement)	<ul style="list-style-type: none"> 1. Combinaison de protection (fuite) 2. Masque respiratoire (fuite, éclaboussure, brouillard, aérosol) 3. Masque respiratoire léger (fuite, éclaboussure, brouillard, aérosol) 4. Masque respiratoire (fuite, éclaboussure, brouillard, aérosol) 5. Protection des chaussures 																								

5.	Safety.....	43
5.1.	Safety and Personal Protective Equipment.....	43
5.2.	Protection of the Environment.....	45

5.1 Safety of Workers!

- Always consider the type of the foreseen task, respectively work!
- To have PPE available is not sufficient – one has to use it correct, too

Table 19: Description of personal protection equipment (PPE)

Task	Personal Protective Equipment
Sampling of liquids or soil	<ul style="list-style-type: none"> Gloves (Vinyl or Nitrile, no Latex) Light respiratory mask (Filter A2P2, for organic vapors and particles, voluntary)
Sampling of a reactor	<ul style="list-style-type: none"> Gloves (Vinyl or Nitrile, no Latex) Safety goggles, only while opening or drilling Light respiratory mask (Filter A2P2, for organic vapors and particles)
Sampling of concrete or brick soil (eg. by drilling)	<ul style="list-style-type: none"> Leather gloves Safety goggles while drilling Light respiratory mask (Filter A2P2, for organic vapors and particles) Ear protection (with 3-5kg)
Dismantling of capacitor (no leakage)	<ul style="list-style-type: none"> Working overall Helmet (according to companies' safety rules) Steel capped (rubber) boots Leather gloves Light respiratory mask only in case of leakage (Filter A2P2, for organic vapors and particles)
Dismantling of capacitor (with leakage)	<ul style="list-style-type: none"> Protective suit (Tyvek) Steel capped (rubber) boots Leather gloves Light respiratory mask (Filter A2P2, for organic vapors and particles)



Therefore Training is a key tool of safety



5.2 Protection of the Environment

- Prevention of further cross-contamination

Considering and follow Guide advises:

- when taking samples;
- when doing site assessments
- when incidents happened




Let's review and discuss Chapter 5!



Chapter 6 - Emergency Actions and Clean Up



Sub-chapters 6



6.	Emergency Actions and Clean Up.....	46
6.1.	Emergency Actions for Cold Incidents.....	46
6.2.	Emergency Actions for Hot Incidents.....	47
6.2.1.	Incident Caused by an Internal Failure	47
6.2.2.	Fires	48
6.3.	First Aid in Case of Contact with PCB.....	49
6.4.	Clean Up after Incidents	49
6.4.1.	Assessment of an Incident.....	49
6.4.2.	Decontamination Methods.....	50
6.4.3.	Protection of Workers and the Environment.....	51
6.4.4.	Disposal	51
6.5.	Check of Clean Up (Monitoring).....	51
6.5.1.	Tolerable Remaining Contamination after a Clean-up.....	51

6 Emergencies

Emergencies involving PCBs can occur:

- with equipment in service
- with phased-out equipment in storage
- during transport
- at the disposal/treatment facility



Therefore all companies dealing with PCB containing equipment/material should develop and implement an emergency action plan.

6.1 Cold Incidents

- The seeping of PCB or spillage from an electrical device into the environment is described as a «cold incident»
- Action must be taken and it shall be reported to the PCB inventory of course (incident, action, evtl. additional “waste”)



12.8 Emergency Response Plan for Cold Incidents

12.8. Emergency Response Plan for Cold Incidents

The following table shows the measures to be taken in case of PCB incidents. For each nature of spill the order of the actions to be taken is indicated by the numbers.

	Nature of spill			
	Leakage into containment device	Spill on concrete and asphalt	Spill on soil	Spill into water
Notify about personnel, chemical manufacturer and competent authorities	1	1	1	1
Notify responsible director and not an adequately trained	2	2	2	2
Protective equipment (local personal contamination)	3	3	3	3
Protect people and/or vehicles from entering the contaminated area	4	4	4	4
If applicable, disconnect the contaminated equipment from power (check, switching)	5	5	5	5
Plug or close all drains in vicinity and check for obstructions (local removal)	6	6	6	6
Stop source: Shut tank by using appropriate methods, place drip tray under leak	7	7	7	7
Spill containment: Fully close the container (PCB) or small area	8	8	8	8
Clean with plastic impervious material from top	9	9	9	9
Clean area if possible and close all drains to avoid water	10	10	10	10
Collect contaminated area: Transfer into waste containers	11	11	11	11
For large contained PCB incidents	12	12	12	12
Shut up PCB with absorbents	13	13	13	13
Use absorbents to collect the contaminated soil: seal them	14	14	14	14
Reported to relevant authorities (national) by a written message	15	15	15	15
Take care sample to determine remaining concentration (ALGP)	16	16	16	16
Check off contaminated container	17	17	17	17
Pack wastes according to ADR, load dispose in hazardous waste	18	18	18	18
Transfer waste into other container near to the vicinity of PCB contamination	19	19	19	19

6.2 Hot Incidents

Hot incidents can be caused by short circuits or fires in the vicinity of PCB equipment.

- During such hot incidents, PCB vapours and contaminated soot can be released and these may contain highly toxic Furans.
- If PCB gets in contact with oxygen, also Dioxins must be considered.



6.2.1 Hot Incidents with electrical devices

- An electrical short circuit (arc) constitutes the most common danger.
- Such a short circuit may cause temperatures of several thousand degrees in a capacitor within fractions of a second.



12.9 Emergency Response for Hot PCB Incidents

12.9. Emergency Response Plan for Hot Incidents

The following table shows the sequence to be taken in case of PCB incidents. For each number of step the order of the actions to be taken is indicated by the numbers.

Emergency Response for Hot PCB Incidents	Nature of Incident		
	Internal failure No heating of equipment	Internal failure of capacitor heating of equipment with oil flow or highly toxic fumes?	Fire in vicinity of equipment leakage of liquid under pressure and toxic?
Notify the brigade			1
Stop plant process, isolate equipment and disconnect induction		1	2
Inform responsible doctor and put on adequate Personal Protective Equipment (respirator mask)		2	3
Remove people from vicinity of equipment/leakage		3	4
Disconnect the concerned equipment if possible	4	4	5
Place out equipment	5		
Evacuate and close the building, put out air conditioning/plugging vents		6	6
Stop process leak (not with aggressive materials, show dry-powder under fire)		7	7
Confine contaminated area		8	8
If fire contained in a heavy pressure vessel, keep stand from danger zone, let the specialist intervene in the fire		9	9
Decontaminate equipment		10	10
Reported accident with process followed by a report to the top		11	11
Fill out reports to determine prevention (RMP)		12 (see above)	12 (see above)
Fill out the design for accident (RMP)		13	13
Check off contaminated equipment		14	14
Use design to control the contaminated equipment		15	15
Check wastes according to PCB and fill gases as hazardous waste	16	16	16

6.2.2 (Transformer) Fires – Main Danger



Review of ESM Guide and Factsheets on PCB - Istanbul, April 7, 2015

6.3 First Aid if in contact with PCB



Kind of Exposure	Measure
➤ Liquid PCB on the skin	➤ Use water and soap to wash thoroughly
➤ Liquid PCB in the eyes	➤ Rinse eyes with lukewarm jets of water for 15 minutes, always keeping eyes wide open
➤ Liquid PCB in the mouth and in the stomach	➤ Rinse mouth with water, do not drink anything else, see doctor immediately
➤ Highly concentrated vapours of PCB	➤ Take affected people outside in the open air

Review of ESM Guide and Factsheets on PCB - Istanbul, April 7, 2015

12.11 Instructions for Workers

Instruction No: 06/2014 | Company:
 Add: 914 Oduşankı on Hazardous Substances

Polychlorierte Biphenyle
 PCB are suspected of causing cancer.

Hazards for human health and the environment
 Breathing in, swallowing or absorption through the skin may result in health damage. May cause irritation (respiratory tract, eyes, skin, organs of digestion). Temporary complaints (dizziness, fatigue, nausea, loss of appetite) are possible. Can cause acute digestive disorders, liver damage, blood picture changes, mood disorders. Carcinogenic effect is suspected. PCB can affect reproductive fertility. PCB can be harmful to the unborn child. Pflanzlich wachsenden Körnern und Samen Ertragsverluste. Unkräutern können sehr giftige Dioxine und Furane entstehen. Hazardous to water - avoid ingress into the ground, water and sewage!

Protective measures and behaviour rules
 Ensure a fresh air supply when working in the event of vapours, work only with exhaust ventilation built into. Feuer, offenen Flammen oder heißen Metallteilen in der Umgebung brennen! Do not leave vessels open! Avoid splashes! Do not mix with other products or chemicals! Avoid contact with eyes, skin and clothing! Fireworklike skin protection necessary. Thoroughly clean hands and face after completing work and before every work break! Use skin care agents! Store contaminated clothing separately from work clothing! Change clothing after completing work! Change footwear daily!
 Change footwear on arrival!
 Eye protection: Full protection goggles!
 Hand protection: Gloves made of: Baumwollweb.
 It is advisable to wear cotton gloves underneath protective gloves.
 Breathing protection: The use of AC-P3 (brown-red) is recommended, combined with AC-F2 (brown-white).
 In pits, shafts and silos, only use anti-blast air-independent breathing apparatus!
 Skin protection: Use greaseproof skin protection clothing for all uncovered parts of the body.
 Body protection: (Disposable) chemical protective suit and plastic boots. Bei Bedarf zementstehende Schutzkleidung!

Behaviour in danger situations
 Collect and dispose of with absorbent non-combustible material (e.g. kieselgrün, sand)! Evacuate the workplace if large quantities should leak! Remove only after applying personal protective equipment! Product is not combustible. In the event of a fire in the environment, cool the receptacle with sprayed water! Hazardous vapours are produced in the event of fire! Only fight larger fires using self-contained breathing equipment and suitable protective equipment.
 Responsible physician or clinic:
 Accident phone:
First Aid
 Dealing with First Aid avoidance: protect yourself and immediately inform a doctor.
 After eye contact: Rinse for 10 minutes with water or with eye-wash solution.
 After skin contact: Take off soiled clothing immediately. Clean with abundant amounts of water and soap. No friction!
 After breathing in: Fresh air. Keep always clear, remove take breath, vomit etc. If breathing or heartbeat stops immediately apply artificial respiration and heart massage.
 After swallowing: Do not cause vomiting. If unconscious, see that plenty of water is drunk a little at a time. No stomach to gorge!
 First Aid specialist:
Proper disposal
 Do not pour into the sewage or a refuse bin!
 Product residues:
 For disposal, collect in.

Notiz: Exposition Nr: 06/2014 | 30666
 nach 114 de la directive sur les produits dangereux

Polychlorierte Biphenyle
 PCB suspected of causing cancer.

Dangers pour l'homme et l'environnement
 L'inhalation, l'ingestion ou l'absorption par la peau peuvent être dangereuses pour la santé. Peut irriter (voies respiratoires, yeux, peau, organes digestifs). Possibilité de maux de tête, fatigue, nausées, perte d'appétit, etc. Peut provoquer des troubles digestifs, lésions du foie, modifications de la formule sanguine, troubles du comportement. On soupçonne un effet cancérogène. PCB peut être nocif pour l'enfant et le fœtus. Peut affecter la fertilité. PCB peut être nuisible à la croissance des végétaux et à la production de semences. Les mauvaises herbes peuvent produire des dioxines et des furanes très toxiques. Polluant pour l'eau - éviter la contamination de la sol, dans les eaux et les égouts!

Mesures de protection et règles de comportement
 Travailler avec une ventilation d'air si des vapeurs sont produites, ne travailler qu'avec des équipements fixés sur le mur, éviter les flammes ou objets chauds (métaux en fusion) ! Ne pas laisser les récipients ouverts ! Éviter les éclaboussures ! Ne pas mélanger avec d'autres produits ou produits chimiques ! Éviter le contact avec les yeux, la peau ou les vêtements ! Préférer la protection de la peau respiratoire. Une fois le travail terminé, changer de vêtements et de chaussures ! Changer les vêtements contaminés !
 Changer les vêtements contaminés !
 Porter des chaussures contaminées !
 Protection des yeux: Lunettes de sécurité complètes !
 Protection des mains: Gants en coton tissés.
 Il est recommandé d'utiliser des gants sous-gants en coton quand on porte des gants de sécurité !
 Protection respiratoire: L'utilisation de AC-P3 (brun-rouge) est recommandée, combinée avec AC-F2 (brun-blanc).
 Dans les puits, les tranchées et les silos, utiliser que des appareils de protection respiratoire indépendants de l'air ambiant !
 Protection de la peau: Utiliser pour toute les parties du corps non protégées une tenue protectrice non tissée.
 Protection corporelle: Combinaison de protection contre les produits chimiques à usage unique) et bottes en matière plastique. Bei Bedarf zementstehende Schutzkleidung!

Comportements en cas de danger
 Recueillir et éliminer le produit avec soin et non inflammable (par ex. du kieselgrün, du sable) et éliminer le produit restant !
 En cas de feu dans l'environnement, refroidir le récipient avec de l'eau pulvérisée !
 Si un incendie se déclare, ne pas intervenir, si un incendie se déclare à proximité, ne pas intervenir, ne pas intervenir !
 Si un incendie se déclare, attention: production de vapeurs toxiques ! Un appareil autonome de protection des voies respiratoires et un équipement de protection adéquat sont indispensables pour combattre les incendies importants.
 Médecin responsable ou clinique:
 Téléphone d'urgence:
Premiers secours
 Pour toutes mesures de premiers secours, se protéger soi-même et éventuellement l'assistant le médecin le plus proche.
 Après contact avec les yeux: Rincer à l'eau ou avec une solution saline pendant 10 minutes.
 Après contact avec la peau: Enlever immédiatement les vêtements contaminés. Nettoyer avec beaucoup d'eau et du savon. Aucun frottement.
 Après inhalation: Air frais. Débrancher les voies respiratoires, éloigner les personnes exposées et les vêtements. Si un arrêt respiratoire ou cardiaque, pratiquer immédiatement la respiration artificielle ou le massage cardiaque.
 Après ingestion: Ne pas provoquer de vomissements. En état inconscient, faire boire beaucoup d'eau par petites gorgées. Aucun produit ménager.
 Prendre soin des vêtements contaminés.
 Porter des chaussures contaminées.
Élimination adéquate
 Ne pas éliminer dans l'égout ou dans la poubelle !
 Restes de produit:
 Pour élimination, collecter dans :

Review of ESM Guide and Factsheets on PCB - Istanbul, April 7, 2015

6.4.1 Assessment of an Incident



Review of ESM Guide and Factsheets on PCB - Istanbul, April 7, 2015

6.4.2 Decontamination methods

Methods depend to:

- Kind of Incident (Spillage, Fire...)
- Pollutant(s)
- Concentration(s)
- Extend of the Contamination
- and type of involved Material (e.g. surfaces of concrete, ceramic, metals, soil etc.)

Evaluate Decontamination Methods!



6.5 Tolerable Remaining Contamination

Proposed general guide values

Description	Substance	Guide value	Unit
Surfaces (for example cleaned/decontaminated metal surfaces)	PCB	100	µg/m ²
Solids (for example concrete, building materials, etc.)	PCB	50	mg/kg
Indoor Air Rooms with a stay of eight hours per day (Intervention value)	PCB	> 6'000	ng/m ³
Indoor Air Rooms with permanent stay (Intervention value)	PCB	> 2'000	ng/m ³
Indoor Air Value to be achieved after a PCB clean-up	PCB	300	ng/m ³

Let's review and discuss Chapter 6!



BAD Examples: Cross-Contamination




Review of ESM Guide and Factsheets on PCB - Istanbul, April 7, 2015

Safe and Cost-effective Solutions



Review of ESM Guide and Factsheets on PCB - Istanbul, April 7, 2015

... same with transformers



Review of ESM Guide and Factsheets on PCB - Istanbul, April 7, 2015

Chapter 7 - Phase Out



Sub-chapters 7

7. Phase Out

7.1. Phase Out of Transformers

The general phasing out of equipment goes with the dismantling procedure, which has to follow the final safety, noise, or vibration equipment as well as all activities of dismantling the transformer. Before any activity on the transformer can start, it must be ensured that the transformer is de-energized and that the oil is drained. The oil must be stored in a safe container and the transformer must be grounded. The transformer must be grounded in a safe manner and the transformer must be grounded in a safe manner.

The winding core should be handled off as metal scrap. It is recommended that the transformer be dismantled in a safe manner and the transformer be dismantled in a safe manner.

It is recommended that the transformer be dismantled in a safe manner and the transformer be dismantled in a safe manner.

It is recommended that the transformer be dismantled in a safe manner and the transformer be dismantled in a safe manner.



Photo 11: Phase out of transformer (transformer Phase out) (Photo 11: Phase out of transformer)

7.2. Misc. Services

7.2.1. Misc. Services

The general phasing out of equipment goes with the dismantling procedure, which has to follow the final safety, noise, or vibration equipment as well as all activities of dismantling the transformer. Before any activity on the transformer can start, it must be ensured that the transformer is de-energized and that the oil is drained. The oil must be stored in a safe container and the transformer must be grounded. The transformer must be grounded in a safe manner and the transformer must be grounded in a safe manner.

The winding core should be handled off as metal scrap. It is recommended that the transformer be dismantled in a safe manner and the transformer be dismantled in a safe manner.

It is recommended that the transformer be dismantled in a safe manner and the transformer be dismantled in a safe manner.

It is recommended that the transformer be dismantled in a safe manner and the transformer be dismantled in a safe manner.



Photo 12: Phase out of transformer (transformer Phase out) (Photo 12: Phase out of transformer)

7.	Phase Out.....	52
7.1.	Phase Out of Transformers.....	52
7.2.	Phase Out of Capacitors.....	53
7.2.1.	Preparation.....	53
7.2.2.	Dismantling.....	54
7.2.3.	Phase Out of Other Equipment.....	54
7.2.4.	Maintenance of In-Service PCB Equipment.....	54

7.1 Phase Out of Transformers



Phased out Equipment = No Value...



Review of ESM Guide and Factsheets on PCB – Istanbul, April 7, 2015

7.2 BEP Phase Out of PCB LV Capacitors



Review of ESM Guide and Factsheets on PCB – Istanbul, April 7, 2015

7.2.2 Caution with phased-out Caps!



7.2.2 Attention: Isolators / Bushings



7.2.4 Maintenance In-Service Equipment

... shall be shifted to 4.1.1 on page 38 as already addressed




Let's review and discuss Chapter 7!



Chapter 8 - Packing



Sub-chapters 8



8.	Packing.....	56
8.1.	Packing According to ADR.....	56
8.2.	Summary of Possible Containers for PCB Transports.....	57
8.2.1.	Labelling of the Packaging.....	61
8.2.2.	Labelling for Storage or Transport.....	61
8.3.	Handling of Packed Waste.....	63

8 Introduction

- The practices in packaging (as well as storing and transportation) of PCB waste always have to be based on prevailing legislation and regulations.
- In case the national regulations are not yet in force, or are on a lower standard than the internationally approved regulations and internationally acceptable standards must be applied.

8 Packaging of PCB Containing Waste

- Packaging must be done in accordance with transport regulations to be able to transport the waste without repackaging
- Globally Harmonized System of Classification and Labelling of Chemicals (GHS)
- The European Agreement concerning the International Carriage of Dangerous Goods by Road (ADR)
- IMDG Code or International Maritime Dangerous Goods Code
- IATA DGR (IATA regulations on the transport of hazardous goods/air transport)
- **ADR**, RID, IMDG packaging instructions mostly similar

8.1 Table 17: Code UN Approved Drum

UN-1A1/Y...
UN-1A2/Y...

Letter/Number	Definition
UN	Symbol of the United Nations or the letters UN
1A2	Code for packaging type
Y	Two-part code: Letters of packaging group
400	For solids: Maximum gross weight in kg (example)
03	The last two figures of the year of manufacture (example)
CH2025	Manufacturer's code (example)



8.1 Production & Tests



8.1 Certificate of Approval for Packaging



ZULASSUNGSSCHEIN
CERTIFICATE OF APPROVAL



BAM
Bundesanstalt für
Materialforschung
und -prüfung








8.2 Summary of possible containers ...




8.2 Packaging of PCB Transformers


PCB Transformers:

- Cooling fluid drained prior to transportation
=> oil into UN drums, IBC liquid containers.
- Transformers in a steel tray (during storage and transport),
volume 125% of liquid PCB remaining in transformers.
- Minimum height of the side of a tray 80 cm for
transportation.
- Absorbent in the tray, absorbing capacity 1,1 times of the
volume of the oil.

8.2.2 PCB Label – Capacitors and Liquids

		UN Number
Multilingual	HAZARDOUS WASTES DECHETS SPECIAUX SONDERABFÄLLE	UN 2315
Waste Identification Code	99 99 99	
Waste Designation	POLYCHLORINATED BIPHENYLS, LIQUID	
UN Number	UN 2315	
Tracking Form Number	AA 123 123 123	
		UN Classification

8.2.2 PCB Label – Solids


		UN Number
Multilingual	HAZARDOUS WASTES DECHETS SPECIAUX SONDERABFÄLLE	UN 3432 
Waste Identification Code	99 99 99	
Waste Designation	POLYCHLORINATED BIPHENYLS, SOLID	
UN Number	UN 3432	
Tracking Form Number	AA 123 123 123	
		UN Classification

8.2.2 Labelling of PCB Wastes - Sea Transport

Labels according to IMDG for sea transport

POLYCHLORINATED
BIPHENYLS, LIQUID


UN 2315



Liquid PCB and capacitors marked with UN nr. 2315, label nr. 9 and marine pollutant label

POLYCHLORINATED
BIPHENYLS, SOLID

UN 3432



Solid PCB waste marked with UN nr. 3432, label nr. 9 and marine pollutant label


Let's review and discuss Chapter 8!



Chapter 9 - Temporary Storage



Sub-chapters 9



9.	Temporary Storage.....	64
9.1.	Temporary Storage - On Site	64
9.2.	Central Storage Platform	65

9 Criteria to be considered

Choice of Site

- No Presence of Ecological Reserves
- Distance to Rivers or Groundwater
- No Residential or Farming Areas
- If industries nearby, what kind of (e.g. food processing plants)
- Consider Possible Effects of Incidents



9.1 Temporary Storage on site - continue


- storage shall not exceed 12 months
- Minimum Requirements fulfilled (see Table 20)
 - Packing
 - Building
 - Authorization & Control
- No luxury solutions
(as example on Picture 86)



9.1 No luxury solutions: BAT/BEP Upgrade



9.2 Central storage platform (HazWaste)



9.2 ... continue

- Potential Hazards (Health, Environment)
- Area preparation
 - Ground preferably sealed / dewatered
 - Fire Fighting Precautions
- Logistics
 - HazWaste transportation
 - Forklifts / crane available
 - loading/offloading area secured
- Capacity
 - suitable for the area/country
 - not too big (INTERIM)!




9.2 Central Storage Platform Considerations

- Foundation
- Floor
 - concrete or steel
 - if concrete – appropriate coating
- Curbs
 - need of containment
 - if concrete – appropriate coating
 - Ramp (suitable for Forklifts)
- Wall / Doors / Roofing
 - light metal sheet construction (or stone / concrete – solid!)
 - Doors must open to outside



9.2 Layout Building: Design considerations



9.2 Emergency Equipment in place



9.2 Further Considerations

- Spill Prevention, Control and Countermeasure Plan (SPCC)
- Database
 - kind of waste, packaging, condition, weight, volume etc.
 - Available in case of Incident
- Small Size Interim Storages
 - Used Box Containers
 - but with sealed Floor (no wood!)



12.17 Regular Inspection of Storages

- Interim Storages and Central Storage Platforms shall be inspected at regular intervals.



12.17. PCB Interim Storage Facility Monthly Inspection Report

Overview: The competent authority is required to inspect the institutions' PCB storage site on a monthly basis. This inspection is completed by a qualified individual, recorded below, and forwarded to the environmental authorities.

Name: _____ Date: _____

No.	Question	Yes	No
1	Storage is posted on the exterior of the PCB storage area and storage areas are secure and only accessible to authorized personnel.		
2	PCB equipment and drums of PCB material are stored in a manner that makes them accessible for inspection and the permits from from leaking fire or being released.		
3	PCB storage site is in good condition, including: <ul style="list-style-type: none"> Floors Lighting Stairs Drains (if present) Weatherproof roofs Fences and walls 		
4	Is each PCB storage area equipped with, where practical, an appropriate fire suppression system and alarm system to adequately address the quantity of PCBs stored on site?		
5	Has the fire extinguisher been inspected within the last month? Is it in working condition?		
6	Where PCB equipment that is not in a container (other than drum) PCB equipment and contains PCB liquids, is stored on a floor of steel, concrete or any other similar durable material that is capable of absorbing any PCB liquid. The concrete floor and sides are sealed with an impervious, shailable, PCB resistant coating.		
7	PCB equipment not stored in containers and contains PCB liquids is stored on a floor of steel, concrete or any other similar durable material, is placed in containers: <ul style="list-style-type: none"> a) For one piece of equipment or container, 125% of the volume of the PCB liquid present; or b) For more than one piece of equipment or container, the greater of twice the volume of the PCB liquid in the largest piece or 25 per cent of the volume of all the PCB liquid stored. 		
8	PCB storage site floor drains, weeps or other openings in the floor are: <ul style="list-style-type: none"> a) closed and sealed to prevent the release of liquids, or b) connected to a closed drainage system suitable for PCB collection that terminates in a location where any spilled liquids are contained and recovered and where the spilled liquids, and c) will not create a fire hazard or a risk to public health or safety. 		
9	Sealed containers of PCB material, other than drums, are used only if the containers are designed for stacking, and are stacked no more than two containers high.		
10	Where drums containing PCB material are stacked, separate the drums from each other by pallets and, in the case of drums of PCB liquid, stack the drums not more than two drums high.		

Completed By: _____ Contact Person: _____

Please retain a copy for your records and forward the original to: _____

PCB Inspection Checklist - 2016 Revision - 12/16/15 - 12/16/15


Let's review and discuss Chapter 9!



Chapter 10 - Transport



Sub-chapters 10



10.	Transport.....	71
10.1.	International Regulations for the Transport of Hazardous Goods	71
10.2.	ADR.....	71
10.2.1.	Obligations of Main Actors.....	71
10.2.2.	Documentation.....	72
10.3.	National Transports.....	73
10.4.	Transboundary Movement of Hazardous Waste.....	73
10.5.	Loading and Safety Check before Transport Takes Place	73
10.5.1.	Loading on a Truck for Local Transports	74
10.5.2.	Loading of Containers for International Transport	74
10.6.	Waste Transportation by Air.....	76

10.1 (Inter-) National Transport Regulations

- **ADR** (European agreement on the international road transport by sea)
- **RID** (Regulation for the international transport of hazardous goods on railways)
- **IMDG** (International maritime dangerous goods code/transport by sea)
- **IATA DGR (IATA regulations on the transport of hazardous goods/air transport)**



Review of ESM Guide and Factsheets on PCB – Istanbul, April 7, 2015



MedPartnership

3

10.2.2 Documentation

The following documents must accompany every shipment in accordance with the ADR:

Movement document

The following data of every single good/waste must be mentioned on the movement document:

- UN number, with the letters «UN» in front of the number
- If the goods are wastes, the word «WASTE» must be written in front of the UN number
- The official designation (Polychlorinated Biphenyl) plus the technical term (PCB)
- UN class (9)
- Packaging group
- Packaging type and number of packaging
- Total quantity of each dangerous good with different UN number
- Name and address of exporter
- Name and address of importer

Review of ESM Guide and Factsheets on PCB – Istanbul, April 7, 2015



MedPartnership


4

10.3 National Transports

- In accordance with National Regulations
- Considering ADR etc.
- Recommendation to use a tracking form also for national transports:

Tracking Form No. AA 123 123 123

Consignor (name, address)	Contact person: Telephone: Date:
Waste (designation / chemical composition of waste)	Waste identification code: Quantity (kg / liter): Packaging (type / number):
Consignee (name, address)	Contact person: Telephone: Quantity (kg / liter): Method of disposal: Date:
Carrier (name, address)	Contact person: Telephone: Means of transport: Date:



10.4 Transfrontier Movement of Waste

Basel Convention on the control of transboundary movements of hazardous wastes and their disposal (1989)

TRANSBOUNDARY MOVEMENT OF WASTE - Notification BASEL CONVENTION

1. Exporter (name, address)	2. Importer (name, address)	3. Consignor (name, address)	4. Consignee (name, address)
5. Waste identification code	6. Quantity (kg / liter)	7. Packaging (type / number)	8. Method of disposal
9. Date of shipment	10. Date of receipt	11. Date of disposal	12. Date of return
13. Signature of exporter	14. Signature of importer	15. Signature of consignor	16. Signature of consignee

TRANSBOUNDARY MOVEMENT OF WASTE - Movement document BASEL CONVENTION

1. Exporter (name, address)	2. Importer (name, address)	3. Consignor (name, address)	4. Consignee (name, address)
5. Waste identification code	6. Quantity (kg / liter)	7. Packaging (type / number)	8. Method of disposal
9. Date of shipment	10. Date of receipt	11. Date of disposal	12. Date of return
13. Signature of exporter	14. Signature of importer	15. Signature of consignor	16. Signature of consignee

Export Regulations

Notification Procedure in accordance with Basel Convention

In case the PCB waste will be exported for acceptable and permitted final disposal, the Basel Convention rules shall be followed.

- A notification form completed by the owner of the waste and delivered to the national competent authority. The notification procedure contains the following steps and procedures
- Notifier is the original producer or the owner of the waste, or licenced collector, dealer or holder of the waste if they have been authorised in writing by the original producer or holder of the waste

Export Regulations

Notification Procedure in accordance with Basel Convention

A contract between the notifier and the receiver of the waste. The contract has to include the following items:

- An obligation to the notifier to take the waste back if the waste did not end up at the original destination
- An obligation to the receiver to dispose of the waste in an environmentally sound method
- The receiver has to inform the notifier and competent authorities concerned within 3 working days from the reception of the waste
- The receiver has to deliver a certificate to the notifier and competent authorities concerned that the waste has been disposed of within 13 months from the reception of the waste

Export Regulations

Notification Procedure in accordance with Basel Convention


- A financial guarantee set by the notifier (or in some cases the receiver of the waste can organise the guarantee).
- The guarantee is needed to ensure that the waste will be returned and an alternative disposal can be arranged in case the original receiver cannot receive the waste
- A duly motivated request written by the authority of the notifying country has to be attached to the notification to be addressed to the competent authority of the receiving country.
- This request should state that the country of origin of the waste does not have proper treatment facilities or capacity for the disposal of the waste

Export Regulations

Notification Procedure in accordance with Basel Convention

- The notification form will be sent by the competent authority to the receiving country and to possible transit countries.
- If within 60 (30 in EU) days the transit country does not react, it is interpreted as "a silent acceptance" of the transit.
- The transit country may object and deny the transit.
- Some countries have forbidden import and even transit of hazardous waste in their territory.
- If the transportation has been approved by all authorities the transport can be carried out. All transport documents including the movement document have to follow the consignment.



10.5 Loading of Containers



10.5 Expert Loading of Containers



10.5 20' Box Container – Precaution Sea



10.6 Transport by Air – An Alternative?

- Air transports of UN no. 2315 and 3432 would basically be possible.
- However, IATA regulations do generally refer to:
 - › Substances in their original, pure form
 - › IATA does NOT refer to wastes
- It is **not appropriate** and **not recommended** to transport Hazardous Waste wastes by air.



Let's review and discuss!




Chapter 11 - Treatment and Disposal



Sub-chapters 11

11. Treatment and Disposal	77
11.1. Technologies and Methods in General.....	77



11.1 Destruction Technologies/Capacities

<http://www.unep.org/tools/default.asp?ct=chem3>

UNITED NATIONS ENVIRONMENT PROGRAMME
United Nations
UNEP

Survey of Currently Available Non-Incineration PCB Destruction Technologies

First Issue August 2009

Prepared by UNEP Chemicals

IOMC

BASEL CONVENTION

DESTRUCTION AND DECONTAMINATION TECHNOLOGIES FOR PCBs AND OTHER POPs WASTES UNDER THE BASEL CONVENTION

A Training Manual for Hazardous Waste Project Managers


Volume A

Secretariat of the Basel Convention

<http://www.basel.int/Implementation/Publications/TrainingManuals/tabid/2363/Default.aspx>

11 Factsheets POPs Destruction Technologies

- „Factsheets for POPs Destruction Technologies” providing details on various decontamination/disposal methods are being prepared by BCS



11 Criteria for the evaluation of disposal options

- Type of PCB waste:
Transformer, capacitor, PCB oil (pure or contaminated), soil, solids like metal, wood, paper, PPE etc.
- Contamination of PCB waste
- Total quantity of PCB wastes:
Local treatment should only be envisaged with quantities exceeding certain limits (depending to technology and size of plant)
- Condition of PCB containing transformers:
Is reuse an option?



11 Available Technologies for PCB Destruction

Technologies for the treatment of:

- Oils
- Transformers
- Capacitors
- Associated waste (solids, PPE, soil etc.)

11 General Objectives

- The technology must comply with BAT and BEP standards and all relevant Conventions (Basel Convention, Stockholm Convention, etc.).
- Destruction efficiency shall be greater than 99.99%.
- All by-products and residues which cannot be land-filled in the country itself must be exported for final treatment in approved plants.

11.1 Combustion Technologies

Overview

High-temperature incineration

Co-incineration in cement kilns



11.1 Non-Combustion Technologies

Overview

Autoclaving

Alkali metal reduction

Ball milling

Base catalysed decomposition

Catalytic hydrodechlorination

Gase-phase chemical reduction

Plasma Arc

Potassium tert-butoxide method

Pyrolysis / waste-to-gas conversion technology

Supercritical water oxidation

Vitrification

Bio-degradation

11 Conclusion Non-Incineration Technologies


- Potential benefits
 - Does not generate Dioxins and Furans
 - Enables the (re-) use of certain materials
 - Probably better accepted by the public opinion
 - Less expensive than incineration (usually)
- To be considered
 - May contain residues for re-processing
 - Lot of “black box” technologies on the market
 - Technologies often not yet commercially approved
 - Need of strict safety controls
 - Expensive in small quantities

11 Conclusions Disposal in General



- In countries with access to incineration, it is the most widely used technology for disposal
- However, alternative technologies for
 - transformers (solvent washing and metal recovery)
 - oils (sodium treatment)
 are available and used, at a lower cost and for smaller volumes of waste material than it is usual for incineration.
- Some components are harder and more expensive to decontaminate completely
- Be aware of “black box” solutions!
- Consider technologies that can be used generally for HazWaste

Let's review and discuss Chapter 11!



12 Annexes



12. Annexes In-Depth Information Web

12. Annexes

12.1. In-Depth Information on the Internet: Conventions and Guidance Documents

- Basel Convention
www.basel.int
- Stockholm Convention
www.pops.int
- FEN PCB Elimination Network
www.pops.int/fen
- Guidance documents on PCBs
<http://chem.pops.int/Implementations/PCBs/DocumentPublications/tabid/655/Default.aspx>
- Rotterdam Convention
www.pic.int
- UNEP Chemicals, many useful reports can be viewed and downloaded via this website
www.chem.unep.ch
- OPA Global Programme of Action for the Protection of the Marine Environment from Land-based Activities, a lot of useful information
www.unep.org/opa
- Identification of PCB containing capacitors, manual for electricians, very detailed list, Australia, 1997 http://www.sae.gov.au/industry/industry_gov_files/industry_273670116_1226123252325264848936.htm
<http://www.unep.org/chem/chemicals/pcb-contaminating-capacitors-information-booklet-electricians-and-electrical.pdf>
- Guidelines for the Identification of PCBs and Materials Containing PCBs, UNEP 1999
<http://www.pops.int/documents/guidance/identification/pcb01.pdf>
- GEF - Global Environment Facility
www.gef.org
- UNITAR - United Nations Institute for Training & Research
www.unitar.org
- UNIDO - United Nations Industrial Development Organization
www.unido.org
- Recommendations on the Transport of Dangerous Goods - Model Regulations
http://www.unxref.org/publications/publications.aspx?ID=166&cat_c=1
- International Chemical Safety Cards
<http://www.ichsc.gov.ni/ichsc/psx/ictar.html#langeng>
- Minamata Convention
<http://www.mercuryconvention.org>
- SAICM - Strategic Approach to International Chemicals Management
<http://www.saicm.org>
- REACH - Registration, Evaluation, Authorisation and Restriction of Chemicals
http://ec.europa.eu/enterprise/sectors/chemicals/reach/index_en.htm

Please note that many documents and publications are under revision. Therefore please check the actualities in the World Wide Web periodically.



12.3 Details PCB Treatment Technologies

12.3. PCB Pre-Treatment Technologies (Extract only)

Transformers are cleaned in a first step. The liquids will be disposed of separately. The "empty" transformer will contain approx. 3 to 10 % liquid, 10 % is related to Askarel because of the higher density. Additionally, the content of wood, paper etc. is responsible for the remaining liquid. Separate treatment is necessary for transformers. "Pure" PCB transformers cannot be cleaned economically for reuse. The same applies to all other devices that contain "pure" PCB. This transformer need specific treatment. In case of Askarel transformers, solvent extraction is a possibility. Some companies put the core into an autoclave and extract PCB by solvent and vacuum. Empty capacitors are cleaned the same way. Alternatively, the transformer shell can be used as autoclave, and solvent is circulated through the empty transformer. In both cases the solvent is re-distilled, and the PCBs are expected to be incinerated. Various studies have shown that only solvent can remove Askarel from non-porous materials. The use of mechanical solvents would be more ecological, they are low flashpoint, however, increases the inflammability risk. Therefore, chlorinated solvents like Perchlorethylene are used. Special attention must be paid to the potentially occurring emissions.

After these cleaning processes transformer coils are carefully disassembled. Porous parts still do contain PCB in the interior parts, and are packed into suitable packaging for final disposal at licensed facilities. Even after that pre-treatment by solvent, PCBs are still present in the winding and between the core sheets. Therefore, core sheets and winding require additional cleaning processes in specific washing machines using again solvent. After that procedure, random samples must be taken in order to check the success of the process. If all metal parts are PCB-free they can be sold as secondary raw material.

12.4. PCB Non Combustion Technologies

Dechlorination, in general, Chemical dechlorination is based on reactions with either an organically bound alkali metal or an alkali metal oxide or hydroxide. Dechlorination processes are well developed for the treatment of liquid PCBs and PCB contaminated oil. The chlorine content is converted to inorganic salts which can be removed from the organic fraction by filtration. Resinous take place under inert atmosphere. Some companies provide mobile treatment plants, which can be used on an operating transformer in the field. There are several types of this technology available. Two suppliers of dechlorination technologies, and their processes are briefly described below:

Continuous Dechlorination Process (CDP)

The CDP Process, developed and patented by Iva Maron, is a process capable of dechlorinate and dechlorinate the PCBs present both in the oil and the inner parts of the transformer (see also continuous mode and closed circuit, with circulation of waste oil, with an efficiency of 99.9 %, as accordance with European Directive 2002/95/EC, The Decommissioning Mobile Unit (DMU) used for the process designed and developed by Iva Maron equipped innovative technologies and unique environmental protection systems, to ensure safe working conditions. The DMU is mobile, then can operate in all logistic scenarios and thanks to specially developed ad-hoc protocols, they can also operate on equipped and under load transformers.

SPHIL Oil Dechlorination Process

The process developed by SD Myers (myers.com/pcb-dechlorination.html) is very specific as the scheduled wastes it is able to treat, as it is designed to treat PCB contaminated transformer oils with concentrations below 10 000 mg/kg without the need to remove the transformer or take the transformer out of service. Concentrations below 2 ppm are achievable. It involves circulating the transformer fluid through a filtration system and the residual PCB concentrations are below detection. The treatment circulates the fluid through the transformer liquid, flushes the PCBs from the transformer windings and other internal components. The treated oil is then suitable for re-treated use. Leaching from the porous parts of the transformer such as wood and paper insulation can occur and the transformer may require another treatment after some time.

12.5. PCB Combustion Technologies

High temperature incineration is the most common technology for destruction of waste with high PCB content in Europe and North America. Modern incinerators have an efficiency of at least 99.9999 % for highest levels of PCB. In order to reach this destruction efficiency, the incinerators operate at temperatures higher than 1200 °C, with a residence time greater than 2 seconds, under conditions that ensure appropriate mixing. The disposal costs are in general lower for waste with high content PCB than for the other disposal methods. In some countries public resistance against hazardous waste incineration has led to the development of different non-incineration technologies although the disposal costs may be higher for these technologies. The formation of dioxin and furan by the incineration has been one of the main concerns. If high temperature incineration is used the incinerator should meet a limit value for emission of dioxin and furan of < 0.1 mg E-TEQ/Nm³ at 11% O₂. Most incinerators are large stationary facilities but in some countries e.g. Canada also small mobile incinerators are operating on a commercial basis. Their capacities are low compared to the stationary ones.

High temperature incineration is the main solution in Europe for "pure" PCB. Various incinerators guarantee extreme low emissions. The incinerators can accept all types of PCB waste that can either be pumped (liquids) or packed into drums. PCBs in drums are fed into the incinerator kiln by elevator. Liquids are usually pumped from storage tank through injectors into the kiln. Transformers have to be dismantled prior to disposal, due to their size.

Co-incineration in cement kilns: The co-incineration of PCB containing liquids is usually limited to the range of 50 to 1 000 ppm PCB in the oil. Higher levels of chlorine would have negative impact to the quality of cement. As rule of thumb, chlorine should usually be limited to 300 to 500 g cement chloride for a kiln without by-pass and 400 to 750 g for a kiln with by-pass, but the chlorine balance must be proved in each instance. It is important that the process control knows the chlorine balance of the process in operation. Additionally, the co-incineration requires proper flue gas cleaning systems.

A number of cases of PCB destruction have demonstrated that the PCB can be satisfactory destroyed in the kilns, but large scale use of cement kilns for destruction of PCBs has not been reported from developing countries. If cement kilns are used to incinerate wastes, the standards of the applicable regulations have to be met. One can refer to the regulation 94/67/EC of the European Council on the incineration of toxic wastes.

12.6. PCB Emerging Technologies

There are a number of emerging technologies, which are not presented in the frame of this handbook. There is a GEF supported review of emerging, innovative technologies for the destruction and decontamination of POPs and the identification of promising technologies for the use in developing countries¹ available in the internet:

http://www.chem.unep.ch/rapid/rapid.htm#PCB_decontamination/PCB%20dechlorination/PCB%20dechlorination
http://www.chem.unep.ch/rapid/rapid.htm#PCB_dechlorination

12.7. PCB Treatment and PCB Disposal Companies

Enterprises from all around the world are listed under the following link:

http://www.chem.unep.ch/rapid/rapid.htm#PCB_dechlorination/PCB%20dechlorination/PCB%20dechlorination
Please note that some websites might be updated in March 2015. Please check periodically the WWW about new publications and downloads.



Let's review and discuss Chapter 12!



End of Guide Review



Factsheets



Aims and Objectives I

The purposes of these five PCB Management Factsheets are:




- To provide an extract of **easy technical** guidance on different aspects of PCB environmentally sound management
- To harmonize proceedings in the Region
- To provide and instrument for Awareness Raising
- The Factsheets do not aim to be “complete”; it however covers some main aspects of ESM of PCB (CA and OA), considering Guidelines of SBC and current Actualities

Factsheets

Features:

- Concise
- Comprehensible
- Related to practice




Target Groups:

- Users, workers, and technicians



Five Specific Factsheets

- Factsheet I: PCB Awareness Raising
- Factsheet II: Identification of PCB Transformers
- Factsheet III: Identification of PCB Capacitors
- Factsheet IV: PCB Open Applications
- Factsheet V: PCB Handling, Packing, Transport



Let's review and discuss!

UNEP MedPartnership

Factsheet I

PCB AWARENESS RAISING

What are PCBs?

Polybrominated Biphenyls (PBBs) are chlorinated, substituted biphenyls. Depending on the number of chlorine atoms in their molecules, their physical, chemical, and toxicological properties vary considerably.

In the 1960s and 1970s maximum PCBs production levels were reached. Between 1983 and 1993 production of PCBs was stopped in most countries.

PCBs is one of the Persistent Organic Pollutants (POPs) regulated under the Stockholm Convention, which requires immediate international action. PCBs shall be eliminated by 2028.

Applications of PCBs

Due to their characteristics PCBs residues were used in open, partially open and closed systems. It is important to know that PCBs applications can be found throughout all industries and do not only focus on utilities.

Typical applications of PCBs in closed systems:

- Insulation and/or cooling fluid in transformers
- Electric fluid in caps
- Hydraulic fluid in lifting equipment, trucks and high pressure pumps

Typical applications of PCBs in open systems:

- Coils (coolants)
- Anti-corrosion and surface coatings
- Paints
- Cables and cable sheaths
- Balloons and small capacitors
- Various others

PCBs Health Risks

PCBs are persistent and transported through air – by evaporating and re-condensing – the so-called "global distillation". PCBs can be found in any

part of the world, and in numerous matrices (air, water, soil, etc.).

Due to its chemical and bio-chemical stability and its high solubility in fatty tissue, the substance has entered the food chain as a bio-accumulator. PCBs are mainly taken in via stomach and intestine, the skin and respiration.

On the basis of sufficient evidence of carcinogenicity in humans and experimental animals, the International Agency for Research on Cancer (IARC) classified PCB as carcinogenic to humans (Group 1).

Effects on Human Health

Some of potential damages related to long term exposure of small doses of PCBs are:

- Damage to liver and kidneys
- Influences on the thyroid hormones, and possible effects on development of the brain
- Influences on the reproductive system and especially unborn children
- Possible carcinogenic effects
- PCBs are highly toxic in case of an acute exposition. The symptoms of an acute poisoning include: Chills, fever, rash, and headache.

PCBs in Fire

The highly toxic substances Dioxin and Furan are unintentionally formed and released from thermal processes (fires) involving PCBs as a result of incomplete combustion. The health effects of such exposures are:

- Influences on the immune system
- Deformations of unborn children
- Chloracne

PCBs Elimination Network (PEN)

The PEN is designed as an equal partnership for stakeholders from different sectors with an interest in the environmentally sound management of PCBs interacting within a voluntary framework. It offers substantial information exchange and support for countries to achieve the goal of the Stockholm Convention related to PCBs. For more information please visit: www.unep.org/pen



Review of ESM Guide and Factsheets on PCB – Istanbul, April 7, 2015

Let's review and discuss!

UNEP MedPartnership

Factsheet II

IDENTIFICATION OF PCB TRANSFORMERS

Sampling Material

- Appropriate pairs / size
- Drop tray (metal or PE)
- Glass vials, 30-50 ml (dark, wide opening)
- Hoist (plastic hoses, 5mm)
- Syringes, 30-100 mm
- Hand pumps
- Funnels
- Carrying box (plastic for vials/bottles)
- Sampling labels (for vials, transformer, report)
- Water proof pens
- Sampling/inventory reports










Personal Protective Equipment and Tools

- One-way protective gloves (Nitrile, PVC, Neoprene or rubber)
- Safety goggles
- Toxicity test set of maintenance tools (crowbar, piners, locking pliers, hammer)

Caution

- Always use new or clean(er) sampling materials
- Collect waste in appropriate/protected place
- Waste disposal in environmental sound manner


Step-by-Step Handling of a Transformer




Review of ESM Guide and Factsheets on PCB – Istanbul, April 7, 2015

Factsheet II – Identification of PCB Transformers



Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

Let's review and discuss!



Review of ESM Guide and Factsheets on PCB – Istanbul, April 7, 2015

Let's review and discuss!



Review of ESM Guide and Factsheets on PCB – Istanbul, April 7, 2015

Factsheet III – Identification of PCB Capacitors



Review of ESM Guide & Factsheets on PCB – Istanbul, April 7, 2015

Let's review and discuss!

MedPartnership

Factsheet IV
PCB OPEN APPLICATIONS

Shipping industry can be an important source of unintentional cross-contamination. Current national PCB inventory activities mainly focus on closed applications, such as sealing fluids in electronic equipment, e.g. transformers, capacitors, and switches.

Examples of Open Applications

Open applications of PCBs for example include, caulks/sealants, paints, anti-corrosion coatings, surface coatings, cables and cable sheaths, and many more. The largest open application of PCBs has been caulks/sealants as well as anti-corrosion coatings and paints in buildings and other constructions such as pipes or machinery.

Table of open PCB applications:

Caulks (sealants)	lubricating fluid in oils and greases, cutting oils, chain lubricants and stamping agents
Paints and glazes	adhesives
Anti-corrosion coatings (indoor and outdoor)	carbonless copy paper
Surface coatings	pesticide extenders (insecticides)
Sealed double glazing (windows)	inks
Cables and cable sheaths	

Private Buildings to Check

Many buildings worldwide constructed or renovated specifically between the 1950s and the early 1980s often contain PCBs in a great variety of applications, which send PCBs into the environment. In buildings PCBs can contribute directly to human exposure via indoor air resuspension and dust.

PCBs in open applications were used in all kind of industrial, public and private buildings as well as in high power, nuclear power and water treatment plants, military installations, the car and shipbuilding as well as the mining industry.





The Basel, Rotterdam and Stockholm Conventions:

An overview



The **Basel**, **Rotterdam** and **Stockholm** Conventions



Basel Convention



Rotterdam Convention



STOCKHOLM CONVENTION

Adoption	22 March 1989	10 September 1998	22 May 2001
Entry into force	5 May 1992	24 February 2004	17 May 2004
Number of Parties to date	182	154	179



www.brsmeas.org

[@brsmeas](https://twitter.com/brsmeas)

Party status Others



Basel Convention



Rotterdam Convention



STOCKHOLM CONVENTION

Fiji	-	-	20.6.01
Korea (DPR)	10.7.08	6.2.04	26.08.02
Mongolia	15.4.97	8.3.01	30.4.04



www.brsmeas.org

[@brsmeas](https://twitter.com/brsmeas)

Scope

4


- **Basel** covers wastes listed in Annex I, as further elaborated in Annexes VIII and IX, and possessing hazardous characteristics (e.g. explosive, flammable, poisonous, infectious, corrosive, toxic, ecotoxic), as well as household wastes (“other wastes” of Annex II). Wastes defined as hazardous under national legislation can also be covered.
- **Rotterdam** covers 47 chemicals (33 pesticides and 14 industrial chemicals) in addition to other chemicals that have been banned or severely restricted for health or environmental reasons by Parties.
- **Stockholm** covers 22 POPs: 14 pesticides, 8 industrial chemicals and by-products.


www.brsmeas.org

@brsmeas


Why these 3 Conventions are working together ?

5


www.brsmeas.org

@brsmeas


International trade




Information exchange



Import and export information



Transboundary movements of wastes



Basel Convention Centres

Stockholm Convention Centres

ASIA AND THE PACIFIC <ul style="list-style-type: none"> • CHINA • IRAN • INDONESIA • SPREP (Samoa) 	ASIA AND THE PACIFIC <ul style="list-style-type: none"> • CHINA • IRAN • KUWAIT • INDIA
AFRICA <ul style="list-style-type: none"> • EGYPT • NIGERIA • SENEGAL • SOUTH AFRICA 	AFRICA <ul style="list-style-type: none"> • ALGERIA • SENEGAL • KENYA • SOUTH AFRICA
CEE <ul style="list-style-type: none"> • SLOVAKIA • RUSSIAN FEDERATION 	CEE <ul style="list-style-type: none"> • CZECH REPUBLIC • RUSSIAN FEDERATION (*)
LAC <ul style="list-style-type: none"> • ARGENTINA • EL SALVADOR • TRINIDAD AND TOBAGO • URUGUAY 	LAC <ul style="list-style-type: none"> • BRAZIL • MEXICO • PANAMA • URUGUAY
	WEOG <ul style="list-style-type: none"> • SPAIN



www.brsmeas.org

[@brsmeas](https://twitter.com/brsmeas)

Thank You!

For further information please visit us at:

www.basel.int

www.pic.int

www.pops.int



The Basel, Rotterdam and Stockholm Conventions:

Export, Import and Transit Controls



CONTENT

- ❑ Import/transit/export procedures
- ❑ The Prior Informed Consent (PIC) procedure
- ❑ Border control procedures for chemicals and for wastes.

Export/import/transit controls under the **Basel** Convention



Export country requests



Transit and import countries decide




If agreed, a movement document is issued



The movement document accompanies the cargo

Import control under the **Rotterdam** Convention

ANNEX III **YES/NO**



IMPORT RESPONSES



PIC CIRCULAR



CUSTOMS CONTROL



All import responses available at:
<http://www.pic.int/Procedures/PICProcedure/tabid/1364/language/en-US/Default.aspx>

Export control under the **Rotterdam** Convention

EXPORTING
COUNTRY



LABEL REQUIREMENTS



SAFETY DATASHEET

SAFETY DATA SHEET - BREVISED	
SECTION 1 - PRODUCT IDENTIFICATION	Product Name: ...
SECTION 2 - HAZARD IDENTIFICATION	Hazard Statement: ...
SECTION 3 - ENVIRONMENTAL INFORMATION	Environmental Precautions: ...
SECTION 4 - FIRST AID	First Aid Measures: ...
SECTION 5 - PREVENTION	Prevention: ...
SECTION 6 - ACCIDENT RESPONSE	Accident Response: ...
SECTION 7 - STORAGE AND STABILITY	Storage: ...
SECTION 8 - TRANSPORT INFORMATION	Transport: ...
SECTION 9 - PHYSICO-CHEMICAL INFORMATION	Physical and Chemical Properties: ...
SECTION 10 - STABILITY AND REACTIVITY	Stability and Reactivity: ...
SECTION 11 - TOXICOLOGICAL INFORMATION	Toxicological Information: ...
SECTION 12 - ECOTOXICOLOGICAL INFORMATION	Ecotoxicological Information: ...
SECTION 13 - DISPOSAL INFORMATION	Disposal: ...
SECTION 14 - OTHER INFORMATION	Other Information: ...

Import/Export control under the **Stockholm** Convention



In case of exceptions, trade may take place:
If wastes, **BaselPIC**
If chemicals covered by **Rotterdam**

Summary of the import/export procedures

	Basel	Rotterdam (import)	Rotterdam (export)
Object	All the hazardous and other wastes covered by the Convention	Chemicals listed in annex III of the Convention.	Chemicals outside annex III that are banned or restricted by the Exporting Party
Trigger	TBM proposed by State of export to State of transit and State of import, using a notification document	Decision Guidance Document sent to all Parties	Export notification sent by State of export to State of import
Decision by the State of import (and State of transit)	Consent/ deny/ request for additional information	Consent/ no consent/ consent with conditions.	Acknowledgement
Form for expressing decision	Written decision communicated to the State of export by the import (and transit) State in the notification document	Written notification sent to the Secretariat. Notifications (so-called "import responses") made available in the PIC circular	Written
Routine customs control	Check the movement document	Check PIC circular or contact Designated National Authority (DNA). Check labelling/SFD.	Check labelling/SFD
Contact	Competent Authority	Designated National Authority	Designated National Authority


The Prior Informed Consent Procedure

Under the **Basel** Convention

Prior Informed Consent (Basel Convention)

Stage 1: Notification


99



Prior Informed Consent (Basel Convention)

Stage 2: Consent & Issuance of Movement Document


100



Prior Informed Consent (**Basel**Convention)

Stage 3: Transboundary Movement


111



Prior Informed Consent (Basel Convention)


Stage 4: Confirmation of disposal

128



The Prior Informed Consent Procedure

Under the Rotterdam Convention




Border Control Procedures

What should customs officers keep in mind when they come across chemicals or hazardous wastes?

Border Control Procedures

for chemicals

Overview of border control procedure for chemicals (import/export)



Points of Contact for Assistance

118

- **Basel** Convention: Competent Authority (CA)
<http://www.basel.int/contact-info/frsetmain.html>
- **Rotterdam** Convention: Designated National Authority (DNA):
<http://www.pic.int/home.php?type=t&id=8&sid=17&tid=8>
- **Stockholm** Convention—National Focal Point for Information Exchange (FP):
<http://chm.pops.int/Countries/ContactPoints/tabid/304/language/fr-CH/Default.aspx>


Border control Procedures

for wastes

Import/Transit/Export Controls: Overview (Basel Convention)


290

Illegal activities can occur at any of these four stages:




Border Control Procedures for Export (Basel Convention)

291




Border Control Procedures: Entry at a Transit Country (BaselConvention)

299




Border Control Procedures: Exit at a Transit Country (BaselConvention)

299



Border Control Procedures for Import (BaselConvention)

2/4



Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem
MedPartnership

Together for the Mediterranean Sea
GEF UNEP

Horizon2020

Regional Activity Centre
for Sustainable Consumption
and Production



Practical aspects of the enforcement of chemicals and hazardous wastes

Regional Meeting on ESM and combating Illegal Traffic of Chemicals and Hazardous Waste in the Mediterranean
7-9 April 2015
The Central Palace Hotel- Istanbul - Turkey

The poster features a background image of a large, modern building with a curved facade, likely the Central Palace Hotel in Istanbul. The text is overlaid on a blue wavy banner at the top. At the bottom, there is a row of logos including UNIDO, UNEP, and others.

Overview of the presentation

- Common challenges and incentives for customs officials when identifying chemicals and wastes
- Identification of chemicals and wastes: HS codes
- Visual identification of wastes
- Safety aspects
- Consequences of illegal traffic

Overview of challenges

- Mix of legitimate trade and illegal traffic
- Incentives for customs
- Detection
- Identification – Harmonized System (HS) codes
- Handling and safety procedures
- Take back procedure
- Cooperation among relevant entities



Incentives for customs

- ❑ Appropriate legal framework
- ❑ Awareness and capacity
- ❑ Focus on both import and export
- ❑ Environmental protection= policy priority at the highest level
- ❑ Clear competences
- ❑ Support from other relevant entities
- ❑ Recognition for performance



Detection: the trigger for enforcement action

- ❑ Random or routine check, international inspections/enforcement actions (e. g., WCO Operation Demeter, INECE SESN, IMPEL-TFS)
- ❑ Intelligence sharing: foreign source or local/national
- ❑ Suspicious shipment (based on appearance or information contained in the paper work):
 - ❑ Country of origin or destination;
 - ❑ Inadequate packaging;
 - ❑ Content;
 - ❑ Absence of, torn or mutilated placards and labels, broken seals;
 - ❑ Low value of the shipment.



Customs controls under the **Basel** and **Rotterdam** Conventions

	BASEL (wastes)	ROTTERDAM (chemicals)
Purpose of the control	<p>Check movement document.</p> <p>Package, labelling and transport conform to international standards;</p> <p>Suspected hazardous wastes mixed with other type of cargo;</p> <p>Hazardous wastes defined under national legislation;</p>	<p>- Chemicals under the Annex III of the Convention without consent to import (import response);</p> <p>Adequate labelling;</p> <p>Safety datasheet</p>
Prior identification	Basel Convention codes, HS codes, Movement document, Basel Convention or National Legislation, Exporter/importer	HS codes, Trade names, CAS numbers, Exporter/importer
Careful examination	Visual identification, sample analysis	Sample analysis
Who should help you?	The Competent Authority of the Basel Convention in your country	The Designated National Authority of the Rotterdam Convention in your country
Consequences of illegal traffic	Duty for State of export to take back (art. 9) if exporter responsible for illegal traffic	Not applicable

How to identify chemicals and hazardous wastes

Chemicals:

- ❑ HS codes;
- ❑ Trade names;
- ❑ Origin and identity of exporter/importer;
- ❑ CAS number;
- ❑ Sample analysis.

Wastes:

- ❑ Codes: e.g. customs (HS), Basel Convention (Annexes I, II, III, VIII and IX), EU, OECD, national;
- ❑ Designation of the waste in the **Basel** Convention movement document;
- ❑ **Stockholm** Convention definition: when POPs substances are no longer allowed for use under the Convention;
- ❑ National legislation: in case waste is defined as hazardous under national legislation;
- ❑ Visual identification: e.g., glass waste from cathode-ray tubes, contaminated paper waste, household waste, lead-acid batteries, metal cables insulated with plastics, etc.
- ❑ Sample analysis: if waste is liquid or sludge. Will require specific safety measures and expertise.



HS codes

8

- HS codes are the primary source of identification of chemicals and hazardous wastes for customs officers;
- Other indications such as the CAS numbers and common trade names can be also relevant for customs officers in order to detect if these chemicals are covered under:
 - a) the **Rotterdam** Convention;
 - b) the **Stockholm** Convention;
 - c) banned or restricted under national laws.

HS codes for chemicals (**Rotterdam** and **Stockholm** Conventions)

9

- HS codes for pure substances under the **Rotterdam** and **Stockholm** Conventions generally start by 29, 28 or 25 (ex. Aldrin 2903.52);
- HS codes for mixtures, preparations and substances under the **Rotterdam** and **Stockholm** Conventions start by 38 or 68 (ex. Lindane 3808.50);
- A list of HS codes for chemicals under the **Rotterdam** Convention can be obtained at:
<http://www.pic.int/customs/Minisite/Documents.html>

HS codes for wastes

- ❑ Most of **Basel** Convention wastes have a six digit HS code:
 - ❑ Most POPs-contaminated wastes are identified under the classification for Basel Convention wastes;
 - ❑ Interconnection table: Correlation between wastes covered by **Basel** Convention and the HS.
- ❑ **Basel** Convention wastes without an HS code:
 - ❑ Parties to make proposals for WCO consideration;
 - ❑ Use of explanatory notes;
 - ❑ Possibility for country to create national HS code by adding two digits.

Visual identification of hazardous wastes (1)



Visual identification of hazardous wastes (2)



Visual identification of hazardous wastes (3)



Visual identification of hazardous wastes (4)



Visual identification of hazardous wastes (5)




Visual identification of hazardous wastes (6)




Visual identification of hazardous wastes (7)



Visual identification of hazardous wastes (8)



Visual identification of hazardous wastes (9)



Safety and handling



Definition of hazards

- National legislation/regulation define chemicals hazards; GHS provides an international approach.
- The **Rotterdam** Convention establishes that exporting countries should provide clear hazardous indications for dangerous chemicals.
- The **Basel** Convention defines wastes hazards in Annex III (eg. Explosive - Flammable – Oxidizing - Poisonous - Infectuous – Corrosive – Toxic).
- Examples of United Nations Packaging Symbols:

Danger, Very toxic to aquatic life



Danger, toxic



Warning, gaz under pressure



Danger, flammable



Danger, may cause fire or explosion



Danger, explosive



Precautions (1)

- ❑ Any container may contain dangerous chemicals or hazardous wastes:
 - ❑ Drums,
 - ❑ In bulk: hazardous substances can be mixed with solids (metal, plastic, paper or products).
- ❑ Corrosive content? Plastic container.
- ❑ Solvent content? Metal container.
- ❑ Leaking, dented, bulging or mishandled container ? Could indicate illegal shipment.
- ❑ Lack of placards? Could indicate illegal shipment.

Precautions (2)

- ❑ Only customs officers trained to handle hazardous substances should do so.
- ❑ Precautions for untrained officers:
 - ❑ Do not open trailer doors of trucks suspected of containing hazardous substances;
 - ❑ Do not open tanks, drums, or other containers that may contain hazardous substances;
 - ❑ Do not presume that what is marked on a label, drum or container is what is inside since illegal traffickers often mix hazardous wastes with other materials;
 - ❑ Do not enter confined spaces that may contain hazardous substances.

What happens when a potential case of illegal trade is identified (1)?

Chemicals under **Rotterdam** and/or **Stockholm** Conventions:

- ❑ The chemicals are “only” banned
- ❑ Contact the designated national authority/national focal point/regional centre
- ❑ Agreement necessary with exporting country

What happens when a potential case of illegal traffic is identified (2)?

Under the **Basel** Convention:

- ❑ The TBM of the **Basel** Convention wastes not following the appropriate notification and consent procedures or resulting in deliberate dumping of wastes constitute illegal traffic.
- ❑ Illegal traffic is to be considered criminal under national legislation.
- ❑ In case of a TBM deemed to be illegal traffic as the result of conduct on the part of the exporter or generator, the State of export shall ensure that the wastes in question are:
 - (a) taken back by the exporter or the generator or, if necessary, by itself into the State of export, or, if impracticable,
 - (b) are otherwise disposed of in accordance with the provisions of this Convention (i.e. environmentally sound management).
- ❑ Contact the national CA.

Cooperation

- Cooperation with the CA in order to detect, identify and address potential cases of illegal traffic (possible task force, MoU or other relevant agreement);
- Cooperation with relevant ministries in order to develop and enforce appropriate legislation;
- Cooperation with the country of export in order to detect illegal traffic and request that the wastes be taken back;
- Cooperation with transit countries in order to detect illegal traffic;
- Cooperation with the private sector (industry, shippers);
- Cooperation with IGOs (Convention Secretariats, WCO, Interpol).



www.brsmeas.org

 @brsmeas



Thank You!

For further information please visit us at:

www.basel.int

www.pic.int

www.pops.int



The Basel, Rotterdam and Stockholm Conventions:

Tools and Materials



HS codes

- For hazardous wastes covered by the **Basel Convention**

Link:

<http://www.basel.int/Implementation/HarmonizedSystemCodes/tabid/2390/Default.aspx>

- For chemicals under the **Rotterdam Convention**

Link:

<http://www.pic.int/TheConvention/Chemicals/AnnexIIChemicals/HarmonizedSystemCodes/tabid/1159/language/en-US/Default.aspx>



Basel Convention: Guidance Elements for Detection, Prevention and Control of Illegal Traffic in Hazardous Wastes

Content

- Introduction
- Part 1. National Capacity Building and International Cooperation
- Part 2. Prevention
- Part 3. Managing Alleged and Confirmed Cases
- Part 4. Use of Electronic Information

Appendix

- Provisions of the Basel Convention and decisions adopted by the Conferences of the Parties to the Basel Convention
- Case studies/examples of successful actions of Parties
- Sampling and analysis
- Guidelines for Risk Management Approach

Available at:

www.basel.int/Implementation/LegalMatters/IllegalTraffic/Guidance



www.brsmeas.org



Basel Convention: Relevant Leaflets

Controlling transboundary movements of hazardous wastes and illegal traffic under the Basel Convention



Available

at: <http://www.basel.int/TheConvention/Publications/BrochuresLeaflets/tabid/2365/Default.aspx>



www.brsmeas.org



Basel Convention: Training Manual on Illegal Traffic for Customs Officers and other Enforcement Agencies

Content

- Introduction
- Part 1. Enforcement and the Basel Convention
- Part 2. Scope of the Convention
- Part 3. Basel Rules from Start to Finish
- Part 4. Illegal Traffic
- Part 5. Cooperation
- Part 6. Responses to a Suspect Hazardous Waste Shipment
- Part 7. Model Investigation Into Illegal Traffic of Hazardous Wastes
- Other information

Available at:

<http://www.basel.int/Portals/4/Basel%20Convention/docs/legalmatters/illegtraff/tmman-e.pdf>



www.brsmeas.org

[@brsmeas](https://twitter.com/brsmeas)

Basel Convention: Instruction Manual on the prosecution of illegal traffic of hazardous wastes or other wastes

Content

- Introduction
- Part 1. Implementation and Enforcement of the Basel Convention at the National Level
- Part 2. What Judges and Prosecutors Need to Know about the Basel Convention
- Part 3. Illegal Traffic of Hazardous and Other Wastes
- Part 4. Preparing to Prosecute a Suspected Case of Illegal Traffic
- Part 5. Sentencing for Illegal Traffic
- Part 6. Remaining Informed about Illegal Traffic and Training
- Part 7. Example of cases of Illegal Traffic

Annexes

- Definitions of Relevant Terms with Regard to Prosecutions of Cases of Illegal Traffic in Hazardous Waste
- Bibliography
- Relevant Basel Convention Articles with Regard to Illegal Traffic

Available at:

www.basel.int/Implementation/LegalMatters/IllegalTraffic/Guidance



www.brsmeas.org

[@brsmeas](https://twitter.com/brsmeas)

Basel Convention: Guidance on the Implementation of the Basel Convention Illegal Traffic Take Back Provision (paragraph 2 of Article 9) **(DRAFT)**

■ Draft from February 2013

■ Content

- Objectives of the guidance document
- Determining whether a shipment is deemed to be illegal traffic
- The take back of the wastes by the State of Export
- Action to be taken following the take back of the illegal traffic

■ Appendix

- Form for the take back of wastes deemed to be illegal traffic in accordance with paragraph 2 of article 9 of the Basel Convention: request for take back (part I) and notification of take back (part II)
- Graphic illustration of the take back procedure

■ Available at:

<http://www.basel.int/Implementation/LegalMatters/Compliance/Activities/IllegalTrafficTakeBackProvision/tabid/3195/Default.aspx>



www.brsmeas.org

[@brsmeas](https://twitter.com/brsmeas)

Basel Convention: Guide to the Control System (Instruction Manual)

■ Content

■ Part I – Description of the control procedure

- Introduction
- Wastes controlled under the Basel Convention
- Restrictions on transboundary movements of hazardous and other wastes
- General description of the control procedure
- Detailed description of the control procedure (checklists)
- Other issues of importance
- Movements that cannot be completed as intended and illegal traffic

■ Part II – Notification and movement document

- Notification document
- Instructions for completing the notification
- Movement document
- Instructions for completing the movement document

■ Appendix

- Glossary
- Categories of wastes to be controlled and of wastes requiring special consideration (annex I and II of the Basel Convention) and annexes VII and IX containing the lists A and B of wastes respectively
- List of hazardous characteristics (Annex III to the Convention)
- List of competent authorities and focal points of Contracting Parties
- List of government authority of non-Contracting Parties
- Basic elements to be included in the contract between the exporter and the disposer
- Annex IV of the Convention (Disposal Operations)

■ Available at: <http://www.basel.int/pub/instruct.doc>



www.brsmeas.org

[@brsmeas](https://twitter.com/brsmeas)

Basel Convention: Instructions for Completing the Notification and Movement Documents

Content

- Notification document for transboundary movements/shipments of waste
- List of abbreviations and codes used in the notification document
- Movement document for transboundary movements/shipments of waste
- List of abbreviations and codes used in the movement document
- Instructions for completing the notification and movement documents
 - Introduction
 - Purpose of the notification and movement documents
 - General requirements
 - Specific instructions for completing the notification document
 - Specific instructions for completing the movement document

■ Available at: <http://www.basel.int/techmatters/forms-notif-mov/vCOP8.pdf>



www.brsmeas.org

[@brsmeas](https://twitter.com/brsmeas)

Rotterdam Convention: The role of customs in the implementation of the Rotterdam Convention – Fact Sheet:

Content

- Provisions of the Rotterdam Convention Relevant to
- Labelling Requirements
- WCO and the Rotterdam Convention
- Banned and Severely Restricted Chemicals
- When trade takes place



■ Available at:

<http://www.pic.int/Portals/5/customs/Minisite/doc/Role%20of%20customs.pdf>



www.brsmeas.org

[@brsmeas](https://twitter.com/brsmeas)

Rotterdam Convention: Case studies on customs related aspects of the Rotterdam Convention

■ Jamaica's experience

- Introduction
- The legal framework
- Procedures
- Export of chemicals
- Background
- Current methods and procedures for import licensing
- Current methods and procedures for notification
- Proposed methods and procedures – import licensing
- Proposed methods and procedures – notification
- Processing C78 System for PCA sensitive entries

■ Switzerland's experience

- Background
- Current methods and procedures for import licensing
- Current methods and procedures for notification
- Proposed methods and procedures – import licensing
- Proposed methods and procedures – notification
- Processing C78 System for PCA sensitive entries

■ Available at:

<http://www.pic.int/Implementation/Customs/DocumentsLinks/tabid/1614/language/en-US/Default.aspx>



List of chemicals under the Rotterdam Convention

■ Harmonized System Codes assigned to chemicals in Annex III to the Rotterdam Convention

- Name of the chemical
- CAS number
- HS code (pure substance)
- HS code (mixtures)

■ List of chemicals listed under the Rotterdam, Stockholm and Basel Conventions

- Name of the chemical
- Related hazardous wastes definition under the Basel Convention

Available at:

<http://www.pic.int/Implementation/Customs/DocumentsLinks/tabid/1614/language/en-US/Default.aspx>

E-learning module for law enforcement officers on hazardous chemicals and wastes under the **Basel, Rotterdam and Stockholm** conventions

- ▣ Developed jointly by the Secretariat of the Basel, Rotterdam and Stockholm Convention and Interpol
- ▣ **Content**
 - Chapter 1: About the Basel, Rotterdam and Stockholm Conventions
 - Chapter 2: Import and export procedures
 - Chapter 3: Control (focus on smuggling and screening methods)
 - Chapter 4: Identification, classification and safety issues
 - Chapter 5: Dealing with suspicious of illegal trade/traffic
 - Chapter 6: Cooperation
 - Chapter 7: Final Assessment (examination)
- ▣ Available in Arabic, English, French and Spanish
- ▣ Available at: <http://synergies.pops.int/enforcementetool>



Manual for customs officers on Hazardous chemicals and wastes under the **Basel, Rotterdam and Stockholm** Conventions

Content:

MANUAL
FOR CUSTOMS OFFICERS
ON HAZARDOUS CHEMICALS
AND WASTES UNDER
THE BASEL, ROTTERDAM
AND STOCKHOLM
CONVENTIONS
2014



- ▣ Module 1: About the Basel, Rotterdam and Stockholm Conventions
- ▣ Module 2: Import and export procedures
- ▣ Module 3: Customs control
- ▣ Module 4: Identification, classification and safety issues
- ▣ Module 5: Dealing with suspicious or illegal traffic
- ▣ Module 6: Cooperation

Available at:

<http://synergies.pops.int/Implementation/TechnicalAssistance/ToolsandMethodologies/ManualforCustomsOfficers/tabid/4457/language/en-US/Default.aspx>



Questions?

□ Contact:

Tarcísio Hardman Reis, Programme Officer

Secretariat of the Basel, Rotterdam and Stockholm Conventions

Geneva, Switzerland

T: +41(0) 22 917 8341

Email: tarcisio.reis@brsmeas.org

Web: <http://www.basel.int> / www.pic.int / www.pops.int



www.brsmeas.org

 [@brsmeas](https://twitter.com/brsmeas)

Component II – MedPartnership Project



Horizon 2020



Regional Meeting on ESM and combating Illegal Traffic of Chemicals and Hazardous Waste in the Mediterranean

7-9 April 2015

The Central Palace Hotel- Istanbul - Turkey

Sub-component 2.3: Environmentally Sound Management of equipment, stocks and wastes containing or contaminated by PCBs in national electricity companies of Mediterranean countries

Project Manager: Tatiana Hema MEDPOL Officer

Project Manager SCPRAC: Manolo Clar

Manager SCPRAC: Enrique Villamore



Index



- 1. Introduction and revised action plan**
- 2. Lessons learned**
- 3. Next steps**





1. Introduction and revised action plan

Project started in 2009

Countries participating

- Albania
- Egypt
- 3 countries did not continue



2012 project revision on participating countries and Action plan

- Bosnia & Herzegovina
- Turkey



1. Introduction and revised action plan

1. Support for the establishment of a **National PCBs management team;**





1. Introduction and revised action plan

2. Development of 9 awareness and training national and regional **workshops on PCBs management** (theoretical and practical) to provide local capacity and identify countries needs;



1. Introduction and revised action plan

3. Support the **PCBs inventory in participating countries:**

1. **Grant PCBs screeners / analysers;**
2. **Training on the use of PCBs analyzers;**
3. **Audit and oil sampling of possible PCBs stakeholders (sites) by a PCB national and international team;**
4. **Analysis and identification of PCB equipment and liquids.**





1. Introduction and revised action plan

4. International tender for packaging, collection and transport for final disposal of identified PCBs;



1. Introduction and revised action plan

5. Disposal of all identified PCBs quantities from participating countries:

Training of local experts on:

- Notification for export
- Handling
 - Draining of transformers
 - Packing
 - Labelling
 - Loading






1. Introduction and revised action plan

6. Development of PCB awareness and training materials:

- PCB management guide
- PCB toolkit
- PCB brochures
- PCB inventory form
- PCB handouts
- PCB website
- PCB video



1. Introduction and revised action plan

6. Development of PCB awareness and training materials (cont.);

- Guide to identify PCBs (trade names)
- List PCB sampling lab material
- Course presentations

Programme	(MedPartnership Project), Activity 2.3
Aims	Aim to introduce environmentally sound management (ESM) to all stages of the lifecycle of electrical equipment containing or contaminated by PCBs in Egypt, Turkey, Jordan and Morocco & neighbouring countries.
Object	Guide to start preliminary identification of PCB's
Project Coordinator	UNEP MAP/ MED POL
Project Specialist	PCB's Management expert Patricia Schmidt
Date	March 2013



PCB Training Workshop in Alexandria, Egypt
From: Wednesday, 20th January, 2014, 2:00 PM - 8:00 PM
Venue: International Training, Hotel, Green Tower Hotel, Alexandria
Venue practical training: Hotel, The Nubia Hotel and Hotel Taha Hotel

Example of equipment for PCB sampling (for 25 people)

Material	Photo	Units	Mass (kg)	Unit cost (\$)	Total cost (\$)	Company
Glass bottles		1000	0.5	0.75	750.00	
Shakers		100	0.2	9.00	900.00	
Sampling box		100	0.1	17.00	1700.00	
Gloves, Nitrile, PVC (temperature of Rubber)		100	0.1	13.00	1300.00	

PCBs: قائمة المواد المستخدمة في أخذ العينات لـ PCBs


المادة	الكمية	الوزن (كجم)	التكلفة لكل وحدة (\$)	التكلفة الإجمالية (\$)	الشركة
زجاجات زجاجية	1000	0.5	0.75	750.00	
مخفوفات	100	0.2	9.00	900.00	
صناديق أخذ العينات	100	0.1	17.00	1700.00	
قفازات نيتريلا، PVC (درجة حرارة المطاط)	100	0.1	13.00	1300.00	



1. Introduction and revised action plan

"PCBs in the Mediterranean" website:

www.pcbsmed.org



1. Introduction and revised action plan

PCB awareness video



https://www.youtube.com/watch?v=nGQLJtI4tz0&feature=player_embedded



1. Introduction and revised action plan

Achievements 2013-2015

- **12 units delivered** of semimobile L2000DX analyser/screener
- **157** local experts to **audit transformers/ capacitors** and use of L2000DX Analyser;
- **239** local experts on **PCBs management** (theory and practice);
- **41** local experts on **PCB handling**;
- **9** local experts on **import export of PCB** (notification process).
- Up to **950 tons** identified for disposal purposes
- **1 regional guide** on PCB management
- **PCB Factsheets** per each GEF eligible country



1. Introduction and revised action plan

Achievements 2013-2015

- Training on **notification procedure** in Turkey
- Practical **training on packing and exporting** in Turkey
- **Disposal** started in Turkey
- **Notification procedure** started in Bosnia Herzegovina,





1. Introduction and revised action plan

Expected outcomes until June 2015

- Conducting Training on notification process and handling In Egypt and Bosnia & Herzegovina
- Continue and finalize the disposal process



2. Lessons learned

1. Ownership and leadership of the project by the country is a must.
2. Lack of human resources, budget and time from the Ministries. **Solution: Hiring local consultants to provide support;**
3. Phase out plans to replace in-use PCBs transformers. **Solution: The State may promote replacement of contaminated transformers;**





2. Lessons learned

4. Concerns from private sector about ownership of PCBs and access for facility audit. **Solution: PCB awareness and training and inspectorate legal enforcement;**
5. PCB reliable inventory data was not available in all countries and is key to prepare a realistic plan. **Solution: In-situ audit of PCBs stakeholders and legal enforcement;**



2. Lessons learned

6. Eliminate PCBs contamination in the food chain;

Considering that PCBs soil and water contamination keeps **PCBs in the food chain**, the most effective way to stop this vicious cycle, is to **take preventive measures** to avoid this.





2. Lessons learned

6a. Control PCBs cross contamination

29 years after the ban PCBs production and trade equipment containing PCBs, the main goal should be the Control of the hot spots of PCBs cross contamination sources focusing on the below activities:

- Dielectric oil treatment facilities
- Dielectric oil treatment mobile units
- Transformers maintenance workshops



2. Lessons learned

6a. Control PCBs cross contamination

Recommended actions:

Introduce legislation, asking before drain a transformer or capacitor, must be checked using a screen equipment like L2000DX, if contains the dielectric oil contains PCBs





2. Lessons learned

6b. Control PCBs contamination of all transformers and capacitors before disposal



Recommended actions:

Introduce legislation, asking before declare a transformer or capacitor as scrap must be checked using a screen equipment like L2000DX, If the dielectric oil contains PCBs



2. Lessons learned

6c. Control PCBs import or export

Recommended actions:

Introduce throw law the obligation Custom authorities of each country should **prohibit the import or export** of transformers and capacitors new or refurbished without issuance of **CERTIFICATE AND ANALYSIS** proving that the dielectric oil is **'PCB FREE'**

PCB-free
PCB < 2 ppm

THIS UNIT HAS BEEN CLASSIFIED BY:

NAME PLATE DATA
 GAS CHROMATOGRAPHY
 SCREEN TESTING
 OTHERS: _____

Signature: _____
Date: _____
Name of Authorizing: _____
EUBMS Identification No.: _____

Manufacturer: _____
Address: _____
Contact Number: _____





2. Lessons learned

6c. Control PCBs import or export (continued)

Recommended actions:

Custom authorities shall import or export PCBs transformers or capacitors with a code different as for new or refurbished products. The PCBs transformers and capacitors are WASTE without any commercial value.



2. Lessons learned

6e. Soil contamination

The storage and operation of transformers causes

- **Soil Oil contamination**
- **Soil PCBs contamination**

It is recommended to take preventive as well remediation actions






3. Next steps to ensure long-term sustainability of results

3.1 POPs-PCBs policy reform and legal framework

- **Updating POPs-PCBs national legislation** in line with the proposed PCB management guide as appropriate
- Introduce the **obligation of all registered PCBs producers-holders**, to enter all maintenance works of each equipment during his life time, into the national PCBs database.



3. Next steps to ensure long-term sustainability of results

3.2 PCB training and awareness

Incorporate (disseminate) **PCBs awareness materials** (PCBs video, PCB brochures, website contents and PCB management guide, etc.) for use in participating countries National POP-PCB awareness program (Ministry's website, awareness and training activities, etc.).





3. Next steps to ensure long-term sustainability of results

3.3 PCB inventory and database

- All countries should develop a **national dynamic database**, with all registered equipment (transformers/capacitors);
- Enter all **input from inventories/ site audits of PCBs equipment into the national database.**




3. Next steps to ensure long-term sustainability of results

3.4 PCB final disposal

Set a **phase-out plan** considering the timeframe set by SAP MED Regional Plans on POPs under the LBS Protocol of the Barcelona Convention (2025) and the Stockholm Convention (2028);

Assure environmentally sound PCBs **disposal methods.**





3. Ideas to ensure long-term sustainability of results

3.5. Replicate and further strengthen the Medpartnership PCB example in other Mediterranean countries and new projects:

- Consider **PCB open applications** activities;
- Support countries on developing and implementing technical guide and protocol on **contaminated site remediation and related sampling**;
- **Regional cooperation.**

3.6 LBS NAP Update/ POPs and hazardous waste management is a key priority.



Egypt
Ms. Elham Refaat Said
Ahmed
Ms. Manal Farag
Ms. Hoda Moustafa
Mr. George Zarif



Bosnia Herzegovina
Mr. Senad Oprasic
Ms. Nermina Skejovic-
Huric
Ms. Maja Maretic
Mr. Mirsad Madesko



We thank you!




Turkey
Ms. Sinem Atgin
Mr. Ahmet Varir
Ms. Sabriye Ayhan
Ms. Betul Dogru
Ms. Nazly Yenil
Mr. Kemal Kurusakiz
Mr. Omer Hallac



Albania
Mr. Redi Baduni
Ms. Rovena Agalliu
Mr. Romeo Hanxhari
Mr. Pellumb Abeshi



Hazardous Wastes in the framework of UNEP/MAP



Contents

- UNEP – MAP – MED POL Programme.
- Barcelona Convention.
- HW Protocol on the Transboundary Movements of Hazardous Wastes and their Disposal in the Mediterranean.
- Strategic Action Programme SAP- MED: Targets on HW.
- The MedPartnership Project.
- First Draft on The General Framework for the Regional Strategy for Combating Illegal Trade and Dump of Hazardous Chemicals and Wastes in the Arab Region (Kalamata, 2009).
- Regional Plan on reduction of HW generation by 20% by 2010




Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem
MedPartnership

Barcelona Convention

Article 11 : Pollution Resulting from the Transboundary Movements of Hazardous Wastes and their Disposal.

The Contracting Parties shall take all appropriate measures to prevent, abate and to the fullest possible extent eliminate pollution of the environment which can be caused by transboundary movements and disposal of hazardous wastes, and to reduce to a minimum, and if possible eliminate, such transboundary movements.



Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem
MedPartnership

SAP- MED Targets on HW.

The SAP proposed targets are:

- By the year 2025, to dispose all hazardous wastes in a safe and environmentally sound manner.
- Over a period of 10 years, to reduce as far as possible by 20% the generation of hazardous waste from industrial installations.
- By the year 2010, to dispose 50% of the hazardous waste generated, in a safe and environmentally sound manner.



The Objectives of the Strategy for the Arab region on illegal trafficking.

Strategy Partnership for the Mediterranean Sea Legal Marine Ecosystem
MedPartnership

- To develop helping tools and training materials for customs.
- To put a program of sub-regional workshop for the training of trainers, depending on information technology.
- To accredit tools to identify chemicals in international trade.
- To establish links with customs organizations at both national and international levels.
- To organize sub-regional workshops to train trainers on the relevant obligations of the relevant conventions.
- To publish assistant materials at both national and regional levels.

Strategy to be updated or complemented with an action plan as need be and implemented



The MedPartnership Project.

Strategy Partnership for the Mediterranean Sea Legal Marine Ecosystem
MedPartnership

- “MedPartnership” co-funded by the GEF and involving several relevant agencies was launched by the Mediterranean countries in the framework of **UNEP/MAP** and in cooperation with the World Bank.
- The objective of the Regional Project is to support the implementation of the NAPs and SAP MED.
- **Component 2:** Pollution from Land based activities including Persistence Organic Pollutants: implementation of SAP-MED and related NAPs includes **PCBs disposal capacity building.**





Contact:

**United Nation Environmental Programme
Coordinating Unit for the Mediterranean Action Plan.
Athens, Greece.**

www.unepmap.gr

tatjana.hema@unepmap.gr

medpol.medpartnership@unepmap.gr

gelsakka2004@yahoo.com

**Thank you for your
attention**

**Merci pour votre
attention**

شكراً لحسن استماعكم

REFERENCES:

➤ **PLAN FOR THE MANAGEMENT OF HAZARDOUS WASTE INCLUDING INVENTORY OF HAZARDOUS WASTE IN THE MEDITERRANEAN REGION. MAP Technical Reports Series No. 147.**

2004 United Nations Environment Programme/Mediterranean Action Plan (UNEP/MAP) P.O. Box 18019, Athens, Greece.

➤ **First Draft on The General Framework for the Regional Strategy for Combating Illegal Trade and Dump of Hazardous Chemicals and Wastes in the Arab Region, UNEP(DEPI)/MED WG. 334/Inf. 10.**

2009 United Nations Environment Programme/Mediterranean Action Plan (UNEP/MAP) P.O. Box 18019, Athens, Greece.

Country presentations



Regional joint meeting on environmental sound management and illegal traffic of chemicals and hazardous waste in the Mediterranean.



Albania, country presentation

**7- 9 April 2015
Istanbul, Turkey**




General Overview

- **Republic of Albania has signed the Stockholm Convention on 5 December 2001 and ratified it on 4 October 2004; Focal Point established in 2012.**
- **Republic of Albania has signed the Basel Convention (1999), the Barcelona Convention (1990) and Rotterdam Convention (2010).**
- **Ministry of Environment financed by UNDP/GEF, has prepared the 1st National Implementation Plan for Reduction and Disposal of POPs (2004-2006);**
- **NIP was transmitted to the Secretariat of SC on 02/12/2007;**
- **First NIP was based on 12 initial POPs;**
- **Working Groups established**
- **POPs inventories conducted in place and**
- **6 Action Plans on measures to be taken.**



Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem
MedPartnership



Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem
MedPartnership

First Inception Workshop 25 September 2014



Presentation of the Project at regional level



Legislation addressing POPs

- Ministry of Environment has the main aim preparation and transposition of EU legislation in place.
- Law no.10431, date 09.06.2011 “On Environment Protection”, prohibits production, import, placing on the market and use of chemicals and pesticides that exhibits POPs properties.
- Law no. 10448, date 14.07.2011 “On Environment Permits”, has transposed in Albanian legislation BAT/BET definitions, requirements, procedures and methods to define them for activities and large combustion plants or for specific instalations.
- Law no.10463, date 22.09.2011 “On integrated waste management”, accompanied by
- National Strategy and National Plan on waste management, approved by DCM no. 172, date 19.01.2011. National Plan includes also measures on PCB/PCT management, collecting plans and/or cleaning and/or disposal of equipments containing PCB.

The law on waste management is followed by several by-laws 1/2

- DCM no.177, date 06.03.2012 “On packaging and waste packaging”.
- DCM no.178, date 06.03.2012 “On waste incineration”.
- DCM no. 452, date 11.07.2012 “On waste landfill”.
- DCM no.705, date 10.10.2012 “On management of waste by end of life vehicles”.
- DCM no. 765, date 07.11.2012 “On approval of rules for separation collection and treatment of used oils”.
- DCM no.866, date 4.12.2012 “On batteries and accumulators and their wastes”.
- DCM no.957, date 19.12.2012 “On electric and electronic equipments and their wastes”.
- DCM no.117, date 13.02.2013 “Establishing criteria determining when certain types of scrap metal cease to be waste”
- DCM no. 798, date 29.09.2010 “On administration of Hospital Wastes”.

During 2014, Ministry of Environment has approved a list of sub-laws on WM

- DCM nr. 229, date 23.04.2014 "On approval of rules for the transfer of non-hazardous waste and information to be included in the document of transfer"
- DCM nr.371, date 11.06.2014 "On approval of rules for submission of hazardous wastes and their document of delivery"
- DCM nr.418, date 25.06.2014 "For differentiated waste collection at source".
- DCM nr.608, date 17.09.2014 "For determining the necessary measures for the collection and treatment of bio wastes, criteria and deadlines for reducing them"
- DCM nr. 641, date 01.10.2014 "On approval of rules for waste export and transit of non-hazardous wastes and inert wastes"

Focusing on POPs

- For implementation of BRS Conventions obligations, a **specific** legislation addressing POPs, PCBs, PIC Procedure is necessary.
- **During 2014**, Ministry of Environment prepared a **legal act on POPs**, based on EU Regulation 850/2004/EC. Currently this Draft DCM is under approval process. Based in it: a **Annually Monitoring Program on Dioxines, Furanes and PCBs** must be prepared by NEA
- Since **beginning of 2015**, MoE is working on preparation of a legal act on **PCB/PCT disposal control rules, dekontamination or disposal of equipments containing PCB/PCT or their wastes**, transposing EU Regulation 94/63/EC; Based in it: a **Preliminary and a Final Inventory on PCB situation in place** must be prepared by NEA

New legislation on chemicals under preparation

During the period November 2014-March 2015, Ministry of Environment financed by a regional Project "ECRAN", has been assisted by Swedish Chemicals Agency (KEMI), and 5 TAIEX Expert Missions on chemicals, are held in Tirana for preparation of :

1. New Law "On chemicals", transposing in place REACH and CLP EU Regulations;
2. New DCM on CLP (GHS)
3. DCM on import Export-PIC Procedure (Rotterdam Convention);
4. DCM on restrictions on the manufacturing, placing on the market and use of certain dangerous substances, mixtures and articles;
5. DCM on Very High Concern substances;

Representatives involved: Custom Authorities, ministries of lines dealing with chemicals, NEA, National licensing center in the country.

UNEP/MAP project implementation

Ministry of Environment of Albania joined UNEP/MAP Project for PCB contaminated oil disposal, under: Sub-component 2.3: Environmentally Sound Management of equipment, stocks and wastes containing or contaminated by PCBs in national electricity companies of Mediterranean countries

- At beginning of 2011, a team of 3 international experts came in Tirana, Albania.
- 2014 January, delivery of L2000DX equipments and chemical reagents to Albania;
- Theoretical workshop on PCB Management, held on 21-22 January 2014, in Tirana.
42 Representatives from: Regional Environment Directories in the country, National Environment Agency, different Municipalities (Tirana, Fier etc), NGOs, Institutions dealing with electricity sector etc, participated in the workshop.

UNEP/MAP project implementation

3. A Practical workshop held on 23-24 January 2014, in Tirana.

- ✓ **42 local experts** trained to audit transformers/capacitors and use L2000DX Analyser
- ✓ **demonstration on site** of PCBs sampling and analysis, at Transformers Repair Unit, under CEZ company (currently BEDO/OSHEE);
 - two transformers and two tanks (800lit) for sampling were chosen
 - two samples from the oil of drums/tanks, and
 - two oil samples from transformers.
 - all information and indicators were screened from their transformers plate.
 - transformers were not filled with PCB while manufactured.
 - The final assessment is made after screening samples using the L2000DX Analyser.
 - The results of screened samples from tanks and transformers were all negative, revealing a maximum concentration of **31 mg/kg**. That means that the oil and transformers can be regarded as **PCB free**.

4. PCB Inventory for identification of transformers, capacitors used by private companies.

Photo: demonstration on site, PCBs sampling and analysis





Lessons learnt under this Project

- Large number and variety of participants in workshops
- The knowledge of participants was at such technical level to understand terminologies, legislation, safety issues, sampling and handling procedures with PCBs.
- Active participation in all days of the workshops. Participants shared their (previously) experiences on PCB management
- PCBs life-cycle management requires cooperation and collaboration of all relevant institutions, at national or local level
- Specific legislation (POPs, PCBs, PIC, HazChem) must be in force as soon as possible



Challenges faced during the project implementation

- A specific legislation on POPs, PCBs, PIC Procedure not in place.
- Duties and Commitment of relevant institutions
- Cooperation with/between institutions, companies dealing with electricity sector, must be mandatory by legislation, or raised at a high level
- Project Implementation requires high level support.

Proposed ideas for the future

- **Assistance on Preparation of Monitoring Program on POPs and PCBs (air, water, land);**
- **Assistance on Preparation of Awareness Training Program on POPs management in general;**
- **Assistance on Implementation in place of the prepared Guide on ESM of PCB**



Thank you for your attention!


Rovena Agalliu
Sector on Air, Climate Changes and Chemicals
Ministry of Environment
E:mail: Rovena.Agalliu@moe.gov.al





Subcomponent 2.3. Environmentally Sound Management of Equipment, Stocks and Wastes Containing or Contaminated by PCBs in National Electricity Companies of Mediterranean countries

BOSNIA AND HERZEGOVINA



Contents

- PCB management system in Bosnia and Herzegovina**
- Implementation of international standards and regulations**
- PCB inventory in Bosnia and Herzegovina**
- PCB disposal**
- Lessons learned from the Project**
- Bosnia and Herzegovina challenges and needs to manage PCB in environmentally sound manner**

About the Project

Sub-component 2.3. of the Med Partnership Project in Bosnia and Herzegovina:

- **Implemented by the Programme for the Assessment and the Control of Pollution in the Mediterranean Region (MEDPOL) and the Regional Activity Center for Cleaner Production (CPRAC)**
- **In cooperation with the Ministry of Foreign Trade and Economic Relations of Bosnia and Herzegovina**
- **Local consultant: Enova, Consultants and Engineers**
- **Started in May 2013**



PCB management system in Bosnia and Herzegovina

- **B&H consists of three separate administrative units**
- **Environmental issues are in the jurisdiction of the entity governments**
- **Competencies regarding environmental issues are divided between:**
 - **FB&H – Entity and cantons**
 - **RS – Entity and local self government units**
 - **BD – District Government**



PCB management system in Bosnia and Herzegovina

Under the **Law on Ministries and Other Administrative Bodies of B&H** (O.G. of BiH, No. 5/03, 42/03, 26/04, 42/04, 45/06, 88/07, 35/09, 59/09 and 103/09), Article 9, paragraph 2:

- **Ministry of Foreign Trade and Economic Relations of B&H (MoFTER)** is responsible for carrying out tasks within the jurisdiction of B&H pertaining to definition of the policies, the basic principles, coordinating activities and harmonizing plans of entity authorities and institutions at the international level in the areas of:
 - agriculture,
 - energy,
 - environmental protection,
 - development and utilization of natural resources and tourism


PCB management system in Bosnia and Herzegovina

- In FBiH and BD, the *Law on Chemicals* or the regulations which restrict or prohibit the manufacture, trade and use of certain chemicals, including PCBs - **not yet adopted**
- In RS, the *Regulation on Conditions for Restricting and Prohibiting the Manufacture, Trade and Use of Chemicals* (O.G. of RS, no. 100/10, 63/13), adopted on the basis of the *Law on Chemicals* (O.G. of RS, no. 25/09) - **prohibits the production and use of PCBs**
- Transport of PCBs - regulated by legislation on transport of hazardous chemicals (i.e. substances and poisons), transboundary movements of waste and the Basel Convention - ratified by BiH in 2000

Lack of adequate legislation on PCB management in B&H
Discrepancy in the adoption of laws and bylaws in FBiH, RS and BD

Strong Partnership for the Mediterranean Sea Large Marine Ecosystem
MedPartnership

PCB management system in Bosnia and Herzegovina

- Regulations on handling and disposal of equipment containing PCBs/PCTs
 - Regulations that define the deadline for the final disposal of waste containing PCBs (liquids and equipment containing more than 0.005% of PCBs by weight)
- Not adopted in FB&H, RS and BD** 
- In FBiH and BD - no regulations that prohibit the recovery, recycling, reclamation, direct reuse or alternative use of liquids containing more than 0.005% of PCBs by weight
 - In RS - the *Law on Waste Management* (O.G. of RS, no. 111/13) prohibits refilling of transformers with PCBs, re-use of PCB waste, recycling PCBs from PCB waste, temporary storage of PCBs, PCB waste or devices containing PCBs for more than two years without ensuring their final disposal or decontamination, and the use of devices containing PCBs unless they are in good working order or undamaged

Strong Partnership for the Mediterranean Sea Large Marine Ecosystem
MedPartnership

PCB management system in Bosnia and Herzegovina

Key issues in the current management of PCBs in B&H

Appropriate management - disabled by the lack of an appropriate legal framework and poor coordination between the relevant institutions

Lack of records of equipment containing or contaminated with PCBs in authorized state and entity institutions of BiH

Lack of records of sites contaminated with PCBs

Inadequate customs tariffs - Indirect Taxation Authority of BiH (Customs Sector) does not have an established special tariff heading for transformers/capacitors containing PCBs

Lack of knowledge on PCB management of persons working with equipment containing PCBs

Inadequate storage of equipment containing or contaminated with PCBs

Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem
MedPartnership

Implementation of international standards and regulations

- **SIGNED:** Bosnia and Herzegovina signed the Convention in 2001
 - **RATIFIED IN BIH:** March 30, 2010
 - **OBLIGATION ART. 7. OF CONVENTION:** National Implementation Plan (NIP) completed in two years after the ratification
-
- Project *“Enabling Activities to Facilitate Early Action on the Implementation of the Stockholm Convention on Persistent Organic Pollutants (POPs) in Bosnia and Herzegovina”* (January 2013– January 2015)




1st National Implementation Plan (NIP) for the Stockholm Convention in B&H



Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem
MedPartnership

Implementation of international standards and regulations



Implementation of international standards and regulations

Conventions and protocols with synergetic action :

- **Convention on the Control of Transboundary Movements of Hazardous Wastes and Their Disposal (Basel Convention)** - Ratified in BiH in 2001
- **Convention on the Prior Informed Consent Procedure for Certain Hazardous Chemicals and Pesticides in International Trade (Rotterdam Convention)** - Ratified in BiH in 2006
- **Convention for the Protection of the Mediterranean Sea Against Pollution (Barcelona Convention)** – Notification of succession in 1992
- **Protocol for the Protection of the Mediterranean Sea against Pollution from Land-Based Sources (LBS Protocol)** - Notification of succession in 1994
- **Convention on Long-Range Transboundary Air Pollution (LTRAP)** - Notification of succession in 1993
- **Convention on Access to Information, Public Participation in Decision-making and Access to Justice in Environmental Matters (Aarhus Convention)** - Ratified in BiH in 2008

PCB Inventory in B&H

2 projects implemented in parallel (2013-2015):

1

Sub-component 2.3. of the Med Partnership Project

2

Enabling Activities to Facilitate Early Action on the Implementation of the Stockholm Convention on Persistent Organic Pollutants (POPs) in Bosnia and Herzegovina:

- GEF Implementing Agency: UNIDO
- Institutions for the implementation and coordination: MoFTER
- National Executive agency: Enova, Consultants and Engineers and the Institute of Protection and Ecology Banja Luka
- The Steering Committee of the project: representatives of relevant institutions

Preliminary PCB inventory in Bosnia and Herzegovina developed by combining the needs of 2 projects

PCB Inventory in B&H

Sub-component 2.3. of the Med Partnership Project



To introduce environmentally sound management (ESM) to all stages of the "life-cycle" of electrical equipment containing or being contaminated with PCBs

The main activities

A) Training programme „Management of PCBs”

B) PCB inventory field trip in Bosnia and Herzegovina

PCB Inventory in B&H

A) Training programme „Management of PCBs”

Training programme „Management of PCBs”

MODULE 1
Theoretical part
 (23 and 24 September 2013) in Mostar

Designed for all institutions / organizations involved in management of PCBs

MODULE 2
Practical part
 (25 and 26 September 2013) in PSH Power Plant “Capljina”, Svitava

For representatives of the power companies and laboratories that are or might be involved in PCB inventory

PCB Inventory in B&H

Training programme - MODULE 1

- **Global context, history, applications, conventions**
- **PCB sound management:**
 - Identification, risk assessment, priority setting
 - Inventory, classification, GHS
 - General and project specific sampling, screening and analysis methods & proceedings
 - Maintenance, life cycle management, phase out and storage
 - Handling, packing, loading, transport
 - Import/export disposal
 - Case studies
 - Written test

Lecturers:

- Urs K. Wagner, ETI
- Panos Ioakimidis, Ecoterra



PCB Inventory in B&H

Training programme - MODULE 2 (Day 1)

- **Safety briefing (inventory safety and proceedings)**
- **Inventory taking on site (data and questionnaires)**
- **Sampling on site**
- **Administration on site**

Lecturers:

- Christian Marchesi, ETI
- Panos Ioakimidis, Ecoterra



PCB Inventory in B&H

Training programme - MODULE 2 (Day 1)



PCB Inventory in B&H

Training programme - MODULE 2 (Day 2)

- **Theoretical L2000 DX training:**
 - Review of screening methods,
 - Screening by L2000
 - Recording of data, Administration and disposal of consumables
- **Practical L2000 DX training:**
 - L2000 parts and maintenance
 - Proceedings
- **Use of L2000 DX by participants**
- **Written Sampling and Screening Test**



PCB Inventory in B&H

B) PCB inventory field trip in Bosnia and Herzegovina

Prior to the trip:

- In the period between 24 June and 26 August 2013 more than 330 official letters and questionnaires sent to identified institutions and/or organizations
- The industrial plants and companies were selected for site visits on the basis of the questionnaires in which the companies stated that they own equipment containing PCBs
- The PCB Inventory Group visited the companies that stated that they own equipment containing PCBs and which **were willing to cooperate and organize site visits**

PCB Inventory in B&H


B) PCB inventory field trip in Bosnia and Herzegovina

Site visits, supported by MoFTER and organised by the NTA, were conducted from 18 to 27 November 2013 in the following companies:

- Electricity generating and distributing company EP HZHB
- Electricity generating and distributing company EP BiH
- "Elektrodistribucija" Sarajevo
- "Elektrodistribucija" Zenica
- Coal Mine "Zenica"
- Coal Mine "Breza"
- Coal Mine "Đurđevik"
- Kemokop d.o.o.
- Kemis d.o.o.
- Jelsingrad Livar



„Elektrodistribucija“ Sarajevo



PCB Inventory in B&H

B) PCB inventory field trip in Bosnia and Herzegovina



„Jelsingrad Livar“, Banja Luka



Coal Mine "Đurđevik"



"Elektrodistribucija"
Zenica, TS 110/35 kV
Tesanj



PCB Inventory in B&H

B) PCB inventory field trip in Bosnia and Herzegovina

Amounts of equipment inventoried on site and the number of samples taken

No. of companies	Number of samples taken	Amounts of equipment			
		Transformers	Capacitors	Switches	Barrels
16	17	22	540	1	17

- The screening of collected samples was performed with Dexsil L2000DX analyser




Preparation for screening





Screening of samples

PCB Inventory in B&H



PCB Inventory in B&H





PCB Inventory in B&H

Potential locations contaminated with PCB

Location	Municipality	Company
TS 35/(20)10 Jelah	Jelah	"Elektrodistribucija" Zenica
TS 10/6 kV	Đurdevik	Subsidiary Company Coal mine "Đurdevik"
TS 10/6 kV	Breza	Subsidiary Company Coal mine "Breza"




Location potentially contaminated with PCBs, Elektrodistribucija Zenica TS 35/(20)10 Jelah



Location potentially contaminated with PCBs, Subsidiary Company Brown Coal Mine "Breza"



PCB Inventory in B&H



PCB Inventory in B&H

Total quantity of PCB containing waste ready for export from B&H

Entity	Company	Transformers (kg)	Capacitors (kg)	Barrelled oil (kg)
B&H	"Elektrodistribucija" Sarajevo		7,874	405
	„Elektrodistribucija“ Zenica, TS 35/10 kV Maglaj II		342	
	"Elektrodistribucija" Zenica, TS 110/35 kV		171	
	Elektrodistribucija" Zenica, 10/0,4 Tešanj 2		240	
	"Pobjeda" Tešanj d.o.o.		1,986	
	Enker d.o.o.		627	
	"Elektrodistribucija" Zenica, TS 35/(20)10 Jelah		684	
	"Elektrodistribucija" Zenica, TS 10/0,4 kV Vitex 4		360	
	"Elektrodistribucija" Zenica, TS 110/35/10 kV Visoko		513	
	"Elektrodistribucija" Zenica, TS 110/35/10 kV Visoko		306	
	"Elektrodistribucija" Zenica, TS 110/35/10 kV Visoko		75	
	Subsidiary Company Coal mine "Zenica"		570	
	Subsidiary Company Coal mine "Đurdevik"		1,150	
	Kemokop d.o.o.		4,740	
	Grioss d.o.o.	60,000	4,140	
Kemis BiH d.o.o.	16,510	595	3,200	
RS	Kemokop d.o.o. Modriča		1,679	
	B&H	76,510	26,052	3,605
	Total quantities in B&H			106,167

PCB disposal

- No PCB treatment facilities in Bosnia and Herzegovina
- According to data from the Basel Convention in **2003 and 2006**, nearly **131 tons** of waste containing PCBs was exported from B&H - to the final destruction in Lyons, France
- Agency for Statistics of B&H reported that nearly **2,500 tons** of waste that **may contain PCBs** was exported in the period **2008-2013** (transformers, capacitors – no tariff code for those containing PCBs)
- *Sub-component 2.3. of the Med Partnership Project* envisaged export and disposal of PCBs contaminated oils and equipment (in the amount of 200 tons) from Bosnia and Herzegovina

PCB disposal

Current status:

- APROCHIM – company selected for the removal and disposal of equipment and wastes contaminated by PCBs in Bosnia and Herzegovina
- APROCHIM – selected local company KEMIS B&H to obtain all necessary licences
- Federal Ministry of Environment and Tourism issued to the company KEMIS B&H the notification number to start the procedure
- KEMIS B&H - prepare all the documentation and obtain the licence for export

Lessons learned

Need for comprehensive awareness raising of targeted groups:

- Representatives of institutions
- Company management
- Employees directly involved in handling of PCB containing equipment
- Other stakeholders

Institutional set up needs to be more structured and more comprehensive, because the fragmented approach will not contribute to environmentally sound management of PCBs

Challenges and needs to manage PCB in environmentally sound manner

1

Improving institutional framework for the management of PCB

- **Establishment of an effective and reliable mechanism of coordination between MoFTER and the institutions responsible for the implementation of SC in Entities (FMET, MPPCEE and DSPPA)**
- **Training programs for inspection bodies on PCBs and equipment containing or is contaminated with PCBs**
- **Strengthening of inspection supervision in terms of reporting equipment and wastes containing PCBs to relevant institutions**

Challenges and needs to manage PCB in environmentally sound manner

2

Development and adoption of new or update of existing legislation that defines all aspects of PCB management

- **Production, import, transport and use of the equipment or liquids that may contain PCBs**
- **Handling and disposal of equipment and waste containing PCBs**
- **Prohibition of recovery, recycling and reuse and direct reuse or alternative use of liquids containing PCBs above 0,005%**
- **Deadlines for replacing equipment containing PCBs and deadlines for the disposal of waste containing PCBs**
- **Occupational safety where working with materials containing PCBs**
- **Monitoring of PCBs in the environment and living organisms**

Challenges and needs to manage PCB in environmentally sound manner

3

Ensuring adequate management of PCBs and equipment containing or contaminated with PCBs, including previous detailed inventory

- Development of **technical guidelines for identification and environmentally sound management** of equipment or products containing or contaminated with PCBs
- **Training of technicians and service personnel** for the proper maintenance of equipment containing PCBs
- **Establishment of databases** of owners of equipment containing or contaminated by PCBs and PCB waste
- **Detailed inventory** of equipment containing or contaminated with PCBs and PCB waste
- Development and implementation of **Phase-out Management Plan** to exclude from use / decontaminate equipment containing or contaminated with PCBs

Challenges and needs to manage PCB in environmentally sound manner

4

Ensuring an adequate management of PCB waste

- Development and implementation of a **plan of disposal / decontamination** of equipment containing PCBs and PCB waste in BiH
- Identification of necessary capacities and **establishment of temporary storage facilities** for PCB waste, as part of hazardous waste storage
- **Safe disposal** of equipment containing PCBs

Challenges and needs to manage PCB in environmentally sound manner

3

Raising awareness and educating the target groups

- Develop and implement **programs to raise awareness** and educate the public
- Prepare and distribute **information materials** on POPs chemicals for different population groups
- Prepare and distribute a **manual for professional and technical persons** on the identification and safe handling and management of hazardous waste containing POPs chemicals
- Develop and implement **programs for further education of teachers and lifelong learning programs** at the level of university specialization

Challenges and needs to manage PCB in environmentally sound manner

4

Establishing criteria and mechanisms for the customs control of import, export and transit of equipment and products that potentially contain PCBs

- **Amendment to the Customs Tariff** relating to equipment with PCBs (transformers and capacitors containing PCBs)
- **Training programs** for Indirect Taxation Authority (**Customs Sector**) on control of illegal imports of products and equipment containing PCB
- **Enhance control** at border crossings to prevent illegal import of POPs

Challenges and needs to manage PCB in environmentally sound manner

Technical and financial assistance from developed countries is of key importance for environmentally sound PCB management and successful implementation of the Stockholm Convention in Bosnia and Herzegovina

Most of the foreign funds are necessary for:

- A detailed inventory of equipment which contains or is contaminated by PCB and PCB waste,
- Implementation of Phase-out Management Plan for equipment containing or contaminated by PCBs (upon its completion)
- Identification of necessary capacities, and establishing a temporary storage for PCB waste,
- Final disposal of PCBs,
- Technical assistance.

Thank you



MAJA MARETIĆ TIRO
SENIOR CONSULTANT
T:+387 33 279 103 / F:+387 33 279 108
maja.maretic-tiro@enova.ba
www.enova.ba



Environmentally Sound Management of equipment, stocks and wastes containing or contaminated by PCBs in national Electricity companies of Mediterranean countries



National PCBs Management System

On the national legislative level in Egypt

**Law no 4/1994 for the Protection of the Environment
Amended by Law 9/2009**

Article 29:

It is forbidden to displace hazardous substances and waste without a license from the competent administrative authority. The executive regulations of this Law shall determine the procedures and conditions for granting such a license and the authority competent to issue same.

The ministers shall, each in his field of competence, issue in coordination with the Minister of Health and EEAA a table of the hazardous substances and waste referred to in para one of this article.






**Decree no. 165 of year 2002 of Minister of Industry
List of Industrial Hazardous Wastes**

item16:

Wastes from electrical and electronic assemblies or scraps containing components such as accumulators, batteries, mercury wetted switches, glass from cathode ray tubes and other activated glass and PCB- capacitors, or contaminated with constituents (e.g. cadmium, mercury, lead, polychlorinated biphenyl) to an extent that they exhibit hazard characteristics.



Road of National Implementation of Stockholm



Stockholm Convention Implementation

Year	Project Name	Activities	Donors
2006-2008	Integrated PCBs Management	<ul style="list-style-type: none"> - Inventory PCBs in Electrical stations. - Data Base for POPs. - Capacity Building programs (TOT). - Analysis Samples with GC. - Final Report. - International Workshop. 	JICA
2009-2010	Sustainable POPs Management First stage	<ul style="list-style-type: none"> - Inventory for POPs all over Egypt. - Analysis with Kites. - Full-sized Project (Second Phase). 	GEF & WB
2009-2011	Dioxin and Furan Inventory (Two stages)	<ul style="list-style-type: none"> - Dioxin and Furan (Toolkit). - Identify Priorities. - Capacity Building. - BAT & BEP pilot project. - Final Report 	PERSIGA
2012	GMP1	<ul style="list-style-type: none"> - Mother Milk (Residue Laboratory) - Air Monitoring - Final Report. 	GEF & UNEP
2012-2015	Integrated Management of PCBs	<ul style="list-style-type: none"> - Complete Inventory for PCBs in Utilities. - 2 Analyzer LX2000. - Capacity Building for all categories. - Get Rid of 185 ton pure PCBs. 	MEDPOL

Year	Project Name	Activities	
2014	GMP2	<ul style="list-style-type: none"> - Surface Water. - Air Monitoring. 	GEF & UNEP
2015-2017	NIP Updating	<ul style="list-style-type: none"> - Review and Update NIP. - New POPs Inventory. - Capacity Building. 	GEF & UNEP
2015-2020	Sustainable POPs Management (Second Phase)	<ul style="list-style-type: none"> - Safe Disposal for Obsolete Pesticide. - PCBs treatment (Low Concentration) - Regulation Updating and Capacity Building 	GEF & WB

Synergy for Basel, Stockholm, Minamata Conventions




Achievements of PCBs Inventory

- The Completion of the creation of Waste Data Base (JICA & Danida) 2008.
- Kick off Meeting in 2010 (Inventory started)
- First Mission in 9/2011 at Alexandria : a meeting with the World Bank , Abbis scrap yard (TSU) and Bakoss Lab were chosen (108,012 Tons)
- SUPPORTING THE GLOBAL MONITORING program ON PERSISTENT ORGANIC POLLUTANTS EGYPT , 2012.
- Second mission in 12/2013 : on site Training in Rakta paper Co. , Training on LX2000 analyzer in Alex –RBO lab (122,930 Tons).
- Completion of the training of trainees (2000) from ministries , relevant agencies and NGOs.
- The completion of the creation of special project web site 10/2013.
- Approval of the updated National Action Plan for persistant organic pollutants 5/2013.
- Environmental Sound Management of PCBs Workshop in Alex 2/ 2014
- Mission by a representative from Aprochim Co. (184,94 Tons) , from which 135,15Tons pure PCBs(Iron and Steel Co. and Industrial and Minning Projects Authority , 49,79Tons from Alex (Rakta Co., Egyptian Copper Works, Abbis scrap yard)
- EIA study approval for the transfer of oil contaminated material and equipment 2/2015.
- A national Team was prepared to supervise all activities for safe final disposal process




**No. of Industrial Utilities and No. of electric transformers' stations
(total of 126)**



**61% of high Concentration PCBs contaminated transformers
in the industrial sectors**



**No. of companies' transformers in Alexandria and El Behira
Governorates**




60% of working transformers in industrial Utilities in (1950-1986) period






No. of transformers in electric transformers' stations in Alexandria



47% of working transformers in electric transformer station 1950-1986



**No. of operating transformers 1950-1986
(total No. 686)**




74% of inventory(No of transformers) was carried out in Alexandria and El Behira, 22% in El Dakahlia, 4% in Damietta







Concentration Of PCBs ppm in General Company for Paper Industry (Rakta)



Concentration Of PCBs ppm in Egyptian Copper Works company



Concentrations of PCBs ppm in the samples analyzed in 4 Governorates



MEDPOL

Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem
MedPartnership

Egypt actions and facts

-2013 November and February 2014 the UNEP/MAP international PCBs expert formed a team of three local experts and audited 6 sites in order to audit and start a dynamic PCBs inventory



-Identified in the country demonstration site of PCBs sampling and analysis

-Until end of January 2014 in Egypt the experts identified more than 184 tn of PCBs, 184 tn already declared as ready to be exported abroad the country for final disposal abroad





Egypt actions and facts

-2013 December delivery L2000DX in Egypt, conduction of theoretical and practical training on PCBs Sound Management and physical auditing of transformers and capacitors

-In Egypt was trained 99 local experts on Overall PCBs Management and 40 to audit transformers / capacitors and use of L2000DX Analyser



Field Work

Leakage in transformers contaminated with PCBs





Picture 7: Transformer No 1

Picture 8: Screening Name Plate of the transformer



Picture 10: In the front the small transformer



Picture 11: In buck site the bigger transform



Training And Awareness Programs

Strong Partnership for the Mediterranean Sea Large Marine Ecosystem
MedPartnership





Sustainability

№	Transformer NO	KLV	Site	Date	Manufactured Year
1	847417	1000	Katnia	2014/01/20	1984
2	785459	500	Katnia	2014/01/20	1978
3	862254	100	Katnia	2014/01/27	1986
4	857256	1000	Katnia	2014/01/27	1985
5	845202	500	Katnia	2014/01/27	1984

556 Suspected Transformers in Electrical Stations 1950-1986

Transformer Inventory 4/2014 in Electrical Station




Ministry of Electricity Central Laboratory


NO	Conc. Ppm	NO	COC. Ppm
1	13.4	11	8.7
2	9.8	12	12.6
3	16.9	13	21.2
4	24.2	14	14.8
5	3.6	15	16.7
6	17.5	16	23.7
7	11.7	17	12.3
8	23.4	18	18.7
9	10.2	19	22
10	15.6	20	19.3

Contaminate Oil Analysis BY LX2000 Analyzer

STUDY OF RISK EXPOSURE ASSESSMENT FOR EGYPTIAN INFANTS EXPOSED TO DIOXIN INTAKE IN COMMERCIAL BABY MILK RESIDUE LABORATORY



How people are exposed to dioxins as PCBs and furans



PCBs Disposal

Actions taken:

- Keep contaminated equipment in safe area storage area and special label until final disposal out of the country.
- Necessary Documents for notifications for Trans frontier shipments/movements of Wastes as discussed by Aprochim mission
- The first approval of EIA document for Road License of PCBs contaminated equipment in Egypt was taken for Eco Con Serv. company .
- The formation of a committee of the relevant authorities to oversee the safe disposal of this equipment out of the country.
- For sustainability of the project ,have been identifies Egyptian companies working in the field of disposal of hazardous waste to trained through the project activities
- Continue to inventory of electrical equipment (1950-1986) at the provincial level.

• Next Steps:

1- One day Mission to identify filling of the notification doc .

2- On – site Training in Steel and Iron Facility :

work-plan for the project or collection and disposal of PCBs in EGYPT ;on safe pumping / packing / labeling.

4-Awareness workshop for “ PCBs Management “ in Cairo .

5- Sending notification file to: Spain/ Italy / France 185 ton out of the country.

6- Trans-boundary movement according to Basel convention / IMDG / ADR rules. (IMO) in accordance with SOLAS Convention, MARPOL Convention and IMDG Code , through out Alex port to France port.

Lessons Learnt from the Project

- How to Identify and recognize (physical view) the contaminated equipment at the sites.
- How samples collection and analysis.
- How the analysis and measurement (TOT) by LX2000 analyzer.
- Health effects and risks of persistent organic pollutants.
- Environmentally and society negative impacts of persistent organic pollutants.
- Identification of hotspots and contaminated sites with PCBs.
- Determination of real quantities of contaminated PCBs equipment and Oil it help us in NIP updating.
- How conducting the information and data through (workshops, meetings , awareness and training...) with Ministries ,NGOs
- Life cycle and Management of POPs
- Guidelines of PCBs storage area, labeling

Difficulties

- No Interim safe Storage area in all sites.
- Cross contamination occurs in maintenance Workshops.
- Products from the PCBs contaminates oil.
- Illegal Trade of PCBs contaminates waste in New electrical transforms.
- Lack of awareness in Maintenance Stations cause cross contaminations.
- PCBs contaminated equipment not included in the unify list
- No limits for PCBs conc. In (air, water, soil in our environmental law (4/94 modified by 9/2009
- Lack of analyzers equipment, ex LX 2000 analyzer in ministries and relative authorities.
- Lack of chemicals for GC. Mass spectroscopy.
- Usage of Transformer to about 40 years : to be used in ruler areas , therefore out of safe control / pose health risks.
- No transporting company possess EIA certificate specially for PCBs.
- According to Stockholm convention (50ppm) could be dangerous and health risky
- Scrap transformers in industrial units may leak, wear which pose hazard to the community inside the unit
- Absence of BAT , BEP in the cases of non intentional production of PCBs
- Absence of analyzers for a long previous period made Inventories which were held of no use
- Selling Oil contaminated with PCBs through auction in electric scrap yard occurs without analysis.

Egypt Challenges and Needs

- **Challenges:**
 - After the ratification of Stockholm convention No real inventory .
 - Illegal trade should be stopped (oil contaminated with PCBs are sold in market used by people as cream/ shampoo, scents) to decrease health risks
 - Law and Regulation .
 - Lack of information
 - Non Regular Repairing for transformers
- **Needs:**
 - Counting the inventory of PCBs oil and equipment in Aswan & El koser.....
 - Inventorying the electrical equipment in hospitals
 - Implement BAT, BEP by changing technology
 - Inventory of non intentional PCBs from industrial sector especially petroleum and petrochemical industries
 - Treatment mobile unit for PCBs
 - Inventory for new POPs
 - Remediation action plan for soil contaminated with PCBs
 - Budget for Inventories to be carried in our hotspots e.g. Upper Egypt
 - Strategy for sustainable management of POPs



Solutions

- Banning the selling of used transformer oils before analysis (free of PCBs)
- Addition of contaminated equipment with PCBs should take place during the amended modification of Hazardous Wastes Lists
- Updating local regulations.
- More Media activities.
- Lack of Budget in industrial sector to apply analysis for PCBs
- The (2) LX2000 analyzers submitted/ delivered by the MEDPOL project covers only inventory held in Alexandria and El Behira . So increasing the numbers of analyzers is a must.
- EMS, Risk assessment and POPs treatment awareness and training programs



Data base and GIS map

Construction of a database gathering data collected

	A	B	C	D	E	F	G
11	Site generalities						
12	Last update: 10/12/2009						
13	Name and address of the company						
14	Area	Sites	ID Site	Name of the company	Address of the company	Address of the site (if different from A2)	
15	References in the questionnaires						
16					A1	A2	A3
20	Great Cairo	Shubra el Khayma City	5 private companies				
21	Great Cairo	Nasr City	Transformer workshop and storage site	CAI-El Nasr City	North Cairo Distribution Company (ministry of electronics)	Nasr city	
22	Equipment specificities / Waste specificities / Testing and sampling						
23	Last update: 10/12/2009						
24	Characteristic						
25	Area	Sites	ID Site	ID Equipment/Waste	Name of manufacturer and country of origin	Number of equipment/waste	Location on the site
26	References in the questionnaires				B1		B2
27					B3		B4
21	Great Cairo	6th October City	Transformer storage site	CAI-6th October	Elnaco, Egypt	1	Transformer
22	Great Cairo	6th October City	Transformer storage site	CAI-6th October	Elnaco, Egypt	1	Transformer
23	Great Cairo	6th October City	Transformer storage site	CAI-6th October	Elnaco, Egypt	1	Transformer
24	Great Cairo	6th October City	Transformer storage site	CAI-6th October	Elnaco, Egypt	1	Transformer
25	Great Cairo	6th October City	Transformer storage site	CAI-6th October	Elnaco, Egypt	1	Transformer
26	Great Cairo	6th October City	Transformer storage site	CAI-6th October	Elnaco, Egypt	1	Transformer
27	Great Cairo	6th October City	Transformer storage site	CAI-6th October	Elnaco, Egypt	1	Transformer

Site generalities
Last update : 1/1/2009

C'S'D'			ENOPC			Name and address of the company		
Area	Sites	ID site	Name of the company	Address of the company	Address of the site (if different from A2)			
References in the questionnaires			A1	A2	A3			
Great Cairo	Shubra el Khayma City	2 electrical distribution station						
Great Cairo	Shubra el Khayma City	1 electrical power plant						
Great Cairo	Shubra el Khayma City	5 private companies						
Great Cairo	Near City	Transformer workshop and storage site	CAHEI Nasr City	North Cairo Distribution Company (priority of electricity)	Near city			
Great Cairo	El Near Company for Coke and Chemicals Industries	chemical and coke industry	CAI-Coke and Chemicals	El Near Company for Coke and Chemicals Industries	Hekma - El Toppan			
Great Cairo	18th October City	Transformer storage site	CAH 18 October	North Cairo Distribution Company (priority of electricity)	18 October city			
Great Cairo	Old Bahim	Oil storage site	CAHOld Bahim	North Cairo Distribution Company (priority of electricity)	Shubra - Bahim			
Great Cairo	Cairo South Power station	Electric power production specific site		Cairo South Power station	22 Sharaan street El Sabhaya - Cairo	Kandah El-Hik - Hekma - Cairo		
Great Cairo	Cairo electricity production company	Production of electricity of different sites		Cairo electricity production company	22 Sharaan street el sabha - Cairo	Cairo west power plant Bakel-cement-18th October		
Great Cairo	Cairo electricity production company "West hot power station"	Electric power production		Cairo electricity production company "West hot power station"	22 sharaan street el sabha - Cairo	West hot - Hekma		
Great Cairo	Talkha Power Station 2 x 210MW	Power Generation Company		Talkha Power Station 2x210MW	Postal box : 36888 (Nasser City, Cairo : 11125, Talkha)			
Great Cairo	Talkha Combined Cycle and Turbine Gas 2 x 24,72 + 2 x 45,54 MW	Power Generation Company		Talkha Combined Cycle and Turbine Gas 2 x 24,72 + 2 x 45,54 MW	Postal box : 36888 (Nasser City, Cairo : 11125, Talkha)			
Great Cairo	North Cairo Distribution Company	Electricity Distribution Company		North Cairo Distribution Company	2nd El Near Road - Near City - Cairo	Company have different branches (13) and other different sites (sketches, workshops...)		
Great Cairo	South Cairo Electricity Distribution Company	Electricity Distribution Company		South Cairo Electricity Distribution Company	10, 28 of July street - Cairo			

Thank You ...





ENVIRONMENTALLY SOUND MANAGEMENT OF PCBS IN TURKEY

Refet Sinem ATGIN

Expert

7-9 April, 2015
Istanbul



Legal Status of PCB Management in Turkey

- Turkey became a party to Basel Convention in 1994.
- First measures were taken for hazardous wastes after being a party to Basel Convention. By-Law on Control of Hazardous Wastes was first issued in 1997, then the new by-law on Control of Wastes was issued in 2005.
- Transboundary movement of PCB wastes are made on the basis of the Basel Convention Notification procedure.



BASEL CONVENTION



Legal Status of PCB Management in Turkey

- Stockholm Convention was signed in 2001 and Turkey became a party in 2010.
- By-Law on Control of Polychlorinated Biphenyls and Polychlorinated Terphenyls
 - prepared by approximating Council Directive 96/59/EC on the disposal of polychlorinated biphenyls and polychlorinated terphenyls (PCB/PCT)
 - issued on December 27th, 2007



Other Legislations Related to PCBs Management in Turkey

By-Law on

- General Principles of Waste Management
- Control of Waste Oils
- Restriction on Production, Placing on the Market and Use of Dangerous Substances, Preparations and Articles
- Control of Industrial Air Pollution
- Control of Soil Pollution and Contaminated Sites by Point Sources
- Control of the End-of-Life Vehicles
- Control of Waste Electrical and Electronic Equipment





PCBs Management Training Istanbul, 15-19 July 2013

• Theoretical Training (15-17 July 2013)



53 personnel from Turkish Ministry of Environment and Urbanization, other governmental and private organisations, industries having PCB equipment were trained, had an exam and got certificates.



PCBs Management Training Istanbul, 15-19 July 2013

Practical Training at Ambarli Power Plant (18-19 July 2013)



Training of Sampling from Transformers



Training of Using Mobile PCB Analyzers

30 personnel took practical training for PCB sampling and analyses with mobile PCB analyzers and got certificates.



Site Visits

- **Sampling from Online Transformers**



- **PCB Analysis in the Laboratory of Ministry**



PCB Inventory of Turkey

Category	Number of equipment	Weight of equipment
Transformers	186	982 tons
Capacitors	2782	138 tons
Contaminated equipment	31	30 tons
TOTAL		1150 tons



Notification Training in Ankara (14 January 2015)



Representatives from Turkish Ministry of Environment and Urbanization attended to Notification Training on export-import and transportation of PCBs according to Basel Convention, OECD Regulations, Regulation (EC) No 1013/2006 and Notification Procedure.




PCB Handling Training at IGSAS Facilities (23 March 2015)






PCB Handling Training at Ambarli Power Plant (26 March 2015)



Difficulties

- Preparation of PCB Inventory
- Reaching companies for surveys
- Giving information on determination of PCBs
- Collecting useful and complete data





Lessons Learnt

To raise the success of PCB Inventory and Disposal Activities

- PCB awareness should be increased
- Informing companies that they can continue using PCB equipments for more years but they should dispose them until 2025 is important
- Financial and technical support is necessary
- Site visits and analysis of the equipments is needed
- Communicating with contact person of each company is useful
- Making protocol with government institutions and getting written agreement from companies is important



Country Challenges and Needs for PCB Management



- Online PCB Inventory Program
- Completing PCB Inventory
- Increasing Disposal Capacity for PCBs (Currently we have one incineration facility for PCBs)
- Technical support for dismantling of large equipments
- Advanced decontamination technology for contaminated metals
- Advanced disposal technology for liquid PCBs
- Mobile PCB decontamination devices



Future Activities for PCBs in Turkey

Ongoing Project

- Shipment and Disposal of **550 tonnes of PCBs until end of June 2015**
- PCB Awareness Training

Remaining PCB Stocks

- 94 tonnes of unused PCBs (can be disposed within the UNEP/MAP Project)
- 513 tonnes of PCB equipments in use

GEF Project on POPs Legacy Elimination and POPs Release Reduction

- Planned to start in 2015
- Disposal of PCBs stocks
- Determination and decontamination of equipments with low PCB concentration



Thank you for your attention

Refet Sinem ATGIN

Expert

Waste Management Department

Ministry of Environment and Urbanization

Address: Ehlibeyt Mah. 1271. Sokak No:13 Balgat 06520

Ankara / TURKEY

Phone: +90 312 586 3103 Fax: +90 312 474 0335

E-mail: rsinem.atgin@csb.gov.tr

Web: www.csb.gov.tr / www.cygm.gov.tr



PCBs Management in Lebanon



PCBs in Lebanon – Introduction



- 1993; Establishment of Lebanese Ministry of Environment (Law 690)
- 1994; Government of Lebanon (GOL) signed the **Basel Convention on the control of Trans-boundary Movement of Hazardous Wastes (Law 387)**
- 2001; Government of Lebanon (GOL) signed the **Stockholm Convention on POPs** and became Party to the Stockholm Convention on January 3, 2003 (Law 432).






PCBs in Lebanon – Baseline Assessment

- 1995 and 2000, The Ministry of Environment in cooperation with Electricite du Liban (EDL) commissioned two investigations, respectively, to ascertain the extent of PCB oil in distribution transformers.
- 2004, a preliminary national inventory of PCBs in Lebanon was conducted as part of the preparation for the National Implementation Plan (NIP) for the Management of POPs. The inventory focused on transformers found in power plants, substations, and the public distribution network.
 - The inventory included a few samples of transformers in privately owned substations, but did not include equipment held by consumers of electricity.
- 2006; The country completed its **National Implementation Plan (NIP)** in accordance with the Stockholm Convention.
 - Lebanon's top priorities in POPs management are:
 - (i) awareness raising;
 - (ii) institutional and regulatory strengthening;
 - (iii) PCB management; and
 - (iv) management of emissions of dioxins and furans.



PCBs in Lebanon – 2006 NIP



- Lebanon's electricity company EDL owns and operates 7 thermal power plants, 56 substations and more than 16,000 distribution transformer stations.
- The results of this preliminary inventory can be summarized as follows:
 - Ten out-of-service transformers and 17 in-service transformers contain about 42 tonnes of PCB oil
 - The concentration of PCB oil in old and new transmission transformers are not present within detectable limits.
- EDL's 16,000 distribution transformers (not including 1,600 out-of-service transformers) contain significant quantities of PCB oil.
- There are at least seven sites in Lebanon potentially contaminated with PCB oil: 2 power plants, 4 substations and the EDL repair shop. The repair shop remains the most critical PCB hotspot; about 1,600 transformers are stored on site destined for repair or final disposal.





PCBs in Lebanon – 2010 Inventory

- A Lebanon Canadian POPs PCB project was implemented by the Ministry of Environment in collaboration with the World Bank (2010).
- The project updated the inventory of the PCB containing equipment and PCB contaminated sites.
- The survey has identified:

	In-service	Out-of-service	Total
Number of Askarel transformers	17	12	29
Total Askarel weight, tons	58	7	65
Total content of pure PCB, tons	35	4	39
Total weight of Askarel transformers, tons	147	21	168



PCBs in Lebanon – 2010 Inventory

Substation	In service			Out-of-service		
	Number of Capacitors	Weight of Capacitors, tons	Weight of PCB, tons	Number of Capacitors	Weight of Capacitors, tons	Weight of PCB, tons
9	6	0.3	0.1	501	22.9	7.6

	Weight of Contaminated Oil, Tons	% of Total Weight	Number of Contaminated Transformers (Best Estimate)	Number of Transformers (Best Estimate)
Distribution network	650-1050	67	2,500	18,800
Substations and thermal power plants	150-300	18	35	224
Hydropower plants	70-100	7	25	76
Baouchriyeh (incl. well)	100	8	280	1,900
Total	1,000-1,600		2,800	21,000



Strategic Partnership for the Mediterranean Sea Legal Marine Environment
MedPartnership

PCBs in Lebanon – 2010 Inventory

- It is considered that 2 sites are significantly more PCB contaminated than the other identified sites in Lebanon:
 - Baouchriyeh storage site and Zouk power plant.
 - Whereas the contamination at Zouk is relatively well defined and covers a small area, the contamination at Baouchriyeh is widespread and includes a well on the site.



Strategic Partnership for the Mediterranean Sea Legal Marine Environment
MedPartnership

PCBs in Lebanon – PCBs Management

- A “PCBs Management in the Power Sector Project” had been developed to dispose of high risk PCBs and improve the inventory management of transformers in the power sector in an environmentally sound manner.
- The project is implemented by the Ministry of Environment in cooperation with the World Bank and EDL.
- The project is funded by GEF through World Bank (USD 2,540,000) and co-financed by the Government of Lebanon (MoE – USD 2,500,000 – and EDL – 2,200,000). The total is around USD 7,500,000.
- The project had been endorsed by the Government of Lebanon (Decree Nb. 1552/2015).
- It will be effectively launched in April 2015.



PCBs in Lebanon – PCBs Management

The project includes 3 components:


- **Component 1. Inventory of PCB contaminated transformers**
 - This component will support a countrywide inventory of the PCB contaminated transformers in the power sector in Lebanon (entire stock of transformers and in the EDL's distribution network).
 - The purpose of the inventory to identify the contaminated transformers and their level of contamination in each site, thus providing a clear picture of the extent of PCB contamination in the power sector.
- **Component 2. Disposal of high-content PCB equipment and contaminated oil**
 - This component will support the disposal of high content PCB equipment (in-service and out-service) abroad owned by the EDL and potentially by the private sector, and of the PCB contaminated oil from repair shop according the Basel convention requirements.
 - Replacement of in – service transformers in the power plant



PCBs in Lebanon – PCBs Management

- **Component 3. Capacity building and project management**
 - This component will support: (i) establishment of a Project Management Unit (PMU) within MOE; (ii) monitoring of indicators and reporting on project performance; (iii) training and capacity building of MOE, EDL and other stakeholders (e.g. customs administration, on site workers technicians etc.) on sustainable management of PCB equipment and storage sites. In addition to the below;
 - Update the Database for EDL
 - Laboratory accreditation
 - Investigation and site assessment of the contaminated well
 - Coordinating with private companies the disposal of PCB capacitors
 - Strengthening the legal framework for improved PCB management
 - Public awareness

Day 3



EU Framework for transboundary movements of waste

- I. Regulation on shipments of waste EC 1013/2006 implementing the Basel Convention and the OECD decision on shipments of waste for recovery between OECD countries. Includes provisions as well that export of waste for disposal to non OECD countries prohibited at all times

- II. Regulation on export of non hazardous waste for recovery to non OECD countries

What does this mean for the import and export of PCBs?

- PCBs >50mg/kg considered as hazardous waste
- Basel Convention codes Y10, A3180 and A1180
- PIC procedure needs to be followed
- Export from EU to non-OECD countries is prohibited (both for recovery and final disposal)
- Import and export only possible for environmentally sound management as waste



Horizon2020



Lesson #1

Illegal trafficking in most cases occurs without any form of prior informed consent or notification!



Horizon2020



Lesson #2

Detecting and enforcing illegal trafficking of wastes requires comprehensive tactics and approaches, such as customs profiling, intelligence-led enforcement and cooperation at all levels



Horizon2020



Lesson #3

Elements that should come back in national legislative and regulatory frameworks should at least include prohibitions on the manufacture, **sale, import and export (for use)** of PCBs; and phase-out dates for PCBs that remain in service, inventory or storage

More elements are described in the Basel Convention Technical guidelines for the environmentally sound management of wastes consisting of, containing or contaminated with polychlorinated biphenyls (PCBs), polychlorinated terphenyls (PCTs) or polybrominated biphenyls (PBBs).



Horizon2020



Drivers for illegal trafficking

- Financial: avoiding high(er) treatment costs and/or making more profit
- Low risk – high profit / weak enforcement systems
- Unawareness (PCB containing parts and materials / open applications)



Modus operandi

- Concealing the PCBs or PCB-containing wastes by:
 - Using wrong customs codes
 - False declarations and paperwork
 - Loading methods
- Mixing transformers cores with metal scrap
- Using routes where risk for inspection is low => so-called port hopping



Creative loading



Examples of Harmonised Customs (HS) codes at high risk for illegal transboundary movements of hazardous waste

HS code	Declared as	In fact can be
3915	Plastic scrap	Waste plastic, mixed with other (hazardous) wastes, medical waste, used chemical bottles or municipal solid waste
7204	Metal scrap	Waste batteries, cable waste, metal scrap contaminated with hazardous waste or electronic wastes
8528	CRT monitors	Waste CRT monitors

HS code for PCB containing oils: 27.10.91

HS code for PCB containing parts: 38.24.82



Example 1: PCB containing transformers



Transformers declared as metal scrap from Germany via the Netherlands to non EU country

Samples showed that the oil contained PCBs.



Horizon2020



Example 2: Otopan case

- Case started in 1999 when the ship could not leave the port of an EU country due to financial problems of the owner
- On board was started with the non-professional removal of asbestos > alerted the health authorities, who in their turn alerted the environmental authorities
- Ship destined for dismantling to a non EU country
- Prior notification procedure was followed in this case
- Suspicions about the amount of asbestos declared, cleansing of sulphur tanks and the amount of PCBs/PCTs contaminated parts on board of the ship
- Import into the state of import was denied when the ship was still outside territorial waters (after info from NGO)
- After pre-cleansing in the country of origin, in independent survey and a new notification the ship was again sent to the non EU country for dismantling/recovery



Grey List of suspected PCB-containing materials on ships

- Cable insulation
- Rubber and felt gaskets
- Thermal insulation material
- including fibreglass, felt, foam and cork
- Transformers, capacitors (also contained in electronic equipment)
- Voltage regulators, switches, reclosers, bushings and electromagnets
- Adhesives and tapes
- Oil, including that contained in electrical equipment and motors, anchor, windlasses, hydraulic systems
- Surface contamination of machinery and other solid surfaces
- Oil-based paint
- Caulking
- Rubber isolation mounts
- Foundations mounts
- Pipe hangers
- Light ballasts
- Plasticizers



Example 3: PCBs in e-waste and waste metal cables

- PCB capacitors mentioned under code A1180, but
- in fact are shipped as second goods or as non-hazardous waste
- Mismanagement of e-waste and/or improper recovery of valuable materials exposing the population and the environment (e.g. open burning to recover the copper)

** In some cases the export of non hazardous waste for recovery from the EU to non OECD countries can be prohibited or requiring a PIC procedure.*

**Other items that can contain PCBs are for example contaminated soils, plasticizers, PVC coatings, pesticide extenders, cutting oil, flame retardants, lubricating oil, hydraulic oil, sealants, adhesives, wood floor finishes and paints.*



Horizon2020



Some inspection and enforcement challenges

- Proof that the goods are to be considered a waste
- Concentration of PCBs higher than 50mg/kg > sampling and testing procedures
- Targeting suspicious shipments
- Limited resources
- Coordination between involved authorities and countries
- Dealing with the return of illegal traffic



Horizon2020





Thank you!

Nancy Isarin
Nancy.isarin@ambiendura.com



Strategic Partnership for the Mediterranean Sea Large Marine Ecosystem
MedPartnership

Together for the Mediterranean Sea
GEF UNEP

Horizon2020
Regional Activity Centre
for Sustainable Consumption
and Production

Basel Convention
UNEP
MAP

**National and regional practices:
Inspections, Dealing with Illegal Traffic, Inter-agency and
Cross-border Collaboration**

By: Nancy Isarin

**Regional Meeting on ESM and combating Illegal Traffic of Chemicals and
Hazardous Waste in the Mediterranean**
7-9 April 2015
The Central Palace Hotel- Istanbul - Turkey

UNEP WHO FAO ILO

National inspection strategies and plans

- Refers to the **legal framework**
- Quantitative and qualitative **aims** (preferably related to indicators)
- Describe the **procedures and ways of working** of the responsible authorities
- Required resources (inspectors, legal support, equipment, IT)
- Data (reporting, sharing and analysing)
- Competences and training
- Monitoring and inspection methods
- Intervention approaches
- Enforcement measures
- Collaboration

* *Examples and templates are available.*

** *Development of waste shipment inspection plans required in the EU from 2017*



Targeting waste shipment

Necessary to use scarce inspection and enforcement resources efficiently and effectively

Identify suspicious shipments and sites by risk assessments and customs profiling, e.g.:

- Use data from multiple sources (open and closed sources) on inter alia sources of PCB wastes, possible treatments, amounts, costs, etc. to get insight in the chain and identify weak spots
- Make profiles in customs declaration system by a combination of indicators like HS code, value of the goods, trade name, destination, key words



Some trade names:

UAbestol, Aceclor, Adkarel, ALC, Apirolio, Apirorio, Areclor, Arochlor, Arochlors, Blacol, Biphenyl, Clophen, Cloresil, Chlophen, Chloretol, Chloretol (USA), Chlorfin, Cloresil, Clorinal, Clorphen, Crophene, Delor, Delorene, Delorit, Delotherm DK/DH, Diaclor (USA), Diarol, Dicolor, Diconal, Disconon, DK (Italy), Ducanol, Dyknol, Educarel, EEC-18, Elaol, Electrophenyl, Elemex, Elinol, Eucarel, Euracel, Fenclor, Fenclor, Gilotherm, Hexol, Hivar, Hydeler, Hydol, Hydrol, Hyrol, Inertenn, Kanechlor, Kaneclor, Kennechlor, Kenneclor, Leromoll, Magvar, MCS 1489, Montar, Monter, Nepoli, Nepolin, Niren, NoFlamol, No-Flamol, Non-Flamol, Olex-sf-d, Orophene, Pheaoclor, Pheneclor, Phenochlor, Phenoclor (France), Plastivar, Prodelec, Pydraul, Pyraclor, Pyralene, Pyranol, Pyroclor, Pyrochlor, Pyronol, Safe-T-Kuhl, SaftKuhl, Saf-T-Kohl, Santosol, Santotherm, Santothern, Santovac, Sat-T-America, Siclonyl, Solvol, Sorol, Soval, Sovol, Sovtol, Tarnol, Terphenychlore, Thermanol, Thermanol, Turbinol,



Horizon2020



Safety aspects

- During physical inspection and sampling personal protective equipment should be provided to **prevent skin and eye contact as well as to control respiratory exposure**, such as suitable chemical and/or oil resistant gloves goggles and protective clothing (nonporous)
- (Interim) storage of hazardous waste: PCBs or PCB items to be stored must be placed in **proper containers, covered and labelled**. Temporary storage facilities for PCB-containing waste must have a **floor-covering** that prevents penetration of PCBs and a curbing that provides sufficient containment volume in the case of a spill, roof and walls that prevent rainwater from reaching the wastes, and no floor drains or other openings that would allow liquids to flow from the area.



Horizon2020



- Do you have any experience with the return of illegally shipped waste?



Horizon2020



Detection of illegal waste shipments

- During the supervision of waste treatment sites,
- During inspections of storage facilities/dock storage,
- In the context of accidents or problems on sites,
- During checks of waste producer's documentation,
- On the basis of reports made to authorities or the police
- During inspections made during transport (road/port/train)



Horizon2020



Take back obligations (article 9 Basel Convention)

In case the illegal traffic is the responsibility of the generator or exporter, the waste in principle needs to be returned to the country of origin, or


if not practical, disposal in accordance with the provisions of the Convention



Some problems with sending back illegally shipped waste

- Lack of commonly agreed procedure > currently under development
- Bankruptcy of the the owner of the waste
- Abandoned waste at the ports
- Waste is not allowed, but further shipped outside the control of the authorities
- Unclear who to contact
- Investigation may be time consuming
- Trail of involved companies and individuals
- Financial implications





Key steps

- **Investigate and gather evidence!**
- **Keep records of all your finding!**
- **Contact the Competent Authorities in all involved states!**
- **Share information concerning the actual return shipment!**

Prosecution

- Illegal trafficking is considered a crime!
- Who is considered responsible for the illegal trafficking (jurisdiction)
- Gathering of evidence
- Who will lead the prosecution
- Sharing of evidence
- Different levels of penalties, sanctions, fines



Horizon2020



Further information

- IMPEL's Manual on the return of illegally shipped waste:
<http://impel.eu/projects/manual-on-the-return-of-illegal-shipments-of-waste>
- Basel Convention on Illegal Traffic:
<http://archive.basel.int/legalmatters/illegtraffic/index.html>
- Basel Convention guidance for prosecutors:
<http://archive.basel.int/meetings/oewg/oewg6/docs/12e.pdf>





Horizon2020



Inter-agency collaboration

- Acknowledging
- How to set up?
- What should be covered by such an agreement?



Regional approaches

- Cross-border collaboration crucial:
 - Common understanding and interpretation
 - Contact on cases and take backs
 - More equal approach and implementation
- Regional strategy or joint plan of action

EU example: IMPEL Network

European Union Network for the Implementation and Enforcement of EU Environmental Law

Aims to :

- Promote the exchange of information and experiences
- Promote the development of national networks
- Carry out joint enforcement projects
- Support, encourage and facilitate capacity building and training
- Identify and develop good best practices
- Produce guidance, tools and common standards
- Develop a greater consistency of approach
- Provide feedback and advice on better regulation issues
- Explore the use of innovative regulatory and non-regulatory instruments

www.impel.eu



Horizon2020



IMPEL Activities

- Enforcement Actions projects
- Inspector exchange programmes
- Development of tools to support inspectors
- Network for public prosecutors
- Perform peer reviews



Horizon2020



ENFORCE = Environmental Network for Optimizing Regulatory Compliance on Illegal Traffic

Aims to:

- Promote compliance with the provisions of the Basel Convention pertaining to preventing and combating illegal traffic in hazardous wastes through the better implementation and enforcement of national law.

<http://www.basel.int/Implementation/TechnicalAssistance/Partnerships/ENFORCE/tabid/3479/Default.aspx>



ENFORCE activities

- **Promoting dialogue** between its partners to develop a vision;
- Improving understanding of the issues, the role of the various stakeholders, their **challenges and needs, and how best to address them**;
- Promoting cooperation between partners and a **coordinated approach** to capacity building activities, in order to avoid duplication or gaps in the activities, to ensure a broader geographical distribution of such activities, and to prevent competition over resources;
- **Increasing the visibility** of and support for efforts aimed at preventing and combating illegal traffic.





Thank you!

Nancy Isarin
Nancy.isarin@ambiendura.com



**REGIONAL MEETING ON THE ESM AND COMBATING ILLEGAL TRAFFIC OF CHEMICALS
AND HAZARDOUS WASTE IN THE MEDITERRANEAN**

7-9 April 2015

The Central Palace Hotel – Istanbul, Turkey

GROUP EXERCISE ON ILLEGAL TRAFFIC



Shipment of possible hazardous waste

The port authorities of Country A detect two containers that are stored at the port terminal and which are leaking. When they take a closer look, they notice corrosion on the container doors. They contact the Customs. The Customs officer in charge decides to conduct a visual inspection of the shipment. Upon opening the container, one of the drums appears to be leaking, several drums have read “flammable liquid” labels on them, and some of the drums are labeled for disposal.

When checking the available paperwork, the documents state that the two containers were part of a larger shipment of 29 containers of mixed chemicals export from Country B. The total value of the goods is USD 10.000. When checking the destination as indicated in the papers, it turns out that the receiving company does not exist.

An investigations was triggered which revealed that a storage company in the state of export (country B) was ordered by the Environmental Protection Agency to clean up chemicals it had been storing illegally for years.





Question I:Identification

Outline the next steps that should be taken in your role as environmental inspector keeping the following in mind:

- How to classify the goods: waste or non-waste? Motivate why
- In case of waste, is the shipment considered hazardous waste? Motivate why
- Who is responsible for the shipment – exporter or importer or somebody else? Explain how you determine these answers.
- How would you prepare for the inspection and how would the inspection be conducted?
- Due to the potentially hazardous situation, what safety concerns exist and how would you address them?
- Is sampling necessary? Who would do the sampling?
- What documentation is necessary to determine if the shipment is legal or illegal?
- What documentation should be collected for any future legal action?
- Is coordination with any other national or international agency necessary? Have the lines of communication exist for the request of such help?

Question II:Action

Outline the steps to be taken in relation to the wastes identified, taking into account article 9 of the Basel Convention:

- Should the shipment be sent back to the exporting country? Who should be involved in this decision?
- Does the authorities of country A need to take any safety measures before the re-exporting?
- Does the authorities of country A need to communicate that this shipment is being sent back to country B? Who should be contacted in country B and how?
- Who will pay for the costs of re-exporting and other associated costs (demurrage, container lease, storage, etc)?
- Is it necessary to prosecute any company/individuals in country A? If so, how evidence will be collected?

Basel Convention Article 9

(...) 2. In case of a transboundary movement of hazardous wastes or other wastes deemed to be illegal traffic as the result of conduct on the part of the exporter or generator, the State of export shall ensure that the wastes in question are:

- (a) taken back by the exporter or the generator or, if necessary, by itself into the State of export, or, if impracticable,
- (b) are otherwise disposed of in accordance with the provisions of this convention,

within 30 days from the time the State of export has been informed about the illegal traffic or such other period of time as States concerned may agree. To this end the Parties concerned shall not oppose, hinder or prevent the return to those wastes to the State of export.